Quick Start Guide



You're now the proud owner of a Standard keyboard. Thanks for being a part of making Good Things for EVERYONE

What's Included

These accessories come with every Standard keyboard.



USB-C cable



Alternate & accent keycaps




Switch puller




Keycap puller

Connecting Your Keyboard




Turning your device on

Turn on the Standard by flipping the switch located on the bottom of the keyboard.



Connect the Standard using the provided USB-C cable to your device.



Wireless

Press ⊗ + P to initiate the pairing process. LED 1 will display a blinking white indicator during the pairing process.

Status Indicators

Charging your keyboard



Power On

Indicator blinks for 1s.

Charging 0

Indicator turns off when 0 charging is complete.



Low Battery
Indicator blinks 5 times.

Connecting your Keyboard

Broadcasting Mode (O)

Indicator blinks in 0.5s intervals for 3 minutes.

 (\bigcirc) **Device Paired**

0

\bigcirc

Indicator blinks for 1s.

Using your Keyboard

Caps Lock 0


(O) Toggle Win / macOS Layout Indicator blinks for 1s. 0

 (\bigcirc) **Switching Devices** Indicator blinks for 1s.

(A) Windows Hotkeys

monokei.co/standard

Windows Hotkeys



Press with any of these keys:

- Decrease Display brightness
- F2 Increase Display brightness
- F3) Swap Ctrl / Caps Lock
- F7 Previous Track
- F8 Play and Pause
- F9 Next Track
- F10 Volume Mute
- Volume Down
- Volume Up

- Print Screen
- Toggle Win Key (hold for 2s)
- Reset Device (hold for 10s)
- Switch to macOS Layout (hold for 2s)
- Initiate Pairing
- Switch to Device 1 (hold for 0.5s)
- Switch to Device 2 (hold for 0.5s)
- Switch to Device 3 (hold for 0.5s)
- Switch to Device 4 (hold for 0.5s)
- Switch to Device 5 (hold for 0.5s)