

TECH SPECS:

- Input voltage ..... 5V
- Output Power ..... 5W x 2
- Audio input (PC) ..... Wireless, TF, USB
- Battery ..... 2000 mAh
- Frequency range ..... 35Hz-16kHz
- Dimensions (L x W x H) ..... 15 x 2.5 x 2.5 IN
- Weight ..... 0.9 lbs

CONNECTING A WIRELESS DEVICE:

Power the speaker on using the ON/OFF switch

On your device’s wireless connection menu, find and select the device “ColorWav”

The blue LED on top of the speaker will flash while waiting to connect

Once connected you will hear “paired” and the blue LED on top of the speaker will remain illuminated

When the battery is low, the speaker will indicate by saying, “low battery”



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

CHARGING THE COLOR WAV SPEAKER:

Ensure the speaker is fully charged before first use

Plug the included charging cable into the charging port of the speaker and connect the USB-A end of the cable into a compatible power source

A red LED light by the charging port will illuminate, indicating the speaker is charging

When the device indicates the battery is low, approx. 4-5 hours of charging time is needed to fully recharge the battery

SAFETY INFORMATION:


Do not attempt to disassemble, repair, or modify this device

Do not expose the speaker to extreme temperatures

The speaker may become warm while charging, this is normal

Do not expose the speaker to water or humidity

BUTTON FUNCTIONS:



- 1 PLAY/PAUSE
- 2 SHORT PRESS TO PLAY PREVIOUS SONG  
LONG PRESS TO LOWER THE VOLUME
- 3 SHORT PRESS TO PLAY NEXT SONG  
LONG PRESS TO RAISE THE VOLUME
- 4 PRESS TO SWITCH THE RGB LIGHT MODE