

Front

 **IMPORTANT** 
PLEASE DO NOT RETURN TO STORE
 If You're Having Trouble, We're Here to Help!



Call us 24/7 at 1-855-292-4087
 E-mail us at alsupport@sakar.com or visit us at alteclansing.com

Rear

REGISTER YOUR PRODUCT

To receive news, exclusive deals, OTA or firmware updates, warranty information and more please register your product at

alteclansingsupport.com




WELCOME 

Thank you for purchasing an Altec Lansing product. It's our goal to make sure you are happy. Share your happiness with our customer concierge.





 follow us
[@alteclansingofficial](#)


 follow us
[@alteclansing](#)


 follow us
[@alteclansingofficial](#)

12 Month Limited Warranty
 All Altec Lansing products come with 12 month limited warranty from the date of its original purchase

24 Hour Customer Support
 We love our customers, and we care about your experience with Altec Lansing. If you need assistance, please call us at 1.855.292.4087 or e-mail alsupport@sakar.com

www.alteclansing.com





JUST LISTEN.





Baby Boom XL
 Rugged Wireless Speaker

IMW270
 QUICK START GUIDE


In the Box 



 Baby Boom XL Rugged Wireless Speaker


 USB-C Charging Cable


 Carabiner


Front


A Closer Look 




Power Button
Volume Down/Previous Track
Volume Up/Next Track
LED Indicator Light
Charging Port


Rear

Charging 




● (red) = Charging
○ (off) = Charging Complete
≈2-3 Hours Full Charge


Powering On/Bluetooth Pairing 




1-2 SEC PRESS & HOLD
Pairing Mode Red & Blue Flashing LED
Paired Blue Flashing LED
Bluetooth ON
Baby Boom XL connected

Controlling Music 

PRESS	PRESS & HOLD (2 sec)
⏪ Volume Up	⏻ On/Off
⏩ Volume Down	⏭ Next Track
⏸ Play/Pause	⏮ Previous Track




True Wireless Mode Part 1 


After connecting Bluetooth with first speaker, power on second speaker.
PRESS & HOLD 2-3 SECONDS

Tap the '⏻' button to enter pairing Mode on the second speaker.


Tap the '⏻' and '-' buttons simultaneously to enter True Wireless Mode on the first speaker.



Red & Blue Flashing LED
Red & Blue Flashing LED
Second Speaker
First Speaker
PRESS & HOLD 1-2 SEC
PRESS & HOLD 3 SEC

Phone Calls/Voice Assistant 

PRESS	PRESS & HOLD (2 sec)
⏻ Answer Call	⏻ Reject Incoming Call
⏻ End Call	Press x2 ⏻




To activate Voice Assistant and speak to Siri or Google Assistant

Overall battery performance varies dependent upon use, settings and environmental conditions. For further information, please visit www.alteclansing.com

Front

Rear

True Wireless Mode Part 2



Once both speakers are in True Wireless mode, they will automatically pair with a Bluetooth enabled device.

With the speakers connected, Stereo Mode uses the speakers as a left and right channel to create a cinematic experience.

FOLLOW US ON



#myalteclansing

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Saker International Inc.
195 Carter Drive
Edison, New Jersey 08817, USA
855-292-4087
www.alteclansing.com