



Thanks for using this product. It's a one hand gamepad, can control mobile phones and tablets. Support Android and IOS system. This product has been successfully invented and used after many tests. It is reasonable and professional designed according to human engineering, which makes it more flexible and comfortable to use.

This product has applied for national use, appearance patent, insproduct has applied for handled as appearance patent, invention patent, intellectual property rights, and passed the CE, FCC, RoHS certificates. The product comes with user manual. Product are subject to be changed and updated after sale without further patients.

Fronce are suggested by the further notice.


Remark: If any, counterfeit, imitation, etc., the company has the right to investigate its legal responsibility.

## How to install to mobile phone:

Put the phone on the spring pad

Spring pad 

Shooting PlusV3



() ()



Charging precautions: Activation switch must be set to N for normal charging. The switch at P is for activate the gamepad. (If the activation function is damaged due to user's misoperation

## GM100 how to connect to Bluetooth

it is not covered by the warranty.)

Game Mode	Game shift mode	Bluetooth Name	Connection Status
Android Mode	Long press power key to open bluetooth	GM100	Blue light flashing while disconnected Blue light keeps on while connected
IOS 13.4 and above mode	Long press iso key to open bluetooth	GM100	Green light flashing while disconnected Green light keeps on while connected



Open settings to activate: Continuously click Android version number or MIUI version number for 7 times to enter developer mode, and open the following options: open developer options, USB debugging [Safe mode]. As shown below:

\_\_\_\_\_ Open ShanWanGamepad to connect Bluetooth and prepare to activate. This product comes with activator, long press the power key for 3 seconds to boot, after Bluetooth connected, shift the activation swifch to P, then insert the connector to the gaming controller, connect to data cable, the type – C USB side connect to mobile phone. As shown below.



How to activate the gaming controller: 1)Active -Device- (make sure the manual switch is at P from Gaming controller)-Next step -No data transfer-OK- Activation

Gaming Continery-New Step - No data I anister-UK: Activation completed.

Other light will cloudy flach, until the App choice it is artivated shafter activation, shift the manual switch to N. 4)Click on the game you want to play, click ShanWanGamepad floating window "+" to set A key and 13 key function to save.



2: For liphone
1)When screen is on, turn off "assistive touch" from settings.
2)Download app "Shooting PlusV3" from app store, Shooting
PlusV3 floating window should be always allowed in the
authorization management of your phone.
3)Click the game you want to play, click Shooting PlusV3 floating
window "\*-" to set up A key and L3 key function and save.
As shown below:



Attenuors:

1) This product: 1, power key, 2, IOS key, 3, A key, long press have the function of switch off the gaming controller.

2) The gaming controller goes into standby after five minutes of

3)Long press A key for 3 seconds the gamepad will connect back to Bluetooth automatically.

Product specification:

Hemi Specification
Product model No. GM100
Product dimensions Vermissishmensform
Wellers protocol
Wellers protocol
Support specification
Support specification
Support specification
Support specification
Support specific

## FCC ID:

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. these limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and an radiate radio frequency energy and, if not installed and

used in accordance with the instructions, may cause harmful

interference to radio communications.

However, there is no guarantee that interference will not occur
in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of

说明书制作要求: SIZE:85\*73mm 材质: 105g铜版纸

折页,中英文正反两面,黑白印刷