

2.4 GHz

INSTRUCTION MANUAL



*IMPORTANT: PLEASE DO NOT RETURN TO STORE
For more information please contact Customer Services: help@hypertoys.com





This device complies with the Part 15 of the FCC rules, Operation is subject to the following two conditions.

This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FC Mask. These limits are designed to provide reasonable protection gainst harmful interference in a residential inside after in the result of the resul

SGS ENERGY EFFICIENC


@Copyright 2025 HyperToy: MADE IN CHINA

DISTRIBUTED BY: HYPER TOY COMPANY 1-866-204-9737 Toll Free



BATTERY SAFETY

- (1) The placement or replacement of batteries is to be performed by an adult.
- (2) Remove the rechargeable battery from the chassis before charging. (3) Always remove exhausted batteries from the car and the transmitter.
- (4) Make sure the main switch is set to OFF before installing the battery pack into the car body.
- (5) Batteries must be inserted with the correct polarity.
- (6) Non-chargeable batteries shall not be recharged.
- (7) Do not short-circuit the batteries.
- (8) Always remove the batteries from the car and the transmitter after playing.
- (9) Never throw the batteries into fire to avoid explosion or leakage.
- (10) Do not mix batteries from different producers or new and old hatteries
- (11) You should only use batteries of the same or equivalent types as recommended.
- (12) Check the batteries on a regular basis to avoid leakage.
- (13) Keep this manual well for future reference as it contains important information about this product.



Product Operation Manual

7.Slide to the rear left corner

Open the battery cover on the car, install 1* 7.4V rechargeable battery pack, fasten the cover and turn the switch to "On".



Basic Product Operations



Push forward

As shown in the above picture, push the remote control lever to right, and the car will turn right 360°. Slowly push the remote control lever, and the car will accelerate slowly.

HYFER!! Push forward Push it to the right Push forward Push to the left Push back Push to the left Push back Push it to the right 0. As shown in the above picture, push the remote contro lever to control the car move backward and turn right at the same time. Slowly push the remote control lever, and the car will accelerate slowly. 13. As shown in the above picture, press the button to control the car slid to the right side.

