


Monster Airmars XKT03说明书

尺寸: 73X93mm 材质: 80克双胶 单黑 6折7页









Charge the charging case

charging cable.




Connect the charging case to the 5V power adapter with Type-C



* Unplug the charging cable after charging.


Open the charging case, the headphones will turn on automatically.



Either headphones is not connected to the bluetooth device when turned on, click the MFB 5 times to clear the previous pairing information and turn off.

Operation

Normal



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is

(1) This device may not cause harmful interference, and (2) this device must accept any

Changes or modifications not expressly approved by the party responsible for compliance

Headphones will turn on automatically (needless to press any button) pair and connect the device when the charging case is opened. After placing the headphones in the charging case, they will turn off and automatic charging will start when the cover is closed.

Charging every 15 days will extend battery life when not in use often. Cleaning off dirt on the charging contacts by cotton swabs with alcohol will maintain a good contact for

Intermittent is normal during playback for wireless products due to environmental factors, device brand, users' behavior, etc.

- WarningS

 1. Do not use headphones at high volume for an extended period of time.

 2. Keep the headphones away from dust and water.

 3. Do not disassemble the headphones and accessories, otherwise warranty will be voided.
- 4. Keep headphones away from any impact or vibration.
 5. Do not use any chemical solvents or cleaning agent on the headphones.

Name of the Parts	Hazardous Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing	0	0	0	0	0	0
Loudspeakers	0	0	0	0	0	0
PCBA	Х	0	0	0	0	0
Accessories	X	0	0	0	0	0

This table is compiled according to SJ/T 11364.

- Environment Friendly Use Period (EFUP)

