


型号: Airmars XKT09

尺寸: 73*93

材质: 80g铜版纸 (折页)




Airmars XKT09


真无线蓝牙耳机
使用说明书

产品参数


- 传输距离 ----- 10m
- 喇叭直径 ----- φ13mm
- 喇叭阻抗 ----- 32Ω±15%
- 灵敏度 ----- 115±1.5dB
- 频率范围 ----- 20Hz-20kHz
- 电池容量(充电盒) ----- 3.7V 300mAh
- 电池容量(耳机) ----- 3.7V 30mAh
- 充电时间(充电盒) ----- ≈1.5小时
- 播放时间(耳机) ----- ≈5小时
- 配合充电盒播放时间 ----- ≈24小时


包装清单

耳机 *2

充电盒 *1

产品示意图

多功能控制
(MFB)
指示灯
充电盒

Type-C接口

产品操作说明

1. 开机

方法一: 打开充电盒盖, 耳机自动开机。
方法二: 单边耳机开机长按对应MFB

2. 关机

方法一: 将耳机放回充电盒, 关上充电盒盖, 耳机关机。
方法二: 双击设备断开连接3分钟后, 自动关机。

3. 配对

方法一: 打开充电盒盖, 耳机自动开机并配对。
方法二: 打开智能设备的蓝牙列表, 搜索 "Monster Airmars XKT09"
进行配对, 连接成功后, 你会听到提示音 "Connected"。
* 超出距离, 在新开连接3分钟内, 回到有效范围, 自动连接设备。

触控键操作

常规模式

语音助手: 长按2秒左MFB
音量加: 单击右MFB
音量减: 单击左MFB

音乐播放模式

暂停/播放: 双击左/右MFB
上一曲: 三击左MFB
下一曲: 三击右MFB

电话免提

接听: 双击左/右MFB
拒接: 长按2秒左/右MFB
挂断: 双击左/右MFB

游戏模式/音乐模式: 已联设备

长按2秒右MFB进入游戏模式
长按2秒右MFB进入音乐模式

恢复出厂设置

任意一个耳机开机后未与蓝牙设备连接状态下, 连续单击耳机功能键3次清除配对信息后关机。

注意

1. 充电盒开盖后, 不需按任何按键, 耳机自动开机。配对并连接: 耳机放入充电盒并合盖后, 充电盒将自动给耳机充电, 耳机关机。

2. 常清洗, 寿命长, 如长期不用, 建议15天充电1次, 延长电池寿命。耳机尾塞部分经常用棉签酒精擦拭, 能辅助耳机防潮, 避免接触不良, 影响使用体验。

3. 耳机由电池供电, 如长时间不用, 请取出耳机并取出电池, 避免电池漏液及过热环境中。

4. 由于本电子产品采用无线传输方式, 在日常使用过程中, 受到环境、手机品牌、使用行为等因素影响, 可能在播放音乐过程中, 会出现卡顿、轻微的声音卡顿属于正常现象。

警告

1. 长时间以高音量使用耳机可能会损害您的听力, 建议只使用适当音量收听、通话和听音乐。

2. 请不要冲凉或将产品放入水中, 以免造成故障。

3. 不要自行拆卸产品及配件, 以免造成损坏及保修失效。

4. 请勿使产品受到强烈冲击或震动以免损坏。

5. 请勿使用化学溶剂或清洗剂清洗产品。

Name of the Parts 部件名称	Hazardous Substances 有害物质					
	Pb 铅	Hg 汞	Cd 镉	Cr(VI) 六价铬	多环芳烃 PAHs	邻苯二甲酸酯 PDE
Housing 外壳	0	0	0	0	0	0
Loudspeakers 喇叭单元	0	0	0	0	0	0
PCBA 电路板组件	X	0	0	0	0	0
Accessories 电源线、连接线	X	0	0	0	0	0

This table is compiled according to SJ/T 11364.

本表格依据SJ/T 11364的规定编制。

0: Indicates that the hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

※: Indicates that the hazardous substance is not contained in this part.

Environment Friendly Use Period (EFUP)
环保使用年限

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or migrate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

该标志仅指使用期限 (10年): 指电子产品中有害物质在正常使用条件下不会发生泄漏或迁移, 电子产品在使用过程中不会发生任何严重的环境污染、任何人身伤害或资产损失。

FCC 声明

该设备经过测试, 符合B类数字设备的限制, 根据FCC规则第15部分。这些限制旨在提供合理的限制住宅装置中防止有害干扰的防护。该设备产生使用并能辐射射频能量, 如不按规定的安装和使用该指示可能对无线电通信造成有害干扰。然而, 有不能保证在特定的安装中不会发生干扰。如果这个设备对收音机或电视接收造成有害干扰, 可通过转动判定设备的开关, 鼓励用户尝试纠正干扰之一或更多以下措施:

—重新定位或重新安装接收天线。

—增加设备与接收器之间的距离。

—将设备连接到与接收器不同的电路上的插座上连接。


—向经销商或有经验的无线电/电视技术人员寻求帮助。

该设备符合FCC规则第15部分。操作遵循以下两点条件:

(1)本装置不得引起有害干扰。

(2)本装置必须接受任何干扰接收到的干扰, 包括可能导致不希望的操作的干扰。

未得到合规方明确批准的变更或修改可能使用户对设备的操作权限失效。




Airmars XKT09


BLUETOOTH WIRELESS HEADPHONES
INSTRUCTIONS MANUAL

Product parameters


- Transmission distance ----- 10m
- Driver diameter ----- φ13mm
- Driver impedance ----- 32Ω±15%
- Sensitivity ----- 115±1.5dB
- Frequency response range ----- 20Hz-20kHz
- Battery capacity (charging case) ----- 3.7V 300mAh
- Battery capacity (Headphone) ----- 3.7V 30mAh
- Charging time (charging case) ----- ≈1.5 hours
- Music playtime (headphone) ----- ≈5 hours
- Music playtime with charging case ----- ≈24 hours


Packing list

Headphone *2

Charging Case *1


Product Schematic Description

Multi-function buttons
(MFB)
Indicator light
充电盒

Type-C Interface

Charge the charging case

Connect the charging case to the 5V power adapter with Type-C charging cable.



Rated input: 5V=30mA(Headphone) Rated input: 5V=300mA (charging case)
Tips:When the ice blue indicator flashes while closing the cover,please charge in time.

Indicator guide

Mode	Describe	Sound prompt
Power On	Earphone blue indicator is on for one second	"Power on"
Power Off	—	"Power off"
Pairing	The earphone blue indicator blinks	"Pairing"
Connected	Headphone indicator off	"Connected"
Disconnected	The earphone blue indicator blinks	"Disconnected"
Low Battery	—	"Battery Low"
Headphones placed in charging case	The blue light stays on for 4 seconds and then goes off	—
Charging case low power	The blue light flashes 4 times in a row	—
Charging case charged	The red light flashing	—
Charging case fully charged	Normally on a red light	—

Product operating instructions

1. Power on

Method 1: Open the charging case, the headphones will turn on automatically.
Method 2: Long press the corresponding MFB when the unilateral headset is turned on

2. Power off

Method 1: Put the headphones into the charging case and close the cover.
Method 2: after disconnected from the Bluetooth device for 3 minutes.

3. Pairing

Method 1: open the charging case, the headphones will start pairing automatically.
Method 2: search and click for "Monster Airmars XKT09" on the Bluetooth list of the smart device, and when connection is successful, "Connected" will be heard.

* Headphones will try reconnecting to the device within 3 minutes when connection is lost.

Operation

Normal

语音助手: Press the left MFB for 2 seconds
Volume + : Click right MFB
Volume - : Click left MFB

Music playback

Pause/Play: Double click Left/Right MFB
Last song: Triple click left MFB
Next song: Triple click right MFB

Phone

Answer: Double click the left/right MFB
Reject: Press left/right MFB for 2 seconds
Hang up: Double click the left/right MFB

Game/music switching device connected

Press right MFB for 2 seconds to enter game mode
Press right MFB for 2 seconds to enter music mode

Restore factory settings

Either headphones is not connected to the Bluetooth device when turned on, click the MFB 3 times to clear the previous pairing information and turn off.

Precautions

1. Headphones will turn on automatically (needless to press any button) pair and connect the device when the charging case is opened. After placing the headphones in the charging case, they will turn off and automatic charging will start when the cover is closed.

2. Charging every 15 days will extend battery life when not in use often. Cleaning off dirt on the charging contacts by cotton swabs with alcohol will maintain a good contact for charging.

3. Keep battery (battery pack) away from inflammables or excessive heat such as direct sunlight.

4. Intermittent is normal during playback for wireless products due to environmental factors, device brand, users' behavior, etc.

Warnings

1. Do not use headphones at high volume for an extended period of time.

2. Keep the headphones away from dust and water.

3. Do not disassemble the headphones and accessories, otherwise warranty will be voided.

4. Keep headphones away from any impact or vibration.

5. Do not use any chemical solvents or cleaning agent on the headphones.

Name of the Parts	Hazardous Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing	0	0	0	0	0	0
Loudspeakers	0	0	0	0	0	0
PCBA	X	0	0	0	0	0
Accessories	X	0	0	0	0	0

This table is compiled according to SJ/T 11364.

0: Indicates that the hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

※: Indicates that the hazardous substance is not contained in this part.

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info

User name

Email

Contact number

Postal code

Mailing address

Product information

Product name

Product number

Product barcode / Serial number / Batch number

Vendor information

Name

Address

Contact number

Postal code

Sales date

Invoice number

Remark

Certificate of Approval

Product No.: _____

Production Time: _____

QC: _____

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, it can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.

— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID : 2ABY-GSMXKT09

