

XKT16说明书

尺寸：60*95mm

材质：80g铜版纸（胶装方式双面印）



Airmars XKT16

真无线蓝牙耳机
使用说明书

封面


产品参数

- 蓝牙版本-----V5.3
- 传输距离-----10m
- 喇叭直径-----φ13mm
- 喇叭阻抗-----32Ω±15%
- 灵敏度-----108±3dB
- 频响范围-----20Hz-20kHz
- 电池容量(充电盒)-----280mAh 3.7V
- 电池容量(耳机)-----30mAh 3.7V
- 充电时间(充电盒)-----≈1.5小时
- 播放时间(耳机)-----≈4小时
- 配合充电盒播放时间-----≈16小时

包装清单

耳机 *2	充电盒 *1
使用说明书 *1	Type-C充电线 *1

产品示意图



给充电盒充电

用Type-C充电线连接充电盒到5V电源适配器。



额定输入：5V==30mA(耳机) 额定输入：5V==280mA(充电盒)
温馨提示：当关闭充电盒盖，红色指示灯闪烁时，请给充电盒充电。

指示灯指南


模式	描述	语音提示
开机	耳机蓝色指示灯亮一秒	"Power on"
关机	—	"Power off"
配对	耳机蓝色指示灯闪烁	"Pairing"
连接	耳机指示灯熄灭	"Connected"
断开	耳机蓝色指示灯闪烁	"Disconnected"
耳机低电	—	"Battery Low"
充电盒给耳机充电	蓝灯常亮4秒后熄灭	—
充电盒低电	蓝灯连续闪烁4次	—
充电盒充电	红灯闪烁	—
充电盒充满	红灯常亮	—

产品操作说明

1. 开机
方法一：打开充电盒盖，耳机取出后自动开机
方法二：左右耳机长按功能键3秒开机

2. 关机
方法一：将耳机放回充电盒，关上充电盒盖，耳机关机。
方法二：与蓝牙设备断开连接3分钟后，自动关机。

3. 配对
方法一：耳机取出后自动开机并配对
方法二：打开智能设备的蓝牙列表，搜索 "Monster Airmars XKT16" 进行配对，连接成功后，你会听到提示音 "Connected"。
* 超出距离，在断开连接3分钟内，回到有效距离，自动连接设备。



注意：
* 如果产品长时间不使用，应先充满电，并确保设备处于关机状态。
* 充电完成后，请将充电线拔出，避免长时间充电造成设备损坏。

触控键操作

常规模式



语音助手：长按2秒左MFB
音量加：单击左MFB
音量减：单击左MFB

音乐播放模式



暂停/播放：双击左/右MFB
上一曲：三击左MFB
下一曲：三击右MFB

电话免提



接听：双击左/右MFB
拒接：长按2秒左/右MFB
挂断：双击左/右MFB

游戏模式/音乐模式切换：已联设备



长按2秒右MFB进入游戏模式
长按2秒右MFB进入音乐模式

清除蓝牙设备设置

耳机开机后未连接蓝牙设备状态下，任意一个耳机三击左/右耳机MFB键，断开耳机与蓝牙设备配对并关机

注意

1. 充电盒开盖后，不需按任何按键，耳机自动开机，配对并连接；耳机放入充电盒并合盖后，充电盒将自动给耳机充电，耳机关机。
2. 常清洁，寿命长，如长期不用，建议15天充电一次，延长电池寿命。耳机需靠充电部分经常得充电，保持电量，避免电量耗尽，影响使用体验。
3. 电池(电池组或电池组合)不得暴露在烈日、烘烤或类似过热的环境中。
4. 由于本款产品采用无线连接方式，在日常使用过程中，受到环境、手机品牌、使用行为等因素影响，可能在播放音乐过程中，会出现短暂、轻微的声音卡顿属于正常现象。

警告

1. 长时间以高音量使用耳机可能会损害您的听力，建议只使用适当音量收听、通话和听音乐。
2. 请不要冲洗或将产品浸入水中，以免造成故障。
3. 不要自行拆卸产品及配件，以免造成损坏及保修失效。
4. 请勿使产品受到强烈冲击或震动以免损坏。
5. 请勿使用化学溶剂或清洗剂清洗产品。

Name of the Parts 部件名称	Hazardous Substances 有害物质					
	Pb 铅	Hg 汞	Cd 镉	Cr(VI) 六价铬	PBB 多溴联苯	PBDE 多溴二苯醚
Housing 外壳	O	O	O	O	O	O
Loudspeakers 喇叭单元	O	O	O	O	O	O
PCBA 电路板组件	X	O	O	O	O	O
Accessories 电源座、连接线	X	O	O	O	O	O

This table is compiled according to SJ/T 11364.
本表格依据SJ/T 11364的规定编制。

O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
O: 表示所有有害物质在该部件所有均质材料中的含量均在 GB/T 26572 标准规定的限量要求以下。
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.
X: 表示所有有害物质至少在该部件的某一均质材料中含量超过 GB/T 26572 标准规定的限量要求。

Environment Friendly Use Period (EFUP)
环保使用年限

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.
该标志是指按照限制 (10年) 期间内电子产品中有害物质在正常使用条件下不会发生外泄或突变，电子产品用户使用该电子产品不会对环境造成严重污染或对人体健康、财产造成严重损害的限制。

保修卡

尊敬的用户，本保修卡是您将来申请保修的凭证，请您配合销售商填写并妥善保管备用！

用户信息

用户姓名	电子邮件
联系电话	邮政编码
通讯地址	
产品信息	
产品名称	产品型号
产品条码/编号/批号	
销售商信息	
名 称	
地 址	
联系电话	邮政编码
销售日期	发票号码
备 注	
产品编号： 生产日期： 售 后 服 务	

FCC 声明

该设备经过测试，符合B类数字设备的限制，根据FCC规则第15部分。这些限制旨在提供合理的限制住宅装置中防止有害干扰的防护，该设备产生使用并能辐射射频能量，如不按规定安装和使用该指示可能对无线电通信造成有害干扰。然而，有不能保证在特定的安装中不会发生干扰。如果这个设备对收音机或电视接收造成有害干扰，可通过转动判定设备的开关，鼓励用户尝试纠正干扰之一或更多以下措施：

- 重新定位或重新安置接收天线。
- 增加设备与接收器之间的距离。
- 将设备连接到与接收器不同的电路上的插座上连接。
- 向经销商或有经验的无线电/电视技术人员寻求帮助。

该设备符合FCC规则第15部分。操作遵循以下两点条件：
(1)本装置不得引起有害干扰。(2)本装置必须接受任何干扰接收到的干扰，包括可能导致不希望的操作的干扰。

未得到合规方明确批准的变化或修改可能使用户对设备的操作权限失效。

FCC ID: 2A8PV-QSMXKT16

封面

1

2

3

4

5

6


Product parameters

- Bluetooth version-----V5.3
- Transmission distance-----10m
- Driver diameter-----φ13mm
- Driver impedance-----32Ω±15%
- Sensitivity-----108±3dB
- Frequency response range-----20Hz-20kHz
- Battery capacity (charging case)-----280mAh 3.7V
- Battery capacity (Headphone)-----30mAh 3.7V
- Charging time (charging case)-----≈1.5 hours
- Music playtime (headphone)-----≈4 hours
- Music playtime with charging case / 配合充电盒播放时间: ≈16 hours

Packing list


Headphone *2	Charging Case *1
Instructions Manual *1	Type-C Charging Cable *1

Product Schematic Description



Charge the charging case

Connect the charging case to the 5V power adapter with Type-C charging cable.



Rated input: 5V==30mA(Headphone) Rated input: 5V==280mA (charging case)
Tips: When the ice blue indicator flashes while closing the cover, please charge in time.

Indicator guide

Mode	Describe	Sound prompt
Power On	Earphone blue indicator is on for one second	"Power on"
Power Off	—	"Power off"
Pairing	The earphone blue indicator blinks	"Pairing"
Connected	Headphone indicator off	"Connected"
Disconnected	The earphone blue indicator blinks	"Disconnected"
Low Battery	—	"Battery Low"
Headphones placed in charging case	The blue light stays on for 4 seconds and then goes off	—
Charging case low power	The blue light flashes 4 times in a row	—
Charging case charged	The red light flashing	—
Charging case fully charged	Normally on a red light	—


Product operating instructions

1. Power on
Method 1: Open the cover of the charging box, and turn on the headset automatically after taking it out.
Method 2: The left/right ear captain presses the function button for 3 seconds to start the machine

2. Power off
Method 1: put the headphone/s into the charging case and close the cover.
Method 2: after disconnected from the Bluetooth device for 3 minutes.

3. Pairing
Method 1: After the earphones are removed, they are automatically turned on and paired
Method 2: search and click for "Monster Airmars XKT16" on the Bluetooth list of the smart device, and when connection is successful, "Connected" will be heard.

* Headphones will try reconnecting to the device within 3 minutes when connection is lost.



Note:
* Fully charge the headphones and power off before an intended not-in-use period.
* Unplug the charging cable after charging.

Operation

Normal



Voice assistant: Press the left MFB for 2 seconds
Volume +: Click right MFB
Volume -: Click left MFB

Music playback



Pause/Play: Double click Left/Right MFB
Last song: Triple click left MFB
Next song: Triple click right MFB

Phone



Answer: Double click the left/right MFB
Reject: Press left/right MFB for 2 seconds
Hang up: Double click the left/right MFB

Game/music switching: device connected



Press right MFB for 2 seconds to enter game mode
Press right MFB for 2 seconds to enter music mode

Clear Bluetooth device Settings

When the headset is not connected to the Bluetooth device after startup, press the left/right headset MFB button three times on any headset to disconnect the headset from the Bluetooth device and shut it down

Precautions

1. Do not use headphones at high volume for an extended period of time.
2. Keep the headphones away from dust and water.
3. Do not disassemble the headphones and accessories, otherwise warranty will be voided.
4. Keep headphones away from any impact or vibration.
5. Do not use any chemical solvents or cleaning agent on the headphones.

Warnings

1. Do not use headphones at high volume for an extended period of time.
2. Keep the headphones away from dust and water.
3. Do not disassemble the headphones and accessories, otherwise warranty will be voided.
4. Keep headphones away from any impact or vibration.
5. Do not use any chemical solvents or cleaning agent on the headphones.

Name of the Parts	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing	O	O	O	O	O	O
Loudspeakers	O	O	O	O	O	O
PCBA	X	O	O	O	O	O
Accessories	X	O	O	O	O	O

This table is compiled according to SJ/T 11364.
O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

Environment Friendly Use Period (EFUP)

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Specifications

Bluetooth version / 蓝牙版本: V5.2
Transmission distance / 传输距离: 10m
Driver diameter / 喇叭直径: φ13mm
Driver impedance / 喇叭阻抗: 32Ω±15%
Sensitivity/灵敏度: 126±1.5dB
Frequency response range / 频响范围: 20Hz-20kHz
Battery capacity (Charging case) / 电池容量(充电盒): 280mAh 3.7V
Battery capacity (Headphone) / 电池容量(耳机): 30mAh 3.7V
Charging time (Charging case) / 充电时间(充电盒): 1.5 hours
Music playtime with charging case / 配合充电盒播放时间: ≈16 hours

人体工学设计，佩戴舒适
Ergonomic Design
Ergonomie pour le confort
Ergonomisches Design für Komfort
дызайн, удобство ношения
인체공학 디자인으로 편안함 착용
人体工学设计，着用快適

综合续航长达16小时
16 Hours of Playtime
Durée de vie combinée jusqu'à 16 heures
Umfassende Ausdauer bis zu 16 Stunden
общая продолжительность работы до 16 часов
최대 16시간 사용
総合航続時間は16時間に及ぶ

Monster定制音效
Monster Customized Acoustics
Effect sonores personnalisés Monster
Monster angepasste Soundeffekte
Монстр настраивает звуковые эффекты
Monster 커스텀 사운드
Monsterカスタムサウンド

音乐/游戏双模式
Music/Gaming Dual Modes
Double mode musique / jeu
Musik und Spiel dual mode
двойной режим
음악 / 게임 듀얼 모드
音楽/ゲームデュアルモード

高清晰通话
Hi-d call
Appels en hd
Gestochen wie hd.
Связь в высоком разрешении
고질질 음성
hd通話です

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info

User name	Email
Contact number	Postal code
Mailing address	
Product information	
Product name	Product number
Product barcode / Serial number / Batch number	
Vendor information	
Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	
产品编号： 生产日期： 售 后 服 务	

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: 2ABPV-QSMXKT16

7

8

9

10

11

12

13