


型号：Airmars XKT20

尺寸：73*93

材质：80g铜版纸（折页）



Monster Airmars XKT20

真无线蓝牙耳机
使用说明书


产品参数

- 蓝牙版本 ----- V5.3
- 传输距离 ----- 10m
- 喇叭直径 ----- ϕ13mm
- 喇叭阻抗 ----- 32Ω±15%
- 灵敏度 ----- 96±3.0dB
- 频响范围 ----- 20Hz-20KHz
- 电池容量(充电盒) ----- 300mAh 3.7V
- 电池容量(耳机) ----- 30mAh 3.7V
- 充电时间(充电盒) ----- ≈1.5小时
- 播放时间(耳机) ----- ≈4小时
- 配合充电盒播放时间 ----- ≈18小时


包装清单

	耳机 *2		充电盒 *1
	Type-C充电线 *1		使用说明书 *1

产品示意说明




多功能按键 (MFB)
指示灯



LCD屏
充电接口

给充电盒充电

用Type-C充电线连接充电盒到5V电源适配器。




额定输入：5V==30mA(耳机) 额定输入：5V==300mA(充电盒)

指示灯指南

模式	描述	语音提示
开机	耳机冰蓝色指示灯闪烁3次	"Power on"
关机	耳机橙色指示灯长亮15熄灭	"Power off"
配对	耳机冰蓝色指示灯交替闪烁	"Pairing"
连接	耳机指示灯熄灭	"Connected"
断开	耳机冰蓝色指示灯交替闪烁	"Disconnected"
耳机低电	耳机橙色指示灯快闪	"Battery low"
充电盒给耳机充电	耳机橙色指示灯长亮	—
充电盒低电	充电盒显示屏圆圈内显示0%至显示熄灭	—
充电盒充电	充电盒显示屏圆圈内显示百分比 递增至100%	—
充电盒充满	充电盒显示屏显示100%后熄灭	—

注意：

- * 如果产品长时间不使用，应充满电，并确保设备处于关机状态。
- * 充电完成后，请将充电线拔出，避免长时间的充电造成设备损坏。



触控键操作

常规模式

- 语音助手：长按2秒左/MFB
- 音量加：单击右MFB
- 音量减：单击左MFB

音乐播放模式

- 暂停/播放：双击左/右MFB
- 上一曲：三击左MFB
- 下一曲：三击右MFB

电话免提

- 接听：双击左/右MFB
- 拒接：长按2秒左/右MFB
- 挂断：双击左/右MFB

音乐模式/游戏模式/影院模式 切换：已联设备

- 长按右耳2S切换到游戏模式
- 长按右耳2S切换到影院模式
- 长按右耳2S切换到音乐模式

耳机在充电盒开盖时，单击充电盒背部按键 音乐模式/游戏模式/影院模式，可轮流切换模式

耳机蓝牙连接状态指示：●●● 蓝牙未连接状态
●●● 蓝牙已连接状态

恢复出厂设置

方式一：任意一个耳机开机后未与蓝牙设备连接状态下，连续单击耳机功能键5次清除配对信息后关机。

方式二：耳机在充电盒开盖时，长按充电盒背部按键5S，耳机恢复出厂设置。

注意

1. 充电盒开盖后，耳机自动开机，配对并连接；耳机放入充电盒，盒盖后给耳机充电，耳机关机。
2. 常清洁，寿命长，如长期不用，建议15天充电1次，延长电池寿命，耳机尾塞充电部分经常用棉签清理，能够辅助充电顺畅，避免接触不良，影响使用体验。
3. 电池电量低时充电盒盖子不要暴露在阳光下，长时间或过热的环境中，禁止拆解，撞击挤压或投入火中，若出现严重膨胀，切勿继续使用，切勿置于高温环境中，浸水后禁止使用。
4. 由于本款产品采用无线连接方式，在日常使用过程中，受到环境、手机品牌、使用行为等因素影响，可能在播放音乐过程中，会出现卡顿、轻微的语音卡顿属于正常现象。

警告

1. 长时间以高音量使用耳机可能会损害您的听力，建议只使用适当音量收听、通话和听音乐。
2. 请勿在水中洗或将产品浸入水中，以免造成故障。
3. 不要自行拆卸产品及其配件，以免造成损坏及保修失效。
4. 请勿使产品受到强烈冲击或震动以免损坏。
5. 请勿使用化学清洁剂或清洗剂清洗产品。

Name of the Parts 部件名称	Hazardous Substances 有害物质					
	Pb 铅	Hg 汞	Cd 镉	Cr(VI) 六价铬	PBB 多溴联苯	PBDE 多溴二苯醚
Housing 外壳	○	○	○	○	○	○
Loudspeakers 喇叭单元	○	○	○	○	○	○
PCBA 电路板组件	X	○	○	○	○	○
Accessories 电源线、连接线	X	○	○	○	○	○

This table is compiled according to SJ/T 11364.
本表格依据SJ/T 11364的规定编制。

○: Indicates that the hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
○: 表示该有害物质在该部件所有均质材料中的含量均符合 GB/T 26572 标准规定的限量要求以下。

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.
X: 表示该有害物质至少在该部件的某一均质材料中含量超过 GB/T 26572 标准规定的限量要求。

FCC 声明

根据FCC规则第15部分，本设备经过测试，符合B类数字设备的限制，这些限制旨在提供合理的住宅设施中的有害干扰防护。该设备产生使用并可辐射射频能量。如果未按照规定安装和使用该设备可能会对无线电通信造成有害干扰。然而，有不能保证在特定安装中不会发生干扰。如果这个设备对无线电或电视接收造成有害干扰，可通过转动来确定设备关闭和打开时，鼓励用户尝试通过一个或多个以下更多措施：

- 重新定向或重新定位接收天线。
- 增加设备和接收器之间的距离。
- 将设备连接到与接收器不同的电路上的插座已连接。
- 请咨询经销商或经验丰富的无线电/电视技术人员以获得帮助。

此设备符合FCC规则的第15部分，操作要以下两个条件限制条件：

- (1) 本装置不得引起有害干扰。
- (2) 本装置必须接受任何接收到的干扰，包括可能导致意外操作的干扰，未经合规责任方明确批准的变更或多次可能使用用户对设备的操作权限失效。

FCC ID: 2ABPV-QSMXXKT20

Environment Friendly Use Period (EFUP)
环保使用年限

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.
这标志所指的期限（10年）是电子电气产品中有毒物质在正常使用的条件下不会发生外泄或突变，电子电气产品用户使用该电子电气产品不会对环境造成严重污染或对其人身、财产造成严重损害的限制。

保修卡

尊敬的客户，本保修卡是您将来申请保修的凭证，请您配合销售商填写并妥善保管备用！

用户信息

用户姓名	电子邮箱
联系电话	邮政编码

通讯地址

产品信息

产品名称	产品型号
产品条码/编号/批号	


销售商信息

名称	
地址	
联系电话	邮政编码
销售日期	发票号码
备注	

合格证

产品编号
生产日期
销售商

合格证



Monster Airmars XKT20

True Wireless Bluetooth headphone
instruction manual


Product parameters

- Bluetooth version ----- V5.3
- Transmission distance ----- 10m
- Driver diameter ----- ϕ13mm
- Driver impedance ----- 32Ω±15%
- Sensitivity ----- 96±3.0dB
- Frequency response range ----- 20Hz-20KHz
- Battery capacity (charging case) ----- 300mAh 3.7V
- Battery capacity (Headphone) ----- 30mAh 3.7V
- Charging time (charging case) ----- ≈1.5 hours
- Music playtime (headphone) ----- ≈4 hours
- Music playtime with charging case ----- ≈18 hours


Packing list

	Headphone *2		Charging Case *1
	Type-C Charging Cable *1		Instructions Manual *1

Product Schematic Description




Multi-Function buttons (MFB)
Pilot Lamp



LCD
Charging interface

Charge the charging case

Connect the charging case to the 5V power adapter with Type-C charging cable.




Rated input: 5V==30mA(Headphone) Rated input: 5V==300mA (charging case)

Indicator guide

Mode	Describe	Sound prompt
Power On	The ice blue light of the headset flashes 3 times.	"Power on"
Power Off	The orange indicator of the headset is on for 15 and off	"Power off"
Pairing	The headphone's ice blue and orange lights flash alternately	"Pairing"
Connected	Headphone light off	"Connected"
Disconnected	The headphone's ice blue and orange lights flash alternately	"Disconnected"
Low Battery	Headphone orange light flashing fast	"Battery low"
Headphones placed in charging case	The orange light of the headset keeps on	—
Charging case low power	The charging case display displays 0% in a circle until the display is off	—
Charging case charging	The percentage in the circle of the charging case display increases to 100%	—
Charging case fully charged	The charging box display screen turns off after displaying 100%	—

注意：


- * Fully charge the headphones and power off before an intended not-in-use period.
- * Unplug the charging cable after charging.



Product operating instructions

1. Power on
Method 1: Open the charging box cover and the headphones will automatically turn on.
Method 2: Press and hold the function touch button for 3 Seconds to turn on the headset.
2. Power off
Method 1: Put the earphones back in the charging case and close the charging case cover and turn off the earphones.
Method 2: After disconnected from the bluetooth device for 3 minutes.
3. Pairing
Step 1: Open the charging box cover, and the headphones will automatically turn on and pair;
Step 2: Search and click for "Monster Airmars XKT20" on the bluetooth list of the smart device, and when connection is successful, "connected" will be heard.

* Headphones will try reconnecting to the device within 3 minutes when connection is lost.



Operation

Normal

- Voice assistant: Press the left MFB for 2 seconds
- Volume +: Click right MFB
- Volume -: Click left MFB

Music playback

- Pause/Play: Double click Left/Right MFB
- Last song: Triple click left MFB
- Next song: Triple click right MFB

Phone

- Answer: Double click the left/right MFB
- Reject: Press left/right MFB for 2 seconds
- Hang up: Double click the left/right MFB

Music/Game/Video mode switching: Device connected

- Long press the right ear for 2S to switch to Game mode
- Long press the right ear for 2S to switch to Video mode
- Long press the right ear for 2S to switch to Music mode

When the headset is in the charging case, click the button on the back of the charging case to switch between Music mode/Game mode/Video mode

Headphone Bluetooth Connection status indicator:
●●● Bluetooth not connected status
●●● Bluetooth connected status

Restore Factory settings

Method 1: Any earbud disconnect with the Bluetooth Device when turn off, click the MFB 5 times to clear the previous Pairing information and turn off.

Method 2: When the lid is open, hold down the button on the back of the earphone charging case for 5S to restore the earphone to factory settings.

Precautions

1. After the charging box is opened, the headphones automatically turn on, pair, and connect; Put the headphones into the charging box, close the cover, charge the headphones, and turn them off.
2. Charging every 15 days will extend battery life when not in use often, Cleaning off dirt on the charging contacts by cotton swabs with alcohol will maintain a good Contact for charging.
3. Keep battery (battery pack) away from inflamm ables or excessive heat such as direct sunlight. Do not disassemble, impact extrusion or put into the fire. If severe Swelling occurs, do not continue to use, Do not expose to high temperatures, Do not use after soaking water
4. Intermittent is normal during play back for wireless products due to environmental factors, device brand users' behavior, etc.

Warnings

1. Do not use headphones at high volume for an extended period of time.
2. Keep the headphones away from dust and water.
3. Do not disassemble the headphones and accessories, otherwise warranty will be voided.
4. Keep headphones away from any impact or vibration.
5. Do not use any chemical solvents or cleaning agent on the headphones.

Name of the Parts	Hazardous Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing	○	○	○	○	○	○
Loudspeakers	○	○	○	○	○	○
PCBA	X	○	○	○	○	○
Accessories	X	○	○	○	○	○

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5cm between the radiator and your body.

Environment Friendly Use Period (EFUP)

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User Information

User name	Email
Contact number	Postal code
Mailing address	

Product information

Product name	Product number
Product barcode / Serial number / Batch number	

Vendor information

Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	

合格证

Product No.
Production Time

合格证