
- 尺寸: 78*30*96mm
- 材质: 300g单粉纸
- 颜色:四色印刷
- 工艺: 4C印刷+局部烫银+表面过哑膜+吸塑





说明书

尺寸: 60*90mm 材质: 书写纸

印刷工艺: 双面印刷





User's Manual

Thank you for choosing our products. The Bluetooth earphone has a fashionable design, powerful functions, and high compatibility, providing you with hands-free convenience in making calls and listening to music. It is your best choice

in office and during traveling and driving. Bluetooth Wireless Technology With the Bluetooth wireless technology, you can connect the earphone to its compatible communication devices without using cables. The Bluetooth wireless connection

wireless connection may be interfered by obstacles (such as walls) or other electronic devices. In some areas, use of the Bluetooth wireless technology may be subject to some constraints. Please consult your

local authority or service provider for details.

Troubleshooting

allows you to use a cell phone without holding it against

the earphone, but the maximum distance between them

cannot exceed 10 meters (about 30 feet). The Bluetooth

Fully charge the earphone before using. For details about how to charge the earphone, see "Charger and Battery" in this manual. Meanwhile, choose the cell phone that is compatible with the earphone or other Bluetooth devices to pair with the earphone. For details about pairing, see "Basic Operations".

Tip: Keep the earphone away from your credit card or other magnetic storage media; otherwise, the stored information

may be lost due to demagnetization. AUT201-E the right earphone (R) to skip forward a track. Earphones battery capacity: 30mAh*2

Charging case battery capacity: 300mAh

Call time: About 5H Bluetooth headset pairing and connection method Turn on the phone's Bluetooth and search for Bluetooth headset devices. After finding the Bluetooth headset, Charger and Battery

the earphone.

Playing or pausing music: When the music is being played. you can tap the left earphone (L) to pause the music, or

repeat the same operation to play the music again. Next track: When the music is being played, you can tap

Receive a call: When there is an incoming call, you can tap the earphone (L) or earphone (R) to answer the call. Reject a call: If you want to reject a call, you can long press the earphone (L) or (R) for rejection.

Voice assistant (Siri): Press on (L) or (R) 2 secondsto activate your voice assistant.

Before using any charger to charge this earphone, check whether the specifications of the charger meet requirements. The recommended output voltage of the charger is DC5V+/-0.25V, and the recommended output current is 100 mA to 500 mA. An over-high charging voltage may damage Warning: Use the recommended charger whenever possible. Use of other types of chargers may violate the warranty terms of the equipment and results in danger. If the charging cable is delivered with the earphone, connect the cable to a CCC-certified charger or computer to charge the earphone.

Charging the Battery The earphone uses embedded charging battery that cannot be removed. Do not attempt to remove the battery from the earphone or the charging box; otherwise, the earphone may be damaged. If the earphone is not used in a long time, keep it in a cool and well-ventilated place,

and charge the earphone once every two months. This device complies with part 15 of the FCC Rules.

must accept any interference received, including interference Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's This equipment has been tested and found to comply with

device may not cause harmful interference, and (2)this device

the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and

can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference

to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna.

condition without restriction.

Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician

requirement. The device can be used in portable exposure

can't charge, can't boot	charger. Pick up the earphone and put it back in the charging box after adjusting the angle. After plugging in the power supply, check whether the earphone has an indicator light
Headphones are noiseless and sound quality deteriorates	Listen to the voice prompt when you turn it on, reconnect your phone, and change the sound source for listening. If the Bluetooth headset is connected to the computer, due to the complexity of the computer system and hardware and imperfect driving, it may be necessary to manually select the audic device protocol or use other devices to connect and play.
Unable to switch	Use the default player or trying another

After-Sales Service Our company provides the "Repair, Replacement and Retur warranties (3R Warranty) service to all its products strictly

click Pair to complete the connection.

according to laws and regulations, and the warranty perio We do not directly provide the return and replacement service If you find any quality problem when using our products

please contact your local distributors as soon as possible for timely replacement. The after-sales service is not provide for the following cases: 1. The Fragile label is altered or torn up.

The product is damaged due to contact with liquid or water.
 The cover or other components of the product are seriously

4. The product is damaged due to improper operations

. The product is damaged due to an accident or negligence

6. The product is damaged due to commercial use of the product in abnormal conditions. 7. Any other situations similar to the preceding ones.

1. To extend the service life of the battery, you are advised to charge the earphone at least once a month. the earphone. Use of other low-quality chargers may bring about dangers.

3. Adjust the volume to an appropriate degree when using 4. DO NOT wear the earphone when sleeping; otherwise, the earphone may be damaged or cause injuries to you. 5. When driving, you are advised to use the company

Bluetooth earphone to ensure your driving safety. It is dangerous to directly use cell phones when driving. 6. Keep the earphone away from kids. Small components of the earphone may cause suffocation or other injuries

FC 😂 🗷 🔟



尺寸: 42x42x42mm 材质: 200G双铜纸