

Wireless Mouse

TTY-27

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Warranty Card Notes

Dear customer:

Thank you for purchasing our products! In order to make our service more satisfactory to you, please read this card carefully and keep it properly after purchase, this warranty card is the proof of warranty.

1. From the date of your purchase, our company will be responsible for any non-human Factors of hardware failure light quality problems to implement the "seven days to return, a month to replace, a year warranty" service policy (part of the online sales of goods warranty rechargeable version of the mouse instructions: time to web page shall prevail). Returned products to ensure that the goods themselves are not scratched and the integrity of the packaging.

Please fill in the following information carefully and keep it properly

Product name: _____ Model number: _____

Store: _____ Date of purchase: _____

Purchase Account Number: _____ Contact Number: _____

Common problems

1. If the mouse switch red light open only flash twice on off, because there is no recognition to the receiver, not no power caused by, please check whether the mouse receiver has been inserted into the computer, whether the computer has been turned on
2. The button below the scroll wheel is to adjust the mouse movement speed, fast in slow three gears, press a gear, so cycle

Wireless mouse instructions for use

Charging board mouse instructions for use.

1. first the bottom of the mouse receiver out, insert the computer USB port, plugged in and wait about 15 seconds to open the switch, you can use.
2. charging method, charging please open the mouse switch, use the micro connector charging cable for charging, can be directly linked to the computer charging, charging the mouse wheel next to the bright blue light, full not light, use up the general charge of about 3 hours, use is not sensitive both no power.

Battery version of the mouse use instructions:

First the back of the battery slot open, take out the receiver inside, insert the computer USB port and wait about 15 seconds to load the battery can be used, the battery can be replaced after the power is used up, if you do not use for a long time, please take out the battery (Note: the battery version can not be charged)