

The Wireless Mouse Use Manual

Thank you for purchasing our products. Please read the product instructions carefully before using the product. If you would like to learn more about the product, please contact us.

How to use a wireless mouse:

Wireless rechargeable mouse (Single-mode version)

1. Charge the mouse for about 2 hours before the first use. During the charging, the blue light is always on and the light is off.
2. Remove the receiver, insert it into the USB port of the computer, open the mouse switch at the bottom near the receiver, wait for a few seconds, and the bottom light flashes, which means that the connection is successful. (In case of problems, replug the receiver and reswitch the mouse until the connection is successful)

pay attention to:

1. The mouse is not used for a long time will automatically enter the dormant state, can move the mouse or press any button to wake up;
2. When the mouse moves slowly, please check whether the battery is insufficient, and it is recommended to charge in time;
3. When the mouse is not connected, please check whether the power switch at the bottom of the mouse is on, or will Move the receiver to other USB interfaces for use;
4. If you do not use the mouse for a long time, please manually turn off the power switch to save power;
5. Do not remove the mouse by yourself, and avoid water;
6. Children use this product under the supervision of adults.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirements, the device can be used in portable exposure condition without restriction