



5 Battery Replacement and Installation Instructions


1.Take out the bluetooth controller.




2.Unscrew the screws with a screwdriver.




3.Remove the old battery.




4.When installing a new battery, pay attention to the direction of the battery, with the flat surface facing up (Reference picture identification)



5.After the battery is replaced, close the bottom cover. Check that the bottom cover is flush with the silicone seal, and then lock the screws to complete the installation.




6.①After the installation,long press the power button for 3 seconds, the indicator light is blinking. Then it is in the power-on state.
②Test whether other buttons have a rebound function. If have, then it can be used.




On land

1. It can be taken out on land and used as a camera remote controller to take pictures.
2. The product adopts 2.4G Bluetooth transmission technology, and the straight-line transmission distance without obstacles can up to 10 meters.



Underwater

When using underwater, due to the spatial isolation of water, the bluetooth controller cannot be separated from the main body of the case. Or it will cause bluetooth disconnection and can not work normally.



5 Waterproof test

- (1) Prepare several pieces of napkin
- (2) Place the napkin into the case
- (3) Close the case, make sure it is completely locked
- (4) Immerse the case in the water for 60 minutes, make the depth is no more than 15 meters
- (5) Take out the case, wipe the surface with fibre cloth
- (6) Open the case and take out the napkin
- (7) Carefully check the napkin, only if the napkin is dry could the case be used, otherwise stop using and ask the customer service for a new one.

6 Reminder

When using the mobile phone system Android 11 (mobile phone listed in 2021) to take a picture, it will crash and the camera function cannot work. The system below Android 11 can be used normally (Android phones listed in 2020 and before 2020). The Android 10 system cannot be upgraded to Android 11, and you don't have to worry about not being able to take pictures after the system upgrade. The Apple IOS system can be used normally.

7 Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
→ Reorient or relocate the receiving antenna.
→ Increase the separation between the equipment and receiver.

→ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
→ Consult the dealer or an experienced radio/TV technician for help.


The device has been evaluated to meet general RF exposure requirement. The device can be u sed in portable exposure condition without restriction

QUICK START GUIDE

Before using your case, read all instructions on this manual. Complete the WATER TEST before using this case with your phone.



1 Product appearance



1	Bluetooth camera controller	2	Screw
3	Non-slip handle	4	Lanyard hole
5	Bracket mounting hole	6	Camera window

- Maximum diving depth with this case is 15 meters.
- Keep the "BT Shutter" APP is opening before diving

2 Attention

Please read the below instructions carefully before using this case.

Operation and maintenance

- Strictly follow the installation & disassembly instructions every time when using.

- The phone should be connected with bluetooth controller before diving. And ensure that the phone is in the long-bright state of taking pictures
- Make sure the case is well-locked and the sealing joint gap is averagely lined up before diving.
- Stop using this case if the sealing ring is damaged or deformed.
- Maximum diving depth is 15meters,over 15 meters is not guaranteed.
- Test the camera shutter button after every-time installation,make sure it is able to rebound after pressing.
- If the camera window is fogged up,keep the desiccant inside the case at least for 10 minutes before putting the case into the water.
- After every-time using,immerse the completely locked case in fresh water for 20 minutes,then wipe the case with soft fibre cloth and keep in a dry place.
- Do not expose the case under the high temperature environment or beside heating equipments,e.g.hot sunshine,oven,or water heater.

Conduct waterproof test before diving.

Do not use the case in sulfur-bearing hot spring.

Do not take the case apart or outfit,privately,otherwise the waterproof function may be descended.

it is not suggested you rent or lend this case to others in case of any disputes.

Keep away from Children.

- Accessories include some small parts,keep away from the reach of children as they may damage thoes parts and to avoid other potential risks like scratch, or unconscious swallow.
- This product is not a toy, adults must have custody of the children.

Accessories

- Only the self-contained or manufacturer approved accessories could be used, other accessories may violate the local rules and possible safety issue may occur. Please contact customer service if you need approved accessories.

Environment protection

- Do not dump this product and its accessories as daily trash.
- Please follow your local rules to handle and recycle.

3 Compatible Phone Model

- New upgrade design and compatible with most phone models, such as iPhone, Huawei, Samsung, Xiaomi, Vivo, Oppo, OnePlus, Google etc, no bigger than 6.9 inches.


4 Installation instructions

Installation premise

- Please do waterproof test to this case before installing your phone.
- Tear off any protective tempered glass or film from the phone screen and wipe the phone screen with fibre cloth,make sure the screen is clean before installing the phone into the case.
- 1.Scan the QR code to download "ShellBoxCamera"with browser or camera before using.
2.For iPhone: You can also search "ShellBoxCamera" directly in APP Store to download.



Bluetooth controller(Shell box-BT) operating instructions




1. Long press for 3 seconds, release after the indicator light flashes, the controller is turned on. And the controller will automatically search for the last linked device, if the last device can not be searched, (Shell box-BT) will automatically enters the searchable state.

2. Long press for 6 seconds, release after the indicator light flashes,the controller is turned on. And the Bluetooth controller enters the searched state.


When the bluetooth disconnect and how to reconnect.

- When the phone is actively disconnected, the phone needs to actively search for the Bluetooth controller, and click to link again.
- The Bluetooth controller is actively disconnected, and the Bluetooth controller needs to be restarted (Long press the power button for 3 seconds, the indicator light will light on and release the button), the Bluetooth controller (Shell box-BT) will automatically connect to the last linked mobile phone.
- Replace the device to connection: In the off state (Long press the power button for 6 seconds, the indicator light flashes and release). Use the phone to find the Bluetooth controller (Shell box-BT) to connect.


2.Twist the screw and open the side Airtight cap




3.Use handle strap to pull out the inner plate




4.Put the phone into inner plate and use the suction cup to suck the back of the phone to prevent the phone from loosening. The position of the mobile phone camera must be aligned with the camera window.



5.Put the inner plate combined with the mobile phone into the diving case.Make sure the handle strap is appressed with the inner plate and not beyond the edge of diving case.



6.Close the side Airtight cap and tighten the screw, now installation finished.



尺寸：130*72mm

材质：157g铜版纸