


■ black ■ Pantone 2995C/C/P
SIZE: 420 x 297 mm
材质: 80G 书写纸 彩色印刷
折法: 风琴3+风琴3
成品尺寸: 105 x 74.25 mm



Front

Connected by
PURE SMART™ | **wiz PRO**

Pure Smart Remote Room Controller
Wi-Fi Enabled - Connected by Wiz Pro - Battery Powered

Totally Wireless Single Pole or 3-Way Installation
Model #: Wiz34,CWR-TW-SCENE-WH

Included in Box:

- Two Sided Adhesive Pads x2
- Neoprene Pads x2
- Drywall Anchors x2
- #6 Screws x2
- 6-32 Screws x2

Room Controller x1

Specifications:

- Power: 3VDC Battery Powered, 60Hz
- 4 AAA Batteries (not included)
- Wireless Frequency: 2.4GHz
- Wireless Standard: IEEE802.11b/g/n
- No load maximum
- Temperature Range: 32° F-104° F
- Range: up to 50 ft radius from router or Wi-Fi Access point
- Rated for Indoor use only
- For control of Wiz smart loads only

Contents

- Section 1. Overview**
 - Device Button Schematic
 - Notes Before Installation
- Section 2. Installation**
 - Device Components
 - Methods for Mounting
- Section 3. App Pairing**
 - Download the app
 - How to Commission the Controller

For more details, please refer to the manual.
If you have any questions during installation, please contact us techsupport@pureedgelighting.com

Section 1. Overview

Controls Overview

Battery Placement

Section 2. Mounting the Device

Junction Box Installation

Note: Please consult a qualified electrician prior to removal of existing 120V wall control.

- Turn off power to the circuit at the circuit breaker prior to removing the existing switch.
- Remove the existing wall control and disconnect all of the wires.
- Wire nut or cap off all of the conductors in the junction box.
- Using the screws marked 6-32 install the back plate of the Remote Room Controller into the junction box.
- Insert the 4 AAA batteries into the Remote Room Controller. Reference the diagram in section 1 for correct battery installation.
- Snap in the front cover plate.

Follow the directions in Section 3 for pairing the Remote Room Controller with the Wiz App.

For 3-way applications follow the additional directions listed below assign the same targets to your Remote Room Controller and whatever device is acting as the second control in the 3-way.

Drywall Installation

Tools Needed: Phillips Screwdriver

- Mark the placement of the anchors on the wall where the Remote Room Controller will be installed by placing the backplate of the room controller in its desired position, using a level to confirm proper alignment, and then with the included screws placed into the holes on the back plate, tap them with a hammer, thereby marking the positioning for the anchor installation.
- Tap the supplied anchor onto the marked points up to the threaded portion with a hammer.
- Screw in the threaded portion of the anchors with a Phillips screwdriver making sure that the top of the anchor is flush to the wall.
- Line the back plate of the Remote Room Controller up with the anchors and screw the supplied #6 screws into the pre-installed anchors.
- Install the 4 AAA batteries correctly per the diagram in section 1. Then snap on the front cover plate.
- Follow the directions in Section 3 for pairing the Remote Room Controller with the Wiz App.

For 3-way applications follow the additional directions listed below to assign the same targets to your Remote Room Controller and whatever device is acting as the second control in the 3-way.

Surface Installation

Tools Needed: A Level

- Clean and dry the surface that the Remote Room Controller will be adhered onto.
- If the installation will be permanent you will utilize the two-sided adhesive pads. For tabletop installations or installations where the device will need to be moved around use the neoprene pads that are included.
- If using the two-sided adhesive pad, you'll now remove the paper backing on the exposed side, press, and hold the backplate against the surface, creating a strong bond. We recommend using a level if installing on the wall to ensure proper alignment.
- Install the 4 AAA batteries.
- Snap on the front cover plate.
- Follow the directions in Section 3 for pairing the Remote Room Controller with the Wiz App.

For 3-way applications follow the additional directions listed below to assign the same targets to your Remote Room Controller and whatever device is acting as the second control in the 3-way.

Section 3. App Pairing

Download Wiz Connected:

1. Please scan the QR code to download the application "Wiz Connected".
2. You may also find the Wiz app in the Apple App Store or the Google Play Store under "Wiz Connected".
3. After you download the Wiz Connected App and register a new account, please follow the instructions below to set up your smart switch.

For Wiz Pro Dashboard Users: Wiz Pro Dashboard account and home must be created before starting commissioning in the Wiz app. Please create an account on Wiz Pro Dashboard. Then create your home or location. After doing so, you may proceed to create an invitation in the dashboard by going to "settings" and then the "members" tab. By clicking on the "invite" button you will be able to generate an invitation to access this dashboard location in the Wiz app. From there you can proceed with commissioning in the Wiz app but also have the added functionality of the Dashboard desktop application.

PLEASE READ BEFORE PAIRING ROOM CONTROLLER IN WIZ APP:

In the Wiz app, any Pure Smart / Wiz fixture(s) must be added to a room prior to adding the Room Controller that will control them. Please refer to the installation manual included with the Pure Smart / Wiz light fixtures for setup.

Smart Pairing

- Once your lamps or fixtures have been connected, press the plus sign in the top right hand corner to add your smart room controller.
- Select "Wall Controller" from the available device types.
- Select whichever room the Wall Controller will be installed in or controlling.
- Follow the on-screen instructions and ensure that your Wall Controller is connected to 120V power and then press "START".
- Follow the on-screen instructions by pressing the ON button 3 times and wait while the Wiz app looks for your Wall Controller.
- When you receive the "Accessory Found" message you may press done and begin controlling the light fixtures in that room with your Wall Controller. Follow additional instructions below to personalize settings and targets.

Additional Settings for Wall Controller Accessory

- For additional setup, select "Settings" on the bottom right corner of the Home screen.
- Select "Accessories" from the Settings menu.
- Select the Wall Controller that you'd like to customize control with.
- If needed, you have the option to rename your Wall Controller.
- You can select individual targets that the Wall Controller will control by choosing specific fixtures or devices.
- Or you can choose an entire room for the Wall Controller to control.

WiZ Pro Software Suite

WiZ Pro Dashboard

- Grant access permission to different stakeholders
- A clear overview to monitor lights with their mapped location
- Full range of configurations and remote control
- Comprehensive reporting on device status

WiZ Pro Setup

- An interface dedicated to Installers
- Extends capabilities of installation of Wiz Pro products

WiZ app

- For end users to have simple, quick control on a daily basis
- Rich features including Scenes and Rhythms

pro.wizconnected.com

Download on the [App Store](#) [GET ON Google Play](#)