


Up to 1GHz  
The EUT is placed in the center of the turn table



Above 1GHz  
The EUT is placed in the center of the turn table