

SPECIFICATIONS

Product line: 128D30355HMM
Material: ABS + Silicone
Normal colors: BLACK, WHITE
Patent No.: 20193092722.4
Accessories: user manual, Adaptor DC 9V/3A

2) Speaker

Bluetooth: V5.0
Power supply: 5V 500mA
Speaker: 40MM 42 3W
Frequency response: 20Hz-20KHz
Working range: Up to 10M

Power supply: 5V 500mA
Frequency response: 20Hz-20KHz
Working range: Up to 30M

95
12PCS
5V 950MA
4000K
100UM

- Battery supply power directly
- 9V/3A Adaptor power supply

Diagram illustrating the components of the Smart Desk Lamp:

- Bluetooth Speaker
- LED Light Panel
- Flexible Gooseneck
- Wireless charging Panel
- Type C charging slot
- Control buttons area

This diagram shows the base of the desk lamp. It features a circular base with a charging panel and a Type C slot. Labels with leader lines point to the following components:

- Charging Panel
- Type C charging slot
- Buttons area

Type C charging slot

10

Diagram illustrating the back of the wireless charger with five control buttons labeled 1 through 5:

- 1: **Headlamp Lamp Control Button**, Long Press 2 seconds for Power on or Off, press once for Brightness Adjustment
- 2: **Wireless Charger Control Button**, short press the button to activate Wireless Charger, it will auto working and turn off automatically if it does not identify the mobile wireless charger input.
- 3: **Workshop "ON/OFF" BUTTON**, Long Press 3 seconds for Power on or short press this button for "Play/Pause"
- 4: **Track or Volume Button**, When short press this button: Previous track, long press: Volume down
- 5: **Track or Volume button**, When short press this button: Next track, long Press: Volume up

- **Off**, press once for Brightness Adjustment
- **Wireless Charge Control Button**, short press this button to activate Wireless Charger, it will stop working and turn off automatically if it does not identify the mobile wireless charger input;
- **Bluetooth "ON/OFF" BUTTON**, Long Press 3 seconds for Power on or short press this button for "Play/Pause"
- **Track or Volume button**, When short press this button: Previous track long press: Volume down.
- **Track or Volume button**, When short press this button: Next track long Press : Volume up.

 * Track or Volume button. When short press this button: Previous track
long press: Volume down

 * Track or Volume button, When short press this button: Next track; long Press : Volume-up.

1

2

1) There are four options of brightness of led lamp

- Short press the touch control button to turn on the Reading Lamp, then reach to the brightness immediately.
- Short press once to switch to the second grade brightness;
- Short press once again to switch to the third grade brightness;
- Short press three times to switch to the forth grade brightness;

2) LED color temperature is 4000K, it is a perfect to protect your eyes;

3) Professional brightness design for book reading;

4) Single mode can focus well light source on the page and adjust

• Short press once to switch to the second grade brightness;
• Short press once again to switch to the third grade brightness;
• Short press three times to switch to the forth grade brightness;

• color temperature is 4000K, it is perfect to protect your eyes;
• essential brightness design for book Reading;
• thin above rock design and 360 degree rotating and adjustment

- 1
- 2

1 Once turn on the wireless charger, and put the smart phone to the top of wireless charging panel, insert the right type of wireless charging of the phone start charging automatically. The white led indicator will start slow flash once it working.

2 Normally it is fast charging if there is no external power input;

3 Support 120W fast charging, it will smartly switch to 120W Fast charging from once you use the adapter inputting the power(75W/14).

Make sure your phone with wireless charging function such as iPhone 8 or above version, your phone is without wireless charging function, please insert a wired charging cable to your phone, then start wireless charging.

When charging, the white LED indicator will start to glow slowly. When the charging is complete, the white LED indicator will stop glowing.

1. Press the **SPEAKER** button on the back of the device.

2. The screen displays a Bluetooth symbol and the name **L3**.

1) **Pairing**

Start pairing automatically once you press **SPEAKER** (on control button). Follow the operating instruction of your Bluetooth device phone, etc. and allow it to search Bluetooth state, after a few seconds your mobile will discover the Bluetooth speaker under "L3". Select this and your device will confirm this pairing. You can start playing music through the speaker. Enter password or PIN 0000 on your Bluetooth device (if necessary), and press "Yes" or "Confirm".

Pairing automatically once you long press 35 of Speaker on/off control icon, follow the operating instruction of your Bluetooth device/phone, and allow it to search Bluetooth state, after a few seconds your mobile will connect to the Bluetooth speaker under "LB". Select this and your device will begin to pairing. You can start play music through the speaker.

Please enter the PIN code 0000 (or 1234) as the Bluetooth pairing password or PIN 0000 on our Bluetooth device (if necessary), and press "OK" or "Confirm".

SAFETY INFORMATION

Expand The Speaker, Battery To Liquid, Wireless, Harmony Of R&B. Do
A Near A Bathing,

Purchase From An Authorized Distributor. Warranty Claims Will Only Be Valid With Proof Of Purchase. If Defect Exists, We Will Repair Or Replace Your Product. We Do Not Cover Normal Wear And Tear, Blown Spark Plug Cords, Scratches, Loss Of Theft. The Warranty Excludes Damages Resulting From Abuse, Accident, Modifications Or Other Causes That Are Not Defect In Materials And Workmanship. Customization Or Modification Will Void Your Warranty. This Warranty Gives You Specific Legal Rights, And You May Have Other Rights That Vary By State And Jurisdiction. These Rights Shall Not Be Affected By This Limited Warranty. This Warranty Cannot Be Transferred Or Assigned. Your Warranty Will Be Void If A Hot Rod 411 (X) Is Not From The Date Of Original Purchase From Authorized Distributor.

MADE IN CHINA

Purchase From An Authorized Distributor. Warranty Claims Will Only Be Valid With Proof Of Purchase. If Defect Exists, We Will Repair Or Replace Your Product. We Do Not Cover Normal Wear And Tear, Blown Spark Plug Cords, Scratches, Loss Of Theft. The Warranty Excludes Damages Resulting From Abuse, Accident, Modifications Or Other Causes That Are Not Defect In Materials And Workmanship. Customization Or Modification Will Void Your Warranty. This Warranty Gives You Specific Legal Rights, And You May Have Other Rights That Vary By State And Jurisdiction. These Rights Shall Not Be Affected By This Limited Warranty. This Warranty Cannot Be Transferred Or Assigned. Your Warranty Will Be Void If A Hot Rod 411 (X) Is Not From The Date Of Original Purchase From Authorized Distributor.

    

MADE IN CHINA

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.