

SIZE:90X112MM

<p>ENJOY MUSIC</p> <p>FAST CHARGE</p> <p>LIGHTING UP</p>	<p>SPECIFICATIONS</p> <p>Product size: 90x112x100MM</p> <p>Material: ABS+PC</p> <p>Normal color: BLACK WHITE</p> <p>Power No.: 20180502217.1</p> <p>Accessories: user manual, Adapter(DC 9V/3A)</p> <p>• Speaker</p> <p>Bluetooth: V5.0</p> <p>Power supply: 5V/500MA</p> <p>Speaker: 60MM 40 ZW</p> <p>Frequency response: 20K-20K Hz</p> <p>Working range: 100m</p> <p>• Desk LED Lamp</p> <p>Flu: 95</p> <p>LED chip: SMD</p> <p>Power Band: 0V/500MA</p> <p>Color Temperature: 4000K</p> <p>LED brightness: 75LM</p> <p>• Wireless Charger</p> <p>Battery supply power: directly</p> <p>5W</p> <p>10W: 9V/3A Adapter power supply</p>	<p>PRODUCT INTRODUCTION</p>	<p>BUTTON OPERATION</p> <ol style="list-style-type: none"> 1. Reading Lamp Control Button, Long Press 2 Seconds for Power on or OFF, press once for brightness adjustment. 2. Wireless Charger Control Button, Short Press this button to activate Wireless Charge, it will stop working and turn off automatically in 5 Seconds. It does not identify the wireless charger type. 3. Bluetooth "ON/OFF" button, Long Press 3 second for Power on or OFF, Short Press this button for "Play/Pause". 4. Track or Volume Button, When short press this button, Previous track, Long Press "Volume down". 5. Track or Volume Button, When short press this button, Next track, Long Press "Volume up". 	<p>DESK LED READING LAMP</p> <ol style="list-style-type: none"> 1. There are four brightness option of LED Lamp. 2. Long press the three control buttons to turn on the Reading Lamp, then press the five brightness buttons, then press the five brightness buttons respectively. 3. Short press once to switch to the next grade brightness. Short press three times to switch to the fifth grade brightness. Short press three times to switch to the first grade brightness. 4. Long press three times to switch to the next grade brightness. 5. Professional brightness design for Book Reading. 	<p>WIRELESS CHARGER</p> <ol style="list-style-type: none"> 1. Close lock on the wireless charger, and Put the smart phone on the top of Wireless charging panel, Press the right area of wireless charging of the phone, then start charging automatically, the white led indicator will flash slow flash green to working. 2. Charge 1.5W (charging against battery power supply). 3. Charge 1.20W for charging against power supply(9V). <p>Make sure your phone with wireless charging function such as iPhone 8 or 8plus version, if your phone is not that version, charging function, please insert a wireless charging adapter to your phone, then start wireless charging.</p>	<p>BLUETOOTH SPEAKER</p> <ol style="list-style-type: none"> 1. Pairing 2. Play 3. Track or Volume Control <p>When short press: ▶ button Previous track, long press Volume down</p> <p>When short press: ▶ button Next track, long Press Volume up</p> <p>When short press: ▶ button Play/Pause</p> <p>When short press: ▶ button Previous track, long press Volume down</p> <p>When short press: ▶ button Next track, long Press Volume up</p> <p>When short press: ▶ button Play/Pause</p>	<p>SAFETY INFORMATION</p> <p>Please Read These Safety Warnings And Caution Carefully To Ensure Your Personal Safety And Prevent Property Damage.</p> <p>Do Not Expose The Speaker Battery To Liquid, Moisture, Heat, Or Fire. Do Not Use Near A Fan/Fan.</p>	<p>Do Not Use The Speaker Near Open Flame, Candles, Lighters, Matches, Meltable Materials, Or Flammable Liquids. Do Not Expose The Battery To Extreme High Or Low Temperatures. Do Not Expose The Speaker Battery To Areas Of Excessively High Or Low Humidity.</p> <p>Do Not Leave The Speaker Battery Unattended For Extended Periods Of Time. Do Not Leave The Speaker Battery Near Open Flame Such As Candles, Lighters, Cigarettes, Or Heaters.</p> <p>Do Not Expose The Speaker Battery In A Fire. The Battery Could Explode Causing Injury Or Death.</p> <p>Only Charge The Battery In Accordance With The User Instructions. Do Not Attempt To Disassemble The Speaker, Remove Or Force Open The Speaker Battery Because This May Result In Electric Shock.</p> <p>Warranty</p> <p>Purchase from an Authorized Distributor. Warranty Claims Will Only be Valid with Proof Of Purchase. If Proof Lacks, We Will Inspect Or Repair Your Products. We Do Not Cover Normal Wear And Tear, Abuse, Accidents, Fire, Theft, Loss, Or Damage Caused by Third Parties. This Warranty Does Not Cover Products Purchased from Unauthorized Resellers, Dealers, or Distributors.</p> <p>Modifications Or Other Causes That Are Not Caused by Material And Workmanship, Consumption, Or Abuse/Abuse Will Void Any Warranty. We Recommend Users Take Safety Precautions And Read The User Manual Carefully. These Rights Shall Not be Affected by This Limited Warranty. This Warranty Cannot be Transferred Or Assigned. See Warranty in User Manual for Details Of This User From The Date Of Original Purchase From Authorized Distributor.</p> <p>© CE EUC</p> <p>MADE IN CHINA</p>
---	---	------------------------------------	--	--	--	---	---	--

7## † o
#

u
" h 7## k u
u

= @

- - k
- - @
- - #

- - # ut

u \ two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

k7- ° 20
-