

正面	85mm	65mm	ALLSOR FAR006M Bluetooth MicroPhone Quick Start Guide http://www.allsor.com	Light Notices (Blue/Red LED) Bluetooth MicroPhone has two leds , Blue&Red to indicate the different operation , status in order to remind the use to pay more attention to the operation state , Blue and Red LED will light on or flash when: Power-on Long press 6 seconds boot , red and blue LED light is 1 seconds flashing three times at the same time, after enter into the state of pairing, flashing red and blue leds, after the success of the bluetooth pairing, blue LED will blink every 6 seconds at a time. When the microphone in the matching state key, click open microphone to exit the matching condition, click again on the open key, the microphone back into the matching condition Power-off Long press for 3 seconds, blue and red LED light flashes three times at the same time in 1 seconds, and then the power shut down. Bluetooth on/off Bluetooth LED	How to Make Bluetooth Connection ? Bluetooth® Speaker In order to make sure of successful pairing between BlueMicroPhone and Bluetooth - based speaker, the distance between two devices is recommended within Bluetooth effective operating range of 12 meters; however, the better the closer. During pairing, when the LED lights on in Red and Blue in turn , it implies that Bluetooth Microphone has been gotten into pairing mode. As soon as the LED turns to Blue color in flash ,that shows the correct pairing has been done successfully.
			Features • A Real Bluetooth Transmitter to be fully Compatible any Bluetooth-based Speaker or Stereo Systems. • A Powerful & High-compatibility Audio Bluetooth Transmitter • Built-in DSP for Wider-range Noise Reduction & Echo Cancellation • Ultra-Low-Delay Audio Encoding • Streamline Compact Design • Wider Audio Frequency Response • Bluetooth 3.0 + EDR	Specification • High-sensibility Microphone: -42dBm • Switch : One for operating start and pairing • LED x2 : Operating and battery indicating • I/O Port : Mini USB for battery recharging • Operating Distance : 12meters • Longer Standby Time : 7 days • Longer Talking Time : 6 hours • Dimension : 125 X 195 X 45 (mm) • Weight : 21g	ALLSOR http://www.allsor.com 9F.,No.9,Ln. 3,Zhongzheng E. Rd., Tamsui Dist., New Taipei City 251,Taiwan
反面	85mm	65mm	ALLSOR FAR006M 藍牙麥克風 快速說明指南 http://www.allsor.com	指示燈的作用（藍色/紅色 LED） 藍牙麥克風有藍色和紅色兩個LED燈，為了提醒不同的操作方式，藍色和紅色的LED燈閃爍方式也會不同 開機 長按6秒開機，指示燈1秒內紅色和藍色LED同時閃爍三次，之後進入配對狀態，紅色和藍色LED進行交替閃爍，藍牙配對成功後，藍色LED會每6秒鐘閃爍一次。當藍牙麥克風配對成功時，單擊開關鍵，麥克風退出配對狀態，再次單擊開關鍵，麥克風重新進入配對狀態。 關機 長按3秒，藍色和紅色LED燈會在1秒內同時閃爍三次，然後電源關閉。 藍牙開關鍵 藍牙指示燈	如何進行藍牙連接 Bluetooth® Speaker 為了確保藍牙麥克風與藍牙揚聲器之間配對成功，兩個設備之間的距離最好在1.2米的工作範圍之內，當然設備靠的越近，效果越好。當藍牙麥克風進入配對狀態時，藍色和紅色LED燈會進行交替閃爍，當LED燈只進行藍色閃爍時，表明兩個設備已成功配對。
			功能 • 一個完全兼容任何基於藍牙揚聲器或音響系統的藍牙發射器 • 一個強大的高度相容的藍牙音頻發射器 • 內置DSP廣泛降噪和回波消除 • 超低延遲音樂和音頻解碼 • 精緻簡化的設計 • 更廣泛的音頻頻率響應 • 藍牙3.0+EDR	規格 • 麥克風靈敏度：-42dBm • 開關鍵：開關機及藍牙配對操作 • LED x2：電量及藍牙指示燈 • I/O 端口：迷你USB充電接口 • 操作距離：12米 • 待機時間：7天 • 使用時間：6小時 • 尺寸：125 X 195 X 45（mm） • 重量：21g	ALLSOR http://www.allsor.com 25147新北市淡水區中正東路一段 3巷9號9樓
正面	85mm	65mm	ALLSOR FAR006M 蓝牙麦克风 快速说明指南 http://www.allsor.com	指示灯的作用（蓝色/红色 LED） 蓝牙麦克风有蓝色和红色两个LED灯，为了提醒不同的操作方式，蓝色和红色的LED灯闪烁方式也会不同 开机 长按6秒开机，指示灯1秒内红色和蓝色LED同时闪烁三次，之后进入配对状态，红色和蓝色LED进行交替闪烁，蓝牙配对成功后，蓝色LED会每6秒钟闪烁一次。当蓝牙麦克风配对成功时，单击开关键，麦克风退出配对状态，再次单击开关键，麦克风重新进入配对状态。 关机 长按3秒，蓝色和红色LED灯会在1秒内同时闪烁三次，然后电源关闭。 蓝牙开关键 蓝牙指示灯	如何进行蓝牙连接 Bluetooth® Speaker 为了确保蓝牙麦克风与蓝牙扬声器之间配对成功，两个设备之间的距离最好在1.2米的工作范围之内，当然设备靠的越近，效果越好。当蓝牙麦克风进入配对状态时，蓝色和红色LED灯会进行交替闪烁，当LED灯只进行蓝色闪烁时，表明两个设备已成功配对。
			功能 • 一个完全兼容任何基于蓝牙扬声器或音响系统的蓝牙发射器 • 一个强大的高度相容的蓝牙音频发射器 • 内置DSP广泛降噪和回波消除 • 超低延迟音乐和音频解码 • 精致简化的设计 • 更广泛的音频频率响应 • 蓝牙3.0+EDR	规格 • 麦克风灵敏度：-42dBm • 开关键：开关机及蓝牙配对操作 • LEDx2：电量及蓝牙指示灯 • I/O端口：迷你USB充电接口 • 操作距离：12米 • 待机时间：7天 • 使用时间：6小时 • 尺寸：125 X 195 X 45（mm） • 重量：21g	ALLSOR http://www.allsor.com 25147新北市淡水区中正东路一段 3巷9号9楼

說明書尺寸：255*390(mm) 正反面四色印刷128g雙銅紙