


**CHARGING**

- (1) The new Ni-Cd battery pack included in this set needs to be charged before use.
- (2) Plug the charger to a wall outlet and join the battery's connector and the charger's connector.
- (3) Please charge for at least 8 hours for the first 2 times. Then, it's enough to charge for 5-6 hours during normal use. Do not overcharge as it will not fill the battery with more power.
- (4) Please check on a regular basis the wire, plug and other electric parts on the toy, batteries and charger. If any damage is found, please repair it before use.

**USE CAUTIONS**

When the car is in motion, do not touch the wheels by hand to avoid damages to the car.



When there's more than one car played in the same place, set the cars to different bands to avoid mutual interference.

Do not bend the antenna or point it at other people or articles to avoid hurts.

Do not play in a place with puddle, mud or sand.

Do not play by the roads or in any other dangerous places to avoid accidents.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



صنعت وفقاً للمواصفات والمعايير العلمية  
Tested according to international standards

NOT SUITABLE FOR CHILDREN UNDER 3 YEARS DUE TO SMALL PARTS  
هشدار برای کودکان زیر ۳ سال  
مناسب نیست: دارای قطعات کوچک است  
تذکره: عمر مناسب حداقل است ۳ ساله است  
قطعات کوچک  
COUNTRY OF ORIGIN: CHINA  
بلد المنشأ: الصين

⚠️ PRECAUCIONES:  
PELIGRO DE AHOGARSE. Contiene partes pequeñas, No recomendado para niños menores de 3 años.  
EN71

⚠️ **WARNING:**  
CHOKING HAZARD - small parts.  
Not for children under 3 years.

MADE IN CHINA

