

StiX 3700 Setup Guide


Contents

StiX 3700*1

HD Cable*1

Power adapter(type-c)*1

Connectors



Specifications

CPU	Quad-core ARM Cortex-A73 and Dual-core ARM Cortex-A53
GPU	Mali G52 MP6
OS	Android 9.0
RAM/ROM	2G RAM, 16G ROM
WIFI	2.4&5Ghz WiFi, IEEE 802.11 b/g/n
Ethernet	1000M LAN
Expand Memory	SD card
Power	TYPE-C INPUT 5V 2.5A
Audio Container	MP1,MP2,MP3,WMA,WAV,OGG,OGA,APE,FLAC,AAC,M4A,3GPP etc Audio formats.
Video Format	Support 4K VP9 and 4K 10bits H265/H264 video decoding, up to 60fps 1080P multi-format video decoding (WMV,MPEG-1/2/4,H264, VP8)
Picture Format	HD JPG/JPEG/BMP/GIF/PNG/TIFF
Resolution	Support 4Kx2K & Full HD 4K*2K@60 fps video output

Control

You can control the StiX 3700 with the following input devices:

1. Wired mouse.
2. 2.4Ghz USB wireless/air mouse and keyboard set.

Basic Setup

What you need:

- 1.High-Definition TV that can display 720p,1080p or 4K video.
- 2.HD cable to connect the StiX 3700 to your TV.
- 3.A wired network cable to connect with Ethernet or 802.11a/b/g/n WIFI network.

Connection:

1. Connect the StiX 3700 and TV with HD cable.
2. Connect the power supply to type-c of StiX 3700 to power on the device.
3. Turn on the TV, and select the correct input.

Language & Input Setting

The default language is English, you can set the desired system language in setting.

1. Date & Time Setting

Setting to network synchronization time, as long as the network connected, the date and time will be with the network synchronization.

2. WIFI Setting

Once turn on WiFi, the StiX 3700 will auto search available wireless router, you can choose a router and input correct password to connected network.

3. Install/Uninstall Apps

StiX 3700 supports third-party Apps. You can install or uninstall Apps freely.

Local Installation:

User can copy apps from computer to USB Flash or TF card, insert the USB Flash or TF card to your device, Find the apps in the USB Flash or TF card and then click install.

Uninstall Apps :

Click Settings-Apps, click an app you want to uninstall, the uninstall window will pop up then click uninstall. If you don't want to uninstall just exit.

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.