

Bluetooth Keyboard

User Manual

Model Name: CL-669

FCC ID:2AAL5CL-669

Wireless Keyboard

CASE FOR IPAD/MID WITH KEYBOARD



Manual

Wireless Keyboard

CASE FOR IPAD/MID WITH KEYBOARD



Manual

Bluetooth keyboard
Caution: to use this product properly, please read the user's guide before installation.
Welcome
Congratulations on selecting the Ultra-Flat Bluetooth Keyboard, it's super slim size with 84 keys. Advanced patent on less noise and adopt latex spring circle and scissor structure, This creative and easy-to-use Bluetooth
Keyboard will bring you the novel feeling of wireless transmitting.

System Requirement
1. IBM or PC Compatible/Mac PC enable with Bluetooth wireless technology.
2. Windows system with Bluetooth software installed(Windows XP SP2 or above, Windows vista, Toshiba stack, widcomm BTW, or IVT Bluecoil)l
3. Mac OS 10.2.8 or above with Bluetooth software installed.
Installation Guide
4. Android 4.0 or above

Step 1. Charging the battery
When to charge
1. First-Time Use Please charge at least 6 hours for the first time usage and charge at least 2 hours when battery runs low
2. Red LED Blinking When the red LED starts blinking, it means the battery is nearly empty

How to charge
Plug the USB cable into your keyboard and computer by USB port respectively and it starts charging. Keyboard can work uninterruptedly during charging.
Step 2. Pairing your Bluetooth Keyboard with your computer
Before pairing your Bluetooth Keyboard with your computer, you should read through the instructions that came with your Bluetooth hardware and software for detail how to pair a device to your

specific Bluetooth Configuration. Follow below steps to pair your Bluetooth Keyboard under Widcomm BTW, Microsoft Bluetooth driver and IVT Bluecoil before you can install your Bluetooth Keyboard, please make sure you have done the Bluetooth dongle installation procedure.

-Press the "connect" button on the bottom of the keyboard for 1-3 seconds. The keyboard will be switched to the standby mode for pairing, the red light LED will flash...
Bluetooth Keyboard
Product Specifications
1. Bluetooth Specification: Version 3.0
2. Range of Frequency: 2.4GHz Spectrum
3. Operating Voltage: 3.7Vdc (powered by Li-ion)
4. Operation Current: <5mA
5. Standby Current: 1.2mA
6. Sleep Current : <0.2mA
7. Transmit Range: up to 10 meters

Troubleshooting
If you are unable to connect your Bluetooth Keyboard to the computer, or the keyboard work unconventionally, please try the following:
1. Before you install your Bluetooth Keyboard, please make sure you have done the Bluetooth Dongle installation procedure, and Bluetooth facility is turned on.
2. Ensure Bluetooth Keyboard has been paired to PC completely. (The system may require pairing again after restart PC if use low battery to pair)
3. Ensure the Bluetooth Keyboard is within a 10 meters range of your PC
4. Ensure your Bluetooth devices of PC have not been charged. (You have to re-connect if changed)
5. If your PC Bluetooth facility is connected to other Bluetooth device, please kindly confirm that the speed of the Bluetooth facility is enough.
Federal Communication Commission Interference Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the Following two conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.
Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the use's authority to operate the equipment.

Dispose of batteries according to local regulations. Do not dispose as household waste

NOTE:
The product is equipped with the Bluetooth Chip BCM20730 which complies with Bluetooth V3.0. BUT for this device the functionality is limited to GFSK (1 Mbit/s) by the firmware.
End-user is not able to change the settings and enable any additional functionality by himself.