







DO NOT PRINT

CUT LINE

FOLD LINE

MANUAL MATERIAL: 80G GLOSSY COATED ART PAPER  
SIZE: 50 X 60MM

|  |  |   |   |   |
|--|--|---|---|---|
| <p><b>description</b></p>  <p>charging indicator</p> <p>working indicator</p> <p>charging port (Type-C)</p> |  <p>mic</p> <p>mfb button</p> | <p><b>product specification</b></p> <p>Bluetooth® version: V5.3<br/>Bluetooth® frequency: 2402MHz-2480MHz<br/>input: DC 5V/350mA<br/>output: 3.7V, 700mAh<br/>distortion: &lt;1%<br/>playing time: 12 hours<br/>size: dia 60*36 mm<br/>frequency range: 80hz-20Khz<br/>support TWS connection<br/>compact size with big sound<br/>FCC ID: 2AANZMSMS<br/>BT ID: D059694</p> <p><b>contents inside</b></p> <ul style="list-style-type: none"><li>• wireless magnetic speaker</li><li>• carrying pouch</li><li>• metal ring</li><li>• USB-C charging cable</li><li>• user manual</li></ul>  | <p><b>power on/off</b></p> <p><b>To power on:</b> press and hold ① for two seconds.<br/><b>To power off:</b> press and hold ① for two seconds.</p> <p><b>Bluetooth® connect</b></p> <ol style="list-style-type: none"><li>1. The working indicator will flash in blue after the speaker is powered on.</li><li>2. Turn on the Bluetooth® on your phone and search for the device; select "BRK-MSMS" to connect.</li><li>3. After connecting, the working indicator will keep lighting in blue.</li><li>4. The speaker will automatically reconnect your phone the next time it is powered on, on the condition that its Bluetooth® is still on.</li></ol> | <p><b>hands-free call</b></p> <p>Short press ① to answer an incoming call, press ① again to end it.</p> <p><b>pause/play music</b></p> <p>Short press ① to pause music while playing. Press ① again to resume play.</p> <p><b>volumen</b></p> <p>Sync the recent media volume on your phone; the default volume is 50% after each power on.</p> <p><b>TWS connection</b></p> <ol style="list-style-type: none"><li>1. After both speakers are powered on, connect one to your phone's Bluetooth® and keep the other one(s) from connecting to any other device.</li></ol> |
|--|--|---|---|---|

|  |   |   |   |  |
|--|---|---|---|--|
| <ol style="list-style-type: none"><li>2. Double press the ① button on both speakers and the working indicator will flash blue and white alternately.</li><li>3. After the pairing is successful, the left channel speaker working indicator keeps lighting in blue, and the right channel speaker working indicator lights white.</li><li>4. Each speaker will automatically reconnect in TWS mode the next time they power on.</li></ol> <p><b>clear connection</b></p> <ol style="list-style-type: none"><li>1. Triple press the ① button to clear and disconnect TWS and Bluetooth®.</li><li>2. The speaker enters the waiting pairing state, and the working indicator flashes blue.</li></ol> | <p><b>save power</b></p> <p>The speaker will power off automatically to save power if it stops working for more than 20 min.</p> <p><b>charging</b></p> <ol style="list-style-type: none"><li>1. When the speaker battery runs low, it automatically reduces the volume to warn you it has entered a power-saving state.</li><li>2. In this case, please charge the speaker immediately. While charging, the charging indicator will light orange.</li><li>3. Once charging is completed, the charging indicator becomes green.</li></ol> <p><b>Note:</b> If not used for a long time, please charge the speaker at least once every three months to extend the battery life.</p> | <p><b>FCC statement</b></p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy. If not installed and used by the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"><li>• Reorient or relocate the receiving antenna.</li><li>• Increase the separation between the equipment and receiver.</li></ul> | <ul style="list-style-type: none"><li>• Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.</li><li>• Consult the dealer or an experienced radio/TV technician for help</li></ul> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>DGL Group, Ltd.<br/>2045 Lincoln Highway, 3rd Fl.<br/>Edison, NJ 08817</p> | <p>wireless magnetic speaker</p>  <p>QUICK GUIDE MODEL: BRK-MSMS</p>   |
|--|---|---|---|--|