

BT138B



User Manual

Note: Fully charge the speaker, before using for the first time. Ver. 1.0.0

Bluetooth

Bluetooth Pairing Procedure:

Please make sure your Bluetooth device is within 1 meter of Bluetooth range while pairing. Specific pairing steps may vary with different devices.

The general pairing steps are as follows:

1. Turn ON the Bluetooth to your BT enabled device and start the speaker into Bluetooth mode. Once you are in Bluetooth mode search for iBall Musi Jemand connect it in your bluetooth enabled device.
2. After successful pairing with the speaker, you can wirelessly enjoy music.

Receiving Calls

You can receive calls from the speaker if your Bluetooth device supports this function and if it is connected with this speaker. Press the Play/Pause button once to receive or end a call. Quickly double-press Play/Pause button to redial. Long press Play/Pause button if you want to reject an incoming call.

Remarks:


If pairing fails, please switch again to Bluetooth mode and try again the above steps.
After successful connection, speaker and your BT enabled device will remember each other, no need to re-pair at the next use just put both of them into Bluetooth mode pairing will take effect on its own.
Every time the speaker start into Bluetooth mode it will try to connect to the previously connected device, if you want to pair some other BT device other than previous then follow the pairing procedure mentioned above.
Not all BT enabled devices may support all the functions related to Bluetooth.
This Speaker may not support all functions related to calling on Laptop/Computer.

Instructions

All the instructions should be read carefully before operation and follow the instructions Keep this product and its accessories away from excessive heat.
The user should not attempt to repair the speaker. Contact the nearest iBall Service Center for assistance.
No sharp object should be subjected to the speaker/speaker-drivers as it may damage the speakers.
Only use a soft cloth, no harsh abrasives or chemicals to clean, as it may damage the surface finishing.
The power adapter of the speaker should be unplugged from the power outlet when the speaker is left unused for a long period time.
Ensure the speaker is waterproof by removing all the connected cables and the cap is tightly closed before exposing the speaker to liquid.
Do not expose the speaker to water while charging, as doing so may result in damage to the speaker or the power source.
IPX6 - Protection assured against light splashing of water. Must not immerse in water.

Packaging List

1. Speaker.....1pc.
2. User Manual.....1pc.
3. USB Charging Cable.....1pc.



- 2 -

Pairing Both The Speaker Together

Bluetooth Pairing Procedure:(TWS)


(TWS Function Optional with other speakers of the same model)
iBall Musi Jem speaker can be played as a single portable speaker or as a 2.0 Wireless portable speaker.

For playing it as a 2.0 portable speaker, please turn ON both the speakers at the same time, make sure that the speaker is not connected with any other device and is in Bluetooth pairing mode now press the Play/Pause button on any one of the speaker to initiate automatic pairing between the two speakers.

Once paired, one speaker will be a Master speaker and the other will be a Slave speaker. LED of Master Speaker will start blinking whereas Slave Speaker will glow yellow constantly.

Playback-function remains accessible in both the speaker, however, mic function will be available only through the master speaker.

Please follow the GENERAL PAIRING STEPS mentioned earlier for pairing with your BT enabled device once both the speakers get paired with each other and enjoy music wirelessly.



UNPAIRING BOTH THE SPEAKERS

To un-pair both the speakers, long press Play/Pause button, both the speaker will break the connection between them and both will be available for individual connection in BT mode and we can use them as two separate speakers.

- 6 -

Description of the Control Buttons and Connections

1 2 3 4 5 6 7



1. **Power On/Off/Mode:** Long press to power On/Off. Single press to change mode.
2. **Play / Vol - :**
MSD/BT mode: Single press to decrease volume and long press to select previous song.
AUX mode: Single press to decrease volume.
3. **Next / Vol + :**
MSD/BT mode: Single press to increase volume and long press to select next song.
AUX mode: Single press to increase volume.
4. **Play/Pause/Call:**
Single press to play/pause in MSD/BT mode and mute/unmute in AUX mode. Long press to disconnect with existing BT connection.
Call functions: Single press to redial a call. Double press to redial. Long press to reject incoming call.
5. **MSD Slot:** To connect Micro SD card as source input.
6. **AUX Slot:** To connect AUX input.
7. **5V DC:** To charge the speaker using 5V/1Amp power adapter.

- 3 -

Features & Specifications

Features

- Small Size – Ultimate Power
- Scoring sound quality
- Inbuilt Mic for hands-free calling
- TWS Mode: Connect 2 speakers wirelessly and play as 2.0 Speaker
- IPX6 Waterproof – Connect 2 speakers wirelessly and play as 2.0 Speaker
- Multiple Playback Options – BT | Micro SD | AUX
- Volume and Multimedia button functions.
- Play music wirelessly from any BT enabled devices
- Convenient carry strap

Specifications

- Bluetooth version – 5.0
- Total Output: 8 W RMS (4W x 2)
- Driver Unit: 4.5 cm x 2
- Frequency Response: 70 Hz – 18 kHz
- Charging Time: Around 4-5 hours
- Working time : Up to 16 hours
- Dimensions: 6.5 cm (H) x 17 cm (W) x 7.2 cm (D)
- Weight: 580 g.

Controls

Power On / Off / Mode | Volume- / Previous Track | Volume+ / Next Track | Play / Pause / Call / TWS

Inputs

BT | Micro SD | AUX

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



*Working time based on high volume level. It may vary and depends on input source selected. * Images shown in manual and packaging may differ from the actual product. * The Bluetooth® Word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by iBall is without their permission. * All other marks contained herein are trademarks of their respective owners. Product specifications are subject to change without notice. For any technical help on iBall products please contact support@iball.co.in | www.iball.co.in

- 5 -

- 7 -

- 8 -