

Bluetooth Speaker DC-1094

USER'S MANUAL

Thank you for purchasing the Wireless Speaker. Please read this manual carefully before operating. Store this user manual in a safe place for future reference.

THE BASICS

AUX input : external audio source connection to a PC, digital media player or any mobile phone etc.

One end of the cable should be inserted into the DC 5V jack and the other end with the USB jack should be inserted into the USB port of the PC or to the DC 5V adaptor.

MIC input - Connect the microphone which is included with the unit to the jack AUX

Press M to select between Bluetooth/FM/Aux-in modes.

When in Bluetooth/FM/mode, short press to move to the previous channel/track. Press and hold to turn down the volume.

BLUETOOTH CONNECTION AND OPERATION

Turn on the speaker unit and the switch on the Bluetooth on your mobile or any other device and search for the speaker name to connect.

If you have previously connected the device to the unit, the connection will establish automatically.

Once the Bluetooth device has been connected to the unit using the above steps, you can playback your favourite music using the **||** key to Play/Pause. Press the **I< /-** and **I/+** buttons to go to the previous or next tracks. Press and hold the **-** and **+** buttons to turn the volume up and down or use the front knob.

AUX-IN

Using the audio cable, plug one end into the audio jack of the external device and the other end into the unit's AUX jack. Press the M button to switch to the Aux-in Mode. Press and hold the **-/+** buttons to turn the volume up and down.

When using this mode to hear music, the Previous and Next buttons will only work from the Bluetooth device and not the unit.

FM RADIO

Press "M" to change to FM mode. Press and hold the **||** button to search for FM channels automatically. The unit will scan all FM stations and save them to its memory.

CHARGING

Connect the charging cable to the micro-usb port on the device and the other end to the 5V 1A adaptor. When the unit is charging, a RED LED light will turn on.

ACCESSORIES

USB charging cable :1 piece

AUX IN cable :1 piece

USER'S MANUAL: 1 piece

SPECIFICATIONS

Bluetooth version:5.1+EDR

Speaker driver unit size:4 inch*2

Output power: 6W

Speaker impedance: 2 Ohm

Frequency response: 100Hz-20 KHz

Signal to noise ratio: >=85dB

FM's scan range: 81.5-108.0 MHz

Bluetooth wireless range: 10 meters

Max memory USB/SD: 32GB

USB charging: DC 5V'

Battery capacity: 1200mAh

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.