
SoundPal Cube F1 wireless



SoundPal User Manual F1 Bluetooth Speaker User Manual Dear Customer, Please read this user manual carefully before using it an keep it in a safe place for any future reference. Warning: 1. In order to extend the life of the speaker and your phy and mental health, please do not play music at large volu for a long time period. 2. If an error occurs, please turn off the power switch immediately, and unplug the USB cable to prevent speak and other component failure.Please insert your drawings the speaker with button description here 1. — Short click to decrease volume. Long click to skip previous track; 2. >// Play/Pause button. Answer a phone call or hang u 3. + Short click to increase volume. Long click to skip to next track. 4. o Aux audio input 5. USB charging port 6. Power ON/OFF Switch

	7. Bluetooth indicator light : Connected - Blue, When battery is charging - Red. SPECIFICATIONS:	Charge through a computers USB port or USB wall charger (charger must be 5V & 1000mA output). PAIRING BLUETOOTH	You can listen and talk through the speaker in place of your mobile phone. • Answer Incoming Calls - While connected to your mobile	 Refer all servicing to qualified personnel only. Do no self-service the unit if the unit has been damaged in Apparatus shall not be exposed to dripping or splase
nd	Bluetooth version 2.1 + EDR	Please make sure that the "Bluetooth" setting of your	phone, incoming calls will ring through the speaker, to	• Do not place any sources of danger on the apparat
and	Output power: 5W Frequency response: 120HZ - 20kHz	Bluetooth device (i.e. phone, tablet, etc) is turned ON before attempting to pair your speaker with it. Generally, your digital	answer a call press the "phone button." To hang up, press the "phone button."	 (e.g. liquid filled objects, lighted candles.) Battery shall not be exposed to excessive heat suc
y. Iysical	S/N Ratio: ≥ 65dB	device will display a list of bluetooth devices that it is able to	Make Outbound Calls - While connected to your mobile	sunshine, fire or like.
blume	Input power: USB 5V	connect to. Your speaker will be displayed under "SoundPal".	phone, dial the number you want to call on your mobile	sunshine, me or ince.
Jamo	Li-ion Battery 800 mAh	(Note: if your device requires a password to connect,	phone and press call.	
	OPERATION	enter "0000").	To redial the last number from your log list double press	
aker	CHARGING	• Turn the speaker ON and it will immediately go into pairing	the "phone button."	
gs of	Before using this speaker it is recommended that you fully	mode and become "discoverable" by other devices.	IMPORTANT SAFETY INSTRUCTIONS	
	charge it using supplied USB charging cable. Initial charging	 Once connected, any audio that normally plays through 	 Read and keep these instructions 	
p to	will take up to 6 hours (we recommend not to charge more	your device will now play through the speaker.	 Heed all warnings and follow all instructions 	
	than 12 hours). Additional charges should last 3-4 hours.	AUX-in	 Do not use this apparatus near water 	
up.	 Charging is indicated by a solid red LED light in front of 	In addition to connecting via bluetooth, you can connect to	 Clean only with dry cloth 	
0	the speaker;	the speaker directly using the included AUX cable. Plug one	 Do not block any ventilation openings. Install in 	
	 charging is complete when the red light is no longer 	end of the AUX cable into your device and the other end into	accordance with manufacturers instructions	
	illuminated.	the speaker.	 Do not install near heat sources such as radiators, heat 	
	If the speaker was not use for a long periods of time, make	HANDS FREE CALLING (Built-in Microphone)	registers, stoves, or other apparatus that produce heat.	
	sure to charge the speaker fully before using it again.		 Use only accessories specified by the manufacturer. 	



WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful end or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for

an uncontrolled environment.

This equipment should be installed and operated with minimum distance

20cm between the radiator & your body.