

EXHIBIT C - EUT INTERNAL PHOTOGRAPHS

For model BF-TD511 UHF:

EUT – Cover off View 1




EUT – Cover off View 2




EUT – Cover off View 3



EUT – Cover off View 4




EUT – Cover off View 5




EUT – Cover off View 6




EUT – Cover off View 7




EUT – Main Board Top View




EUT – Main Board Top Shielding off View




EUT – Main Board Bottom View




EUT -Switch Board Top View




EUT -Switch Board Bottom View



EUT –Side Keyboard View




EUT –Accessory Connector View




EUT -FPC keyboard Top View




EUT -FPC keyboard Bottom View




EUT -Speaker View




EUT -LCD board View



EUT -IC Mains View 1



EUT -IC Mains View 2



For model BF-TD512 UHF:

EUT – Cover off View 1



EUT – Cover off View 2



For model BF-TD510 UHF:

EUT – Cover off View 1



EUT – Cover off View 2




EUT – Battery View



EUT – Charger Cover off View



EUT – Charger Main Board Top View



EUT – Charger Main Board Bottom View

