


QUICK START GUIDE

Emotion Max

Active noise cancelling Wireless Over Ear Headphone with Multipoint



www.soulnation.com/support
SES-035-01

EMOTION MAX

First of all, Thank You!

We hope you enjoy your purchase and being a part of our little community called **SOULNATION**.

Every SOUL product is designed with an emphasis on three key elements: **Power, Clarity, and Comfort**. We are committed to providing you the highest quality product with the latest technology and best value.


We'd love to hear your thoughts or see a picture or two on our social media.

Again, thank you for your support.

You are the reason why we can keep going!

— SOUL Team

©2021 SOULNATION
Please follow us on our social media platforms for news and updates!



KEEP GOING

Every SOUL has a story, tell us yours...

Every SOUL has a story. It propels every person. The heart of every act - the reason why. The running, leaping, and dancing. It's behind every entrepreneur, artist, musician, dancer, and athlete. The striving, perseverance, and overcoming. It gets you up early and keeps you up late. It's that voice in your head that says...


Keep Going

GETTING STARTED


Commentaires / Lass Uns Anleiten / Empescamos / 始めましょう / 의 시작과 / 開始使用 / 开始使用 / Давайте Начнем

AUTO PAIRING


Appairage Automatique / Automatische Pairing / Emparejamiento Automático / オートペアリング / 자동페어링 / 自動配對 / АВТОМАТИЧЕСКОЕ СОПРЯЖЕНИЕ



RESET
Réinitialiser / Reiniciar / Zurücksetzen / 리셋 / 재설정 / 重設 / Сброс




BATTERY INDICATOR



Charging: Blue White
100%: Blue
Turn Off: Red

MULTIPOINT CONNECTION


Conexión Multipunto / Mehrpunktverbindung / Conexiones Multipunto / マルチポイント接続 / 다 지점 연결 / 多點連接 / Многоточечное Соединение



- PAIR 1ST DEVICE
- PAIR 2ND DEVICE
- RE-CONNECT 1ST DEVICE

MUSIC & CALLS

La Música / Musik / Música / 音樂 / 음악 / 音樂 / 音乐 / МУЗЫКА
Appel / Anruf / Llamada / コール / 電話 / 來電 / 来电 / ЗАПИСИ



POWER
On: >2s
Off: >5s

CALLS
x1
>2s
x3
>2s

PLAY / PAUSE
x1

TRANSPARENCY MODE
x2


VOLUME
Vol+: x1
Vol-: x1

SKIP TRACK
>2s
>2s



CONTENTS

Contenu / Inhalt / Contenido / 同梱品 / 내용 / 内容 / КОМПЛЕКТ ПОСТАВКИ



WARNING

DO NOT use alcohol, paint thinners, detergent, shampoo, or other solvents for cleaning purposes.
DO NOT immerse the earphones under water.
DO NOT expose the product to extremely high or low temperatures.
DO NOT use the product near candles, cooking burners and open flames.
DO NOT disassemble the product in any way to avoid electric shock.
DO NOT charge the battery in accordance with the instructions provided by the company.
DO NOT wash the charging box.

CAUTION

DISPOSE OF BATTERIES PROPERLY IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

INSTRUCTIONS

DO NOT OBTAIN THE USED BATTERIES ALONG WITH HOUSEHOLD WASTE.
DISPOSAL OF BATTERY SHOULD COMPLY WITH LOCAL ENVIRONMENTAL REGULATIONS.

AVERTISSEMENT

NE PAS utiliser d'alcool, de diluants de peinture, de détergent, de shampooing ou d'autres solvants pour effectuer un nettoyage.
NE PAS immerger intentionnellement les écouteurs sous l'eau.
NE PAS exposer les écouteurs aux températures extrêmes.
NE PAS utiliser le produit à des températures extrêmement élevées ou basses.
NE PAS laisser le produit près de bougies, de gazinières et de flammes nues.
NE PAS démonter le produit de aucune manière pour éviter tout choc électrique.
Ne chargez le batterie que conformément aux instructions fournies par le fabricant.

ATTENTION

LES PRODUITS D'ALIMENTATION AUGMENTENT LA BATTERIE EST REMPLACÉE PAR UN TYPE
DE BATTERIE NE CONFORMANT PAS.

INSTRUCTIONS

NE PAS OBTENIR LES BATTERIES USAGÉES AVEC LES DÉCHETS MÉNAGÈRES.
L'ÉLIMINATION DES BATTERIES DEVE COMPLIÉR LES NORMES ENVIRONNEMENTALES LOCALES SUR L'ENVIRONNEMENT.

ВНИМАНИЕ

НЕ ПОЛУЧАЙТЕ ИСПОЛЬЗОВАННЫЕ БАТАРЕИ ВМЕСТЕ С БЫТОВЫМ МУСОРНЫМ
ОТХОДАМИ. УТИЛИЗАЦИЯ БАТАРЕИ ДОЛЖНА СОТВЕТСТВОВАТЬ МЕСТНЫМ
РЕГУЛИРУЮЩИМ ЗАКОНОДАТЕЛЬСТВОМ.

ADVERTENCIA

NO USE alcohol, diluyentes de pinturas, detergentes, champú u otros disolventes para la limpieza.
NO intencionalmente sumergir los auriculares en el agua.
NO exponer los auriculares a temperaturas extremadamente altas o bajas.
NO utilizar el producto a temperaturas extremadamente elevadas o bajas.
NO dejar el producto cerca de velas, estufas o flamas vivas.
NO desarmar el producto en modo alguno para evitar descargas eléctricas.
No cargue la batería que no sea la indicada en las instrucciones suministradas por el fabricante.

PRECAUCIÓN

REEMPLAZAR LAS BATERÍAS USADAS CON EL RESTO DE LA BASURA DOMÉSTICA.
LA ELIMINACIÓN DE LAS BATERÍAS DEBE CUMPLIR CON LAS NORMAS AMBIENTALES LOCALES.

INSTRUCCIONES

NO OBTENER LAS BATERÍAS USADAS CON EL RESTO DE LA BASURA DOMÉSTICA.
LA ELIMINACIÓN DE LAS BATERÍAS DEBE CUMPLIR CON LAS NORMAS AMBIENTALES LOCALES.

ЗАВАН

НЕ ПОЛУЧАЙТЕ ИСПОЛЬЗОВАННЫЕ БАТАРЕИ ВМЕСТЕ С БЫТОВЫМ МУСОРНЫМ
ОТХОДАМИ. УТИЛИЗАЦИЯ БАТАРЕИ ДОЛЖНА СОТВЕТСТВОВАТЬ МЕСТНЫМ
РЕГУЛИРУЮЩИМ ЗАКОНОДАТЕЛЬСТВОМ.

使用上の注意

アルコール、塗料用シンナー、洗剤、シャンプーなどの溶剤で洗わないでください。
水やアルコールを意図的にかけないでください。
水や極端に高い温度にさらさないでください。
極端に高い温度にさらさないでください。
ろうそく、調理器具、火のそばに製品を置かないでください。
必ずメーカーの指示に従ってバッテリーを充電してください。

注意

必ずメーカーの指示に従ってバッテリーを充電してください。

警告

必ずメーカーの指示に従ってバッテリーを充電してください。

警告

請勿使用酒精、塗料稀釋劑、清潔劑、洗髮水或其他溶劑進行清潔。
請勿將耳塞浸入水中。
請勿將耳塞暴露於極端高溫或極端低溫下。
請勿將產品靠近蠟燭、爐火或明火。
請勿拆解產品以避電擊。
請依照原廠說明書指示進行充電。

注意事項

請勿將使用過的電池與其他家庭垃圾一起丟棄。
電池的處理應符合當地環境保護法規。

說明

請勿將使用過的電池與其他家庭垃圾一起丟棄。
電池的處理應符合當地環境保護法規。

Size (Folded): 90mm X 60mm
Size (Unfolded): 630mm X 60mm
DOUBLE SIDED PRINT



PROJECT TITLE

EMOTION MAX QSG DESIGN

DATE CREATED

18 / MAY / 2021

Copyright@Soul Electronics Limited
Private and Confidential

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.