

B18s Usermanual

Bluetooth pairing Name: Soul s-storm

1: 2. Single machine mode operation

2.1. Press the key for 1 second, turn on the machine and enter the Bluetooth mode. The Bluetooth indicator (red and blue lights flash alternately) will enter the Bluetooth configuration state. After connecting with the mobile phone, the Bluetooth indicator light (blue light 8s flashes once).

2.2. Click this key to pause the play attack; press and hold this key for 10s; Automatically enter the pairing mode (with pairing prompt sound); double click this key to enter the redial function of the speaker. After dialing out successfully, click this key to hang up the phone; when the associated mobile phone calls, there is a voice prompt; short press this key to answer the call, long press 2S to refuse to answer the call; after the call is completed, click this key again to hang up the phone;

2.3. Short press the "" key to reduce the volume, and long press the "" key for 2 seconds to select the previous song,

2.4. Short press the "" key to increase the volume, and long press the "" key for 2 seconds to select the next song,

2.5. Press the key three times quickly (after Siri starts, you can't speak one sentence, you have to manually click the phone voice, otherwise Siri will be automatically turned off).

3. TWS mode operation

1. Press the key for 1 second, turn on the machine and enter the Bluetooth mode. The Bluetooth indicator (red and blue lights flash alternately) will enter the Bluetooth configuration state. After connecting with the mobile phone, the Bluetooth indicator light (blue light 8s flashes once).

2.2. Any one of the two models enters TWS pairing status, and the blue light flashes rapidly; after the pairing is successful, the host computer (red and blue lights flash alternately), and the auxiliary machine (the blue light 8s flashes once), and the Bluetooth indicator light (the blue light 8s flashes once) is connected with the mobile phone.

3.2.2. Click this key to pause the play attack;

4. When the mobile phone and TWS are connected, the chief and vice captains press 3S to disconnect the TWS connection, first release the TWS connection, and then long press 10s to disconnect to enter the manual pairing mode, and the red and blue lights flash alternately.)

5. Short press the "" key to reduce the volume, and long press the "" key for 2 seconds to select the previous song,

6. Short press the "" key to increase the volume, and long press the "" key for 2 seconds to select the next song,

7. When calling, the short key can realize the function of answering the call, a short press can end the call, and a long key for 1.5 seconds can reject the call.

8.2.5. Press the key three times quickly (after Siri starts, you can't speak one sentence, you need to manually click the phone voice, otherwise Siri will be automatically closed).

9. In TWS state, press and hold the host or slave key for 3 seconds, and the two models enter the shutdown state. The red light is on for one second and then goes out

10. Switch on and enter Bluetooth mode. If no device is connected, Bluetooth will be automatically turned off after 3 minutes, and the Bluetooth indicator will be off.

11. Connect back mode: 1. Connect back to the connected mobile phone when the phone is turned on; 2. Turn on the Bluetooth of Android mobile phone to automatically connect back; 3. When the mobile phone is disconnected automatically after leaving the Bluetooth receiving distance, it can be connected back before the Bluetooth stereo is automatically turned off (3 minutes)

Note: 1. The equipment has the function of automatic back connection, and there is a prompt tone after the equipment is connected back,

2. When the speaker is not working, it will shut down automatically after 3 minutes

3. Low battery alarm at 3.4V; shutdown at 3.0V

4. Connect the mobile phone with Bluetooth to display the power

FCC Warning

a. § 15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

b. § 15.21 Changes or modification warning.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

c. § 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.