

- ② To answer a call, press the multifunction button or use the keys on the phone.
- ③ To reject the call, press and hold the multifunction button for about **1 seconds**.
- ④ To end a call, press the multifunction button or use the keys on the phone.

Note: If you receive or make a call while listening to music, the music will stop automatically until the call is ending. To pause or resume playing, press the multifunction button. To stop playing music, press the multifunction button again.

■ BUTTON FUNCTION CHART (BLUETOOTH SOURCE)

FUNCTION	BUTTON	OPERATION
Turn On	Multifunction Button	Press and hold (Approximately 4s)
Pair	Multifunction Button	Press and hold (Approximately 6s)
Turn Off	Multifunction Button	Press and hold (Approximately 3s)
Answer Call	Multifunction Button	Single Press
End Call	Multifunction Button	Single Press
Refuse Call	Multifunction Button	Press and hold (Approximately 1s)
Last Call Redial	Multifunction Button	Double Press (quickly)
Play (Music Mode)	Multifunction Button	Single Press
Pause (Music Mode)	Multifunction Button	Single Press
Volume Up	Volume up button	Single Press
Forward track	Volume up button	Press and hold
Volume Down	Volume down button	Single Press
Backward track	Volume down button	Press and hold

■ TROUBLE SHOOTING

See below for solutions to common problems.

SYMPTOM	SOLUTION
LEDs are not lighting up	Power button is not turned on. The battery is out of power. Charge your device.
Hearing Distortion	Lower Volume on your phone/music player/device. Charge your device. Confirm that your phone/music player is Bluetooth compatible. Don't turn on too many headsets and Bluetooth devices at the same time when connecting. Please turn off other headsets and turn on the paired headset in order to avoid interference.
Unable to Pair with Bluetooth devices	Failed to pair successfully within 3 minutes. Please repeat the pairing procedure. Make sure the blue LED is flashing quickly (under pairing mode) Make sure the input password is correct if required. Clear the pairing list on your phone and try again.

Compliance with FCC rules (U.S.A., only)

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- Proper connections must be used for connection to a host computer and/or peripherals in order to meet FCC emission limits.

■ SPECIFICATIONS

Bluetooth® Version: Bluetooth 4.0 + EDR

Bluetooth® Profiles: Handsfree Profile (HFP) for talking and operating the phone
Advanced Audio Distribution Profile (A2DP) for audio streaming
Audio Video Remote Control Profile (AVRCP) for music control

Battery Life: Call time up to 12 hours, music time up to 10 hours (Varies by volume level and content)

Standby Time: Up to 15 days

Charging Time: Approx. 3 hrs from empty to full charge

Bluetooth® Range: 33 ft (10m)

Microphone: Omni-directional

Battery Type: Lithium ion polymer

■ SAFETY INFORMATION

Follow these tips and safety instructions to preserve the operational lifespan of your Bluetooth Stereo Headset:

- ① Do not use this headset in extreme temperatures. Keep away from extreme hot, cold, dry, or damp areas. Also keep away from water, fire, and radiation.
- ② It is recommended that you allow the battery to fully charge before using the device for the first time. (approximately 3 hours. Do not recharge unattended for longer than **8 hours**)
- ③ The effective range for this wireless device is 10 Meters. Performance may be affected by distance and interference from other devices or conditions within the operating environment.
- ④ Barriers and other wireless devices may affect the performance of headset.
- ⑤ Check the laws and regulations on the use of mobile phones and hands-free equipment in areas you intend to use this product.

▲ WARNING

- ① Permanent hearing damage or hearing loss may occur if earphones are used at a high volume. Hearing experts suggest not continuously listening to music at a high volume. If you hear a "hissing" noise in your ears, or if you experience discomfort, lower the volume, or temporarily discontinue use of this product until discomfort subsides.
- ② Do not disassemble your Bluetooth Stereo Headset.
- ③ Do not allow young children to use your Headset unsupervised.
- ④ Observe all signs and instructions that require an electrical device or radio product to be switched off in designated areas, such as petrol/refueling stations, hospitals, blasting areas, potentially explosive atmospheres or aircraft.
- ⑤ Do not use or connect adaptors and/or chargers to this product that are not approved of or specified in this quick start guide.



SV3

Pro Hi-Definition Wireless
On-Ear Headphones


User Manual

CONTENTS

- 1 Bluetooth stereo headset
- 2 Micro-USB cable
- 3 3.5mm stereo cable
- 4 Carrying Pouch



LAYOUT AND CONTROLS



- A Volume up button/Forward track
- B Blue/Red LED
- C Volume down button/Backward track
- D Multifunction button (Power on/off, Pairing, Answer call/End call/Reject call, Play/Pause)
- E Micro-USB jack for charging
- F 3.5mm AUX jack
- G Microphone
- H Adjustable headband
- I Foldable design

BASIC OPERATIONS

CHARGING THE BATTERY

The LED will continually flash when battery power is low. When the battery is completely drained, no indicator light will work. Before using, allow the battery to charge for at least 3 hours.

- 1 Connect the Micro-USB cable to the USB Jack on your headset.
- 2 Connect the USB end to a USB port on your computer or Laptop.

WHEN CHARGING

The blue LED will flash slowly during charging.

WHEN FULLY CHARGED

The blue LED indicator will light up.

POWER ON/OFF

To switch the headset on, press and hold the multifunction button for about **4 seconds** and then release.

Note: If the Bluetooth Stereo Headset has already been paired or connected to another Bluetooth device before, the Blue LED light will slowly flash as the headset automatically attempts to reconnect to the paired device. If the headset is unable to locate a device within **5 minutes**, it will be in standby state, and if the headset is unable to locate a device within **30 minutes**, it will shut down automatically.

To turn the power off, press and hold the multifunction button for about **3 seconds** and then release. The red LED will light for 1 second, then all LED lights will go off.

PAIRING HEADSET WITH BLUETOOTH ENABLED DEVICES

- 1 If the headset has not been previously paired with a device, press and hold the multifunction button for about **6 seconds** until the blue/red LEDs light flash quickly, indicating that the device is in "pairing" mode.
- 2 If the headset has been previously paired with the device, you just need to press and hold the multifunction button for about **4 seconds** until the blue indicator light is on and flashes slowly which indicates standby mode, and then headset could connect to the device (its Bluetooth function should be turned on) automatically.
- 3 Turn on Bluetooth function on the device, and set it to search for Bluetooth devices.
- 4 Once the device is discovered, make the connection by selecting "SOUL SV3".
- 5 Enter "0000" if a passcode is asked.

Note: If you have paired and connected the headset with one of your Bluetooth device, disconnect the headset from it before pairing the headset with another Bluetooth device, and then follow the instructions in the section above to pair and connect again.

DISCONNECTING THE HEADSET

Switch off the headset, or disconnect it in the Bluetooth menu of your device. You do not need to delete pairing with the headset to disconnect it.

RECONNECT HEADSET

To connect the headset to the mobile phone or music player that you have last used:

Switch on the headset, and open the Bluetooth function of your device. In your device, you may be able to allow the headset to connect to it automatically. For further instructions, refer to your device's user's guide.

USING THE HEADSET

Place headset on your ears by matching the L/R markers to your ears accordingly. Adjust the length of the headband until the speaker pads rest comfortably on your ears.

LISTEN TO MUSIC

- 1 Pair and connect the headset to a Bluetooth device such as a mobile phone and music player. Then press the multifunction button. The music player must support the A2DP Bluetooth profile. The music functions available depend on your mobile phone or music player.
- 2 To control forward track, backward track, **press and hold** the volume up or down button to have "Forward or Backward track" function.
- 3 To adjust the headset volume, **single press** the volume up or down button to adjust volume during a call or while listening to music.
- 4 To listen to music from wired audio source, connect 3.5mm stereo cable from AUX jack to music player such as MP3, PC, CD player, etc. You will be able to adjust the volume or track on player only.

Note: Audio content via 3.5mm stereo cable will override wireless audio via Bluetooth

CALL HANDLING

- 1 To make a call, while connected to the headset, use your mobile phone and dial as you normally do. And double press the multifunction button of headset can redial last call directly.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.