

Instruction manual


Welcome to choose HIGHSTAR company product ICAMP BLUETOOTH SPEAKER WITH NIGHT LIGHT. The product is a portable audio with Bluetooth receiver. You can store the songs in mobile phone or device with Bluetooth playback, and then transmit to this product for music playback via Bluetooth.

Read the instruction manual quickly before use.

A. Main features and Technical Parameters

1. Bluetooth audio player
2. Handfree function
3. $\Phi 3.5$ mm audio input interface
4. Audio Max power: 5W*1
5. Frequency response: 20Hz-20kHz
6. Max. power consumption: 1W
7. Power supplied: built-in rechargeable lithium battery
8. Connect external USB DC 5V power source to charge the unit
9. Charging time : around 3-4 hours
10. Continue playing music about 6-8 hours when built-in lithium battery is fully charged.
11. Continue for Nightlight about 10 hours when built-in lithium battery is fully charged.
12. LED Bluetooth/line in indicator and power charge indicator
13. Water resistance level: IPX4

B. Product Illustration



C. Key functions

No	Current mode	Function operating	Button	Operation	Indicator
1	Power off	Power on	Ⓜ	Long press for 2 seconds	Status Indicator is ON
2	Power on	Power off	Ⓜ	Long press for 5 seconds	Status Indicator is OFF
3	Power on	Bluetooth pairing		manually paired	blue status indicator is flashing rapidly
4	Power on	Bluetooth pair successfully		Automatically paired	blue status indicator is flashing slowly
5	Power on	Call back	Ⓜ	Double click twice	
6	Call mode	Answer call	Ⓜ	Short press once	
7	Call mode	Reject call	Ⓜ	Long press	
8	Talk mode	End call	Ⓜ	Short press once	
9	Bluetooth mode	Volume up	+	Long Press	
10	Bluetooth mode	Volume down	-	Long Press	
11	Bluetooth mode	Previous song	⏮	Short Press once	
12	Bluetooth mode	Next song	⏭	Short Press once	
13	Bluetooth mode	pause/play/mute	⏸	Short press circle	
14	Any mode	Charging			Red charging indicator is ON
15	Any mode	Battery is full			Red charging indicator is Off and change to green
16	Bluetooth mode	Audio input		Audio cable is plug into the audio input	Green status indicator is ON
17	Audio mode	Bluetooth mode		Unplug The audio cable	Blue status indicator is ON
18	Any mode	Night light ON/OFF	Ⓜ	Short press circle	
19	On Mode	Dimmer	Ⓜ	Long press	The brightness in ascending or descending regulation.

D. Bluetooth playback

1. Long press “Ⓜ” for 2 seconds for power ON to Bluetooth speaker. Blue status indicator is ON. Please don't plug the audio cable into the line- in jack when Bluetooth playback.
2. Turn on your cell phone or Bluetooth device on the Bluetooth function, and search for devices in the Bluetooth menu.
3. When "Hiting" appears on the Bluetooth devices list, select "Hiting" to establish pairing and connection (if asked for a passkey, enter 0000).When the pairing and connection is successful, it produces a connected tone, and Bluetooth indicator changes to slow flash, the speaker is ready for playing music. Short Press “Ⓜ” to play music.
4. When the connection between the mobile and the speaker is successful, and the speaker is playing music, the music will be stopped when incoming call is reaching and the speaker will play incoming call alert, and short press “Ⓜ” to answer the call, others' speech will be broadcast via the speaker, Long press

“Ⓜ / Ⓜ” to adjust desire volume for conversation. Please keep toward the speaker within 1meter distance during phone conversation. Short press “Ⓜ” to hang up the phone. The speaker is automatically restored before playback music.

To reject the incoming call, long press “Ⓜ” for 2 seconds to reject the incoming call.

To redial the previous call number, short press “Ⓜ” twice for redial.

5. If the pairing is overtime or no flash for indicator light, please repeat step 1 to 3 for re-connection.

E. Audio input mode

1. Please insert 3.5mm audio cable into the audio input port of the product , with MP3, IPOD, cell phone or other audio connections, audio music playback, adjust the audio output volume to achieve the best sound , and the green indicator is on.

2. Long press “Ⓜ / Ⓜ” to adjust desire volume to achieve the best sound .The speaker is already adjusted to the max. sound volume when 'du.du.du' sound is occurred.

3. Through 'audio line-in' jack playing music, short press “Ⓜ” for play/pause , the last song, the next song are no function. Please control music through your music device.

4. Please pull out the audio cable to disconnect the devices from the speaker, the speaker will switch back to the Bluetooth mood , blue status indicator is flashing again, and the product will automatically pair back with the last device.

F. Power supply

1. Connect DC 5V adapter with the Micro USB for power supply and charging the built-in rechargeable lithium battery synchronously, the red power indicator is on. After the full charge , the red indicator is off , and the green indicator is on. Disconnect the adapter , all the power charging indicators are off.

2. Comparing with the Bluetooth function , Line-in is the first for the unit .

3. The speaker is powered by the built-in rechargeable battery , if no adapter to be connected. When the speaker is charging through Micro USB, it is not affected whether the speaker is ON or OFF status.

G. Night Light function

1. The Bluetooth speaker is with Night light function. Please short press “Ⓜ” for Light ON/OFF, or long press “Ⓜ” to adjust the dimmer function.

H. Troubleshooting

Failure Manifest	Solutions
Bluetooth playback interrupt and produce a sound.	Lower battery, please charge
Fail to turn on	
Music intermittent in Bluetooth playback	Try to move the bluetooth device close to the product or change the audio or equipment location
	Lower battery , please charge
	Try to move the Bluetooth device closer to the speaker
	Turn off & restart
	Device of the computer has Bluetooth function or not
Equipmment cannot pair with Bluetooth audio connection	Try repeating this product Bluetooth playback and set up steps
	Play the music in the only one device , cancel Equipmment and unused pairs (see the documents for help), in accordance with the procedure set pairing new devices
	Bluetooth name is not correct, confirm whether "Hiting"
	Repair again
No call function	Check the setting of the phone(see the phone manual)
	Lower battery, please charge
Key failure	Turn off & restart
	Please use the original adapter for this item.
Weak sound	Touch “Ⓜ” key to the suitable level

I. Packing Accessories

1. Micro USB cable x 1
2. Line in audio cable x 1
3. An adapter (optional)
4. Instruction manualx 1

Caution :

1. The product avoids rain and damp, in order to avoid damage.
2. The product should be kept away from fire, high temperature environment to avoid the product does not work normally and explosion.

3. When the product is playing music via Bluetooth technology, the music may caused intermittent or noise because of the environment or the source device (such as mobile phones) interference or software incompatibilities etc... Please adjust the distance between the music device and the unit, or restart the unit's power supply or restart the music device or change to other music source to have better sound performance.

4. When the product is during a call via Bluetooth technology, the conversation may be intermittent or noise, or phone off because of the environment or the network signal interference or poor etc... Please adjust the distance between the phone and the unit, or change to other calling device, or restart the unit's power supply etc..to improve the calling quality.

5. Do not touch the speaker or the speaker collision with other objects to avoid damaging the speakers.

6. The power supply output 5V and current 1A or more.

7. If it is stopped using for a long time , pls make sure it is full charged .

8. The product built-in rechargeable lithium battery, please do not pollute the environment when discarded, try to classify recycling.

9. The product should be used for the first time after the battery is fully charged.

FCC Certification Requirements

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**