USER GUIDE

IMBT25 Bluetooth Headphones

Visit iamplus.com for support.

English User guide

Warning letter:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The statements should be displayed in the user manual: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.


This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.


Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio

exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne

doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage

radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.





What's in the Box.

- I.AM+ BT Earphones
- Micro USB charging cable.
- Quick Start Guide
- User Guide
- Warranty

2. Headphones operation

Item	Requirement and Description					
Power On/Off	 Power On: Press and hold the multifunction button for 3 seconds. (release the button after the white LED bright, the red LED and white LED start flashing means the device enter pairing mode) Power Off: Press and hold the multifunction button until the red LED light up. Red LED turn off means the device power off 					
Pairing	 First paring: Press and hold multifunction button for 3 sec. to power on, earphones auto-enter pairing mode - LED alternates flashing Red and White. To paring with your Bluetooth enabled device, go to settings on your device make sure Bluetooth is switched on. The earphones appears as "A.I. Buttons" Select to pair. Bluetooth pairing after a successful first pairing: Power off then Press and hold multifunction button for 5 sec. to place earphones in pairing mode - LED alternates flashing Red and White, mobile phone search the Bluetooth device to connect the earphones (earphones ID is "A.I. Buttons") If the earphones are outside Bluetooth range and disconnect from device, the earphones will automatically try to re-connect. If reconnection is unsuccessful for more than 5 mins, the earphones will power off. Set up use of earphones with multiple devices Pair headphones to device 1 Turn off the Bluetooth on device 1, and turn on Bluetooth on phone 2 					

while charging, Solid white when full charge is reached. Music Mode Functio No No Volume up Wusic or phone call mode Volume Music or phone down Call mode Play/Pause Music mode No No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button Triple press multifunction button							
Charging Voice command Hold volume down for 3 seconds to activate. LED Indication LED turned off when headset powered off or not charging Power on: white LED on 1s Power off: red LED on 1s Pairing: LED alternates flashing Red and White Connected: white LED 0.1s on 24s off Disconnected: white LED 0.1s on 2 times/2s off Incoming call: white LED 0.5s on 70.5s off Outgoing call: white LED 0.5s on 70.5s off Music play: white LED 1s on 74s off LED is changed from white blinking to Red blinking when battery low Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Music Mode Functio Status Sound Operation indication Volume up Music or phone No Press volume - call mode Volume Music or phone No Press volume - call mode Play/Pause Music mode No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button		3. Search and pair the headset to device 2					
Using voice command LED Indication • LED turned off when headset powered off or not charging • Power on: white LED on 1s • Power off: red LED on 1s • Pairing: LED alternates flashing Red and White • Connected: white LED 0.1s on 2s times/2s off • Disconnected: white LED 0.1s on 2 times/2s off • Incoming call: white LED 0.5s on /0.5s off • Outgoing call: white LED 0.5s on /0.5s off • Active call: white LED 1s on /1s off • Music play: white LED 1s on /4s off • LED is changed from white blinking to Red blinking when battery low • Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio No Status Sound No Press volume + Volume up Music or phone call mode Volume Music or phone call mode Play/Pause Music mode No No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button		4. Turn on Bluetooth on device 1 and connect to earphones					
Using voice command LED Indication • LED turned off when headset powered off or not charging • Power on: white LED on 1s • Power off: red LED on 1s • Pairing: LED alternates flashing Red and White • Connected: white LED 0.1s on 2s times/2s off • Disconnected: white LED 0.1s on 2 times/2s off • Incoming call: white LED 0.5s on /0.5s off • Outgoing call: white LED 0.5s on /0.5s off • Active call: white LED 1s on /1s off • Music play: white LED 1s on /4s off • LED is changed from white blinking to Red blinking when battery low • Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio No Status Sound No Press volume + Volume up Music or phone call mode Volume Music or phone call mode Play/Pause Music mode No No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button							
Using voice command LED Indication • LED turned off when headset powered off or not charging • Power on: white LED on 1s • Power off: red LED on 1s • Pairing: LED alternates flashing Red and White • Connected: white LED 0.1s on 2s times/2s off • Disconnected: white LED 0.1s on 2 times/2s off • Incoming call: white LED 0.5s on /0.5s off • Outgoing call: white LED 0.5s on /0.5s off • Active call: white LED 1s on /1s off • Music play: white LED 1s on /4s off • LED is changed from white blinking to Red blinking when battery low • Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio No Status Sound No Press volume + Volume up Music or phone call mode Volume Music or phone call mode Play/Pause Music mode No No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button							
Using voice command LED Indication • LED turned off when headset powered off or not charging • Power on: white LED on 1s • Power off: red LED on 1s • Pairing: LED alternates flashing Red and White • Connected: white LED 0.1s on 2s times/2s off • Disconnected: white LED 0.1s on 2 times/2s off • Incoming call: white LED 0.5s on /0.5s off • Outgoing call: white LED 0.5s on /0.5s off • Active call: white LED 1s on /1s off • Music play: white LED 1s on /4s off • LED is changed from white blinking to Red blinking when battery low • Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio No Status Sound No Press volume + Volume up Music or phone call mode Volume Music or phone call mode Play/Pause Music mode No No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button							
Using voice command LED Indication • LED turned off when headset powered off or not charging • Power on: white LED on 1s • Power off: red LED on 1s • Pairing: LED alternates flashing Red and White • Connected: white LED 0.1s on 2s times/2s off • Disconnected: white LED 0.1s on 2 times/2s off • Incoming call: white LED 0.5s on /0.5s off • Outgoing call: white LED 0.5s on /0.5s off • Active call: white LED 1s on /1s off • Music play: white LED 1s on /4s off • LED is changed from white blinking to Red blinking when battery low • Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio No Status Sound No Press volume + Volume up Music or phone call mode Volume Music or phone call mode Play/Pause Music mode No No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button	Charging	Open USB doo	or on controller and	d connect micro II	SR cable		
LED Indication • LED turned off when headset powered off or not charging • Power on: white LED on 1s • Power off: red LED on 1s • Pairing: LED alternates flashing Red and White • Connected: white LED 0.1s on/4s off • Disconnected: white LED 0.1s on/4s off • Incoming call: white LED 0.5s on /0.5s off • Outgoing call: white LED 0.5s on /0.5s off • Active call: white LED 1s on /1s off • Music play: white LED 1s on /1s off • Music play: white LED 1s on /4s off • LED is changed from white blinking to Red blinking when battery low • Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode • Functio • No • Status • Sound • Indication Volume up • Music or phone call mode Volume • Wolume • Music or phone call mode Play/Pause • Music mode No • Short press multifunction button Next song • Music mode No • Triple press • multifunction button Previous • Song • Music mode No • Triple press • multifunction button	Charging	Open OBB doc	on controller and	d connect micro o	SD caoic		
Power on: white LED on 1s		Hold volume down for 3 seconds to activate.					
Power on: white LED on 1s Power off: red LED on 1s Pairing: LED alternates flashing Red and White Connected: white LED 0.1s on/4s off Disconnected: white LED 0.1s on 2 times/2s off Incoming call: white LED 0.5s on /0.5s off Outgoing call: white LED 0.5s on /0.5s off Active call: white LED 1s on /1s off Music play: white LED 1s on /4s off LED is changed from white blinking to Red blinking when battery low Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio Status Sound indication Volume up Music or phone call mode Volume Music or phone call mode Play/Pause Music mode No Short press multifunction button Next song Music mode No Triple press multifunction button Previous Song Music mode No Triple press multifunction button	LED						
Power off: red LED on 1s Pairing: LED alternates flashing Red and White Connected: white LED 0.1s on/4s off Disconnected: white LED 0.1s on 2 times/2s off Incoming call: white LED 0.5s on /0.5s off Outgoing call: white LED 0.5s on /0.5s off Active call: white LED 1s on /1s off Music play: white LED 1s on /4s off LED is changed from white blinking to Red blinking when battery low Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio Status Sound indication Volume up Music or phone call mode Volume Music or phone call mode Play/Pause Music mode No Short press multifunction button Next song Music mode No Triple press multifunction button Previous Music mode No Triple press multifunction button	Indication	• LED turned off when headset powered off or not charging					
Pairing: LED alternates flashing Red and White Connected: white LED 0.1s on/4s off Disconnected: white LED 0.1s on 2 times/2s off Incoming call: white LED 0.5s on /0.5s off Outgoing call: white LED 0.5s on /0.5s off Outgoing call: white LED 1s on /1s off Music play: white LED 1s on /1s off Music play: white LED 1s on /4s off LED is changed from white blinking to Red blinking when battery low Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio Status Sound indication Volume up Music or phone No Press volume + Call mode Volume Music or phone No Press volume - down call mode Play/Pause Music mode No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button		• Power on: white LED on 1s					
Connected: white LED 0.1s on/4s off Disconnected: white LED 0.1s on 2 times/2s off Incoming call: white LED 0.5s on /0.5s off Outgoing call: white LED 0.5s on /0.5s off Outgoing call: white LED 1s on /1s off Active call: white LED 1s on /1s off Music play: white LED 1s on /4s off LED is changed from white blinking to Red blinking when battery low Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio Status Sound indication Volume up Music or phone call mode Volume Music or phone call mode Play/Pause Music mode No Short press multifunction button Next song Music mode No Double press multifunction button Previous Song Music mode No Triple press multifunction button		Power off: red LED on 1s					
 Disconnected: white LED 0.1s on 2 times/2s off Incoming call: white LED 0.5s on /0.5s off Outgoing call: white LED 0.5s on /0.5s off Active call: white LED 1s on /1s off Music play: white LED 1s on /4s off LED is changed from white blinking to Red blinking when battery low Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio Status Sound indication Volume up Music or phone call mode Volume Music or phone down call mode Press volume - Call mode Play/Pause Music mode No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button 		Pairing: LED alternates flashing Red and White					
 Incoming call: white LED 0.5s on /0.5s off Outgoing call: white LED 0.5s on /0.5s off Active call: white LED 1s on /1s off Music play: white LED 1s on /4s off LED is changed from white blinking to Red blinking when battery low Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio Status Sound indication Volume up Music or phone call mode Volume Music or phone down call mode Press volume - call mode Play/Pause Music mode No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button 		• Connected: white LED 0.1s on/4s off					
 Active call: white LED 1s on /1s off Music play: white LED 1s on /4s off LED is changed from white blinking to Red blinking when battery low Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio Status Sound indication Volume up Music or phone call mode Volume Music or phone down call mode Press volume - Volume - Volume while charge is reached. Press volume - Volume - Volume while charge is reached. Press volume - Volume - Volume while charge is reached. Press volume - Volume - Volume while charge is reached. Press volume - Volume while charge is reached. Pr							
 Music play: white LED 1s on /4s off LED is changed from white blinking to Red blinking when battery low Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode Functio Status Sound indication Volume up Music or phone call mode Volume Music or phone down call mode Press volume - Volume - Volume while charging mode - LED signal red wh		• Outgoing call: white LED 0.5s on /0.5s off					
 Charging: The headset will power off and enter charging mode - LED signal red while charging, Solid white when full charge is reached. Music Mode							
while charging, Solid white when full charge is reached. Music Mode Functio No No Volume up Wusic or phone call mode Volume Music or phone down Call mode Play/Pause Music mode No No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button Triple press multifunction button		1 4					
Music Mode n Functio n Status indication Coperation Volume up down Music or phone call mode No press volume + Volume down Music or phone call mode No press volume - Play/Pause Music mode No press volume - No play/Pause Music mode No press multifunction button Next song Music mode No press multifunction button Previous song Music mode No press multifunction button		• Charging: The headset will power off and enter charging mode - LED signal red					
n indication Volume up Music or phone call mode No Press volume + Volume down Music or phone call mode No Press volume - Play/Pause Music mode No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button	Music Mode	<u> </u>	Ī Ī				
Volume Music or phone down call mode Play/Pause Music mode No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button	Widsic Wiode		Status		Operation		
Volume Music or phone down call mode Play/Pause Music mode No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button		Volume up	_	No	Press volume +		
down call mode Play/Pause Music mode No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button			can mode				
Play/Pause Music mode No Short press multifunction button Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button			_	No	Press volume -		
Next song Music mode No Double press multifunction button Previous Music mode No Triple press multifunction button				No	Short press multifunction		
Previous Music mode No Triple press multifunction button		1 lay/1 aust	IVIUSIC IIIOUC	110	1		
song button		Next song	Music mode	No	1		
			Music mode	No			
	Phone call		Incoming call	'Beep' sound	Press multifunction button 1		

mode			once	time
	Reject	Incoming call	No	Press and hold multifunction
	incoming call			button for 2 seconds
	Hang up	During phone	'Beep' sound	Press multifunction button 1
	phone call	call	one time	time
	Switch call	During phone	No	Double press multifunction
	between	call		button
	headset and			
	phone			

- Incoming call status:
 - When mobile phone connected to headset through Bluetooth, mobile phone will stop music player and play ring tone when have incoming call
 - Mobile phone to resume playing music after hanging up phone call

IMBT25 Bluetooth Headphones Specification:

Up to 7hrs use time
Micro USB charging
Ip54 water resistance.

Frequency Response 20 ~ 20K Hz

Sensitivity 107 dB/mW at 1KHz

Impedance 32 Ohm

Speaker driver 11mm

Magnet type NdFeB

Distortion <1% at 1KHz

Music playback time 7hours

Batteries charging time 2hours

Battery type Li-Polymer Battery

Bluetooth version v4.2

Bluetooth range 10m

Audio connection HSP, A2DP with aptX

Weight 18g