


**Soundbar**

**Contact Us**

**Email Us:**  
Email our team at any time at: tianrui\_sales08@163.com we aim to respond to emails within 1 business day.

**Mighty Rock**

7: General Use



This symbol indicates that the relevant electrical product or battery should not be disposed of as general household waste. To ensure the correct waste treatment of the product and battery, try to dispose of them in accordance with any local laws of requirement for disposal of any electrical equipment or batteries. In doing so, you will help to conserve natural resources and improve the standards of environmental protection in treatment and disposal of electrical waste.

**CE**

Products with the CE marking comply with the EMC Directive (2004/108/EC) and the Low Voltage Directive (2006/95/EC) issued by the Commission of the European Community.

The socket outlet shall be installed near the equipment, and shall be easily accessible.

CAUTION: There is a risk of explosion if batteries are replaced with a type not fit for the unit. Dispose of used batteries according to the instructions.

7

7: General Use

**Bluetooth Mode**

1. Connect unit to power. Long press the "Standby" button on the unit, or press the "Standby" button on the Remote to enter Bluetooth Mode. Unit will start searching for a Bluetooth device to connect.
2. Make sure the Bluetooth function of your Mobile or Tablet device is turned ON (Read your related User Manual for full instructions to turn it on). This unit will show as "Mighty Rock" in the Device List, if/when Bluetooth is enabled.
3. Once connected successfully, through the Device connected you will now be able to select audio to play through Soundbar.
4. To adjust Volume, long press the buttons on the unit, or press the Volume +/- buttons on the Remote. You can also alter the sound level from device you have connected via Bluetooth. Note, always adjust to a suitable level as with high power, sound distortion can occur.
5. If connecting to Bluetooth through an adapter, you may require a password. Enter "0000" to connect.

8

7: General Use

**Line In Model**

1. When you wish to connect your device via AUX IN, press the "Mode" button at this time the LED Light will be "Green". To use the RCA Line, press "Mode" again and the LED Light will turn "White".
2. When in the correct mode, connect your device with the relative cable. Once connected, you will be able to select audio to play through Soundbar.
3. You can now use the "Mute" and "Volume +" or "Volume -" to control sound levels from Remote Control, there are also "Volume +/-" buttons on the unit when long pressed will operate volume.

**Adapter Description:**

Input Range - AC100-240V  
Frequency Range - 50/60Hz  
Output - DC 18V, 2A

9

8: Warranty

**Details**

Please keep your receipt as proof of purchase. This product is warranted for any defect in materials or workmanship for one year after the original date of purchase.


This product is for normal domestic use only.

This warranty does not cover damage from misuse or neglect, accidental damage, vermin infestation, excessive voltages such as lightning or power surges or any modification that affects the reliability of the product.


In the unlikely event that your product fails to work normally please contact your supplier and have your receipt of purchase on hand. This warranty is subject to the following provisions:

- This is only valid in New Zealand.
- The product must be correctly connected and operated in accordance with the instructions contained in the manual.
- This product must be used solely for domestic purposes only.
- The warranty will be rendered invalid if the product is resold or been damaged by unauthorized repair.

10



**Soundbar**



**KY-2018**  
Soundbar Speaker  
User Manual

1: Features and Contents

**Features**


- 30" Soundbar
- 2.0 Channel Speaker System
- Stream Music via Bluetooth
- Play Music from a Smart Phone or Tablet
- 30W Total Power Usage

**What's in the Box?**

- 1x Soundbar Speaker
- 1x Remote Control
- Power Supply
- AV Lead
- User Manual
- AUX IN

**Something Missing?**

Please contact the retailer or store you purchased this Soundbar from.



1

2: Technical Specifications

**Sound System**



Channel: 2.0CH  
Output: 15W\*2  
Freq. Response: 90~20000Hz  
S/N Ratio: 80db  
Impedence: 8ohm

**External Interface Function**

DC Power Input: 18V Power Supply


2

3: Product Structure

3

4: Remote Control




4

5: Getting Started

**Powering On**

The instructions below provide simple steps to help power on your soundbar.




- With the Power Supply included, insert the mains adapter plug into the rear of the unit.
- Insert the plug into a power socket and switch the power on.
- Press and hold the **STANDBY** Button on the side of the Soundbar, until Red LED goes off.

5

6: Using the EQ Function

**Did You Know?**

You can alter the frequency response of this audio system using the EQ button.



- Press the EQ button on the Remote Control repeatedly to move between the EQ modes: Rock, Pop, Jazz, Live, Classic and Vocal. The Orange LED will illuminate when EQ mode is active.
- To revert back to Default, press **FLAT** on the Remote Control. The Orange LED will turn off to indicate EQ modes are inactive.

6