

Digital Wireless KIT

Feature)

- · 4CH digital wireless camera & DVR system
- · Simple installation- no cables required! · Total digital wireless, no interferences,
- no privacy leak
 7" LCD monitor with integrated video recorder
- · Support up to 32GB SD card and external
- · Support 4 cameras/ 24hours /7days
- non-stop overwrite recording
- · Multiple recording modes: manual. schedule, and motion activated
- · 15meter night vision range
- · Video quality: 4CH VGA 10fps, 1CH VGA 30fps
- · Weather proof outdoor cameras with 300 m/1000ft transmission open range
- · Video output function for bigger monitor



Digital Wireless KIT

Operation)

- . Connect the power supply, automatic power on
- (in the shutdown, press the power button you can boot) · the camera and monitor can not have metal shielding
- · monitor will display the picture from the camera
- · adjust volume and brightness
- · other features of the device operation method. please refer to the user manual



1. press to enter the menu settings

2. press ▲ ▼ to select the item, press ■ to enter this project

3. press ▲ ▼ to choose to set the project, press ■ to confirm

4. press to exit Setup



1. press to enter the menu settings

2. press ▲ ▼ to select the item, press ■ to enter this project

3. press ▲ ▼ to choose to set the project, press ■ to confirm

4. press to exit Setup

Digital Wireless KIT

1. press
to enter the menu settings

2. press ▲ ▼ to select the item, press to enter this project 3. press ▲ ▼ to choose to set the project, press ■ to confirm

4. press to exit Setup





1. press to enter the menu settings 2. press ▲ v to select the item, press to enter this project

3. press▲ ▼ to choose to set the camera, press ■ o confirm

4. press pair switch on the camera line

5. press to exit Setup

Shortcut key)

- 1. in the manual state, press dec may display a different camera 2. in the monitoring state, press 🔼 can adjust the speaker volume
- 3. Press a can quickly enter the video play menu
- 4. In QUAD mode, press [55] button, can switch sound from different camera

Packing List

Nuber	Name	Quantity	Unit
1	Receiver	1	Piece
2	Camera	4	Piece
3	Adapter	5	Piece
4	Manual	1	Piece
5	A/V Line	1	Piece
6	Bracket	1	Piece

四画面 无线摄像机与DVR系统 7英寸液晶显示器和内置录像功能 數字技术

4 频道数字无线摄像机套装

基本参数

- · 4频道数字无线摄像机与DVR系统
- · 安裝简单, 无需布线 · 全数字无线, 无干扰, 无隐私泄漏
- 具有7"液晶显示器和内置录像机
- · 支持最高32GB的SD卡
- ·支持4个摄像机/24小时/7天不间断覆盖录音 ·多种显示模式:手动显示,循环显示,4面面显示
- ・视频质量: 4CH VGA10fps, 1CH VGA30fps ·防天气变化干扰室外摄像机。开放范围可达300 m/1000ft
- 大屏幕输出视频

结构简图



4 频道数字无线摄像机套装

操作方法

- •开机:接通电源,自动开机(在关机状态,按开机键■■即可开机)
- 调整摄像头和监视屏的位置,不可有金属屏蔽
- 监视屏上会显示摄像头的监控画面 • 调整好合适的声音和亮度
- 该设备的其他功能操作方法,请参考以下说明

预览模式



1.按 📰 健进入菜单设定

2.按 🔼 🔽 键选择该项目,按 🖬 进入此项目

3.按 ▲ ■ 健选择要设定的项目,按 ■ 确认

4.按 🚥 健退出设定

录影储存



1.按 📰 键进入菜单设定

2.按 🔼 🔽 键选择该项目,按 🖼 进入此项目

3.按 ▲ ■ 健选择要设定的项目,按 ■ 确认

4.按 500 键退出设定

4 频道数字无线摄像机套装

系统设定

1.按 📰 键进入菜单设定

2.按 🔼 🔽 键选择该项目,按 🐯 进入此项目

3.按 ▲ □ □ 键选择要设定的项目。按 ■ 确认

4.按 🚥 键退出设定

对码方法





1.按 📰 键进入菜单设定

2.按 ▲ ■ 键选择系统设定项目,进入对码选项 3.按 ▲ ▼ 键选择要对码的摄像头按 ■ 确认

4.摄像头端,按电源线上面的对码按键一次,对码成功

5.按 🚥 键退出

快捷按键

1.在手动选择摄像头的状态下, 按 📧 可以切换显示不同的摄像头

2.在监视状态下,按 🔼 可以调节喇叭音量的大小

3.按 ■ 可以快捷进入视频播放菜单

4.在四画面状态下,按100按键,可以切换不同摄像头的监听声音

包装清单

序号	名称	数量	单位
1	接收机	- 1	fit
2	摄像头	4	fi
3	15.00	5	个
4	说明书	1	本
5	A/VEQ	- 1	张
6	收在支架	- 1	个



RoHS CE FC &



使用前请仔短阅读本使用说明书,并妥善保管。以备将未谓用

7"_{Tft}

Photograph for illustration only factual products may vary assording to availability

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.