

# Bluetooth Speaker User Manual

Thank you very much to choose our company and also appreciate greatly for you to purchase and use our Bluetooth Speaker. This file is to help you to use this speaker properly. Please do understand the Bluetooth function of your cell phone or other Bluetooth device before you use our product, such as desktop, laptop etc...

## Safety Standard

1. To ensure safety, please comply with the rules specified in this manual. Strongly recommend you to read and understand this manual before using the speaker.
2. Pay attention to sharp edges, rough surface, metal parts, accessories and packing, so as to avoid any possible injuries.
3. Do not disassemble or repair this product, as this may start a fire, electronic breakdown, or even totally destroy this product, and all these are not included

## Using Guide of Bluetooth speaker

### 1. Power ON/OFF

Push the power button to ON state, the blue LED will sparkle, and the voice prompt of "*Bluetooth music play system has been turned on*" will come out. When you press the Vol. + and Vol. – simultaneously, it can be switched between Chinese and English. Push the power button to OFF state, the blue LED will be off.

### 2. Audio

The voice prompt of "*Bluetooth mode*" will come out automatically once the power button turned ON. Insert the audio cable into the AUX IN port, the voice prompt "*AUX IN mode*" will come out, and then can play the audio signal and the blue LED sparkle slowly. When press the Play/Pause Button  , music can play or pause.

Note: When the speaker play music via Bluetooth or TF card, insert the audio cable, it will turn to play audio signal automatically. Press the "M" button can switch mode among the Bluetooth mode, AUX IN mode and MP3 mode. When switch to Bluetooth mode, the Bluetooth will connected successfully after five seconds,

### 3. Bluetooth

The voice prompt of "*Bluetooth mode*" will come out from speaker after the power button turned ON. And the Bluetooth device can search this product directly, and then the Bluetooth device can display the pairing name: BT Speaker or other customized pairing name in the pairing list. Please confirm and choose the pairing name on your Bluetooth device, the speaker will pair it automatically. If it needs password, please input "0000". After it paired successfully, the voice prompts of "*Bluetooth pairing successfully*" will come out, and then can play Bluetooth Signal.

### 4. Bluetooth Reconnection

4.1 When speaker playing Bluetooth signal, close the Bluetooth function of speaker or Bluetooth device, reopen the Bluetooth function of speaker or Bluetooth device again, the voice prompts "*Bluetooth pairing successfully*" will come out, the Bluetooth device is paused now, press the play

button can play Bluetooth signal(some Bluetooth device needn't this step).

4.2 There is a voice prompts "*The device is disconnected*" after the speaker exceed the RF Range(10m) , then the voice prompts "*Bluetooth pairing successfully*" will come out when the RF range less than 10m(the apart time within 5 minutes ). The Bluetooth device is paused, press the play button can play Bluetooth signal (some Bluetooth device needn't this step).

## 5. TF card

The voice prompts "*Bluetooth mode*" will come out when the speaker has been turned on. Insert the TF card, there is voice prompts "*MP3 mode*", then the speaker will play TF card signal directly, and the blue LED sparkle. When insert the audio cable, the voice prompts "*AUX IN mode*" will come out, it turns to audio signal.

Note: When the speaker play music via Bluetooth, then insert the TF card, it will play TF card signal automatically.

## 6. Play/Pause, Vol.+/Vol.-, Next/Previous

### 6.1 Play/Pause

- 1) When the speaker plays music via Bluetooth or TF card, press  , it will be paused and the blue LED always lighting, press this button  again, it will play music and the blue LED will sparkle.
- 2) When the speaker plays music via Bluetooth signal, and insert the TF card at the same time, the speaker will play music via TF card signal automatically. Long press the play/pause/Bluetooth button, the music play signal can be switched between the Bluetooth and TF card.

### 6.2 Vol.+/Vol.-

When the speaker plays music via Bluetooth or TF card, long press Vol. +, the volume will be up, press it until the volume turn to highest, there is "beep" from the loudspeaker; long press Vol.-, the volume will be down.

### 6.3 Next/Previous

When the speaker plays music via Bluetooth or TF card, short press Vol. +, the speaker will skip to next song; short press Vol.-, it will skip to previous song.

## 7. Charging

It indicates the low-power when play music off and on, please charging.

Make the USB cable connect to micro 5PUSB, and insert it into the micro 5PUSB port, and charging with USB or other USB port 5V. The red LED will be on during the charging, when it is full, the red LED will turn to green.

### Warning:

- Do choose adapter from regular manufacturer.
- Do charge the speaker if it not be used for a long time (over three months).

## 10. Technical Specifications

Parameters	Index
Bluetooth Specification	V2.1+EDR
Bluetooth protocol	HFPV1.5,A2DPV1.2,AVRCPV1.0
RF Range	10 m
Frequency Response	100HZ-20KHZ
Signal-To-Noise	≥60db
Distortion	≤0.1 %
Working voltage/current	3.3~4.5V
Charging voltage/current	USB 5V
Hands-free function	YES
Weight	220g
Product dimension	107.5*37*54.9mm
Playback Time	>3H
Charging Time	2-3H
Battery Capacity	600mA
Loudspeaker Output	4Ω*3W

## 11. Packing List

- 1X            Bluetooth Speaker
- 1X            Micro 5P USB Charge cable
- 1X            3.5\*3.5 Audio Cable
- 1X            User Manual

## 12.Q&A

1) Why BT speaker cannot be powered on?

A:1. Make sure the battery of BT speaker is charged,

2. Check to see that the Power ON / OFF switch is at the ON position. When the speaker is powered on, the blue LED light will blink.

2) Why BT speaker cannot connect to a Bluetooth device?

A: 1. Check that the BT speaker is turned on.

2. Ensure the Bluetooth device is in the effective working range.

3. Delete the BT speaker name entry from your Bluetooth device paired memory list and

re-pair your device with the BT speaker.

4. Check that both your Bluetooth device and BT speaker are not connected to any other devices.

#### **FCC Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation