


# Welcome Guide

Ultra Compact [Bluetooth Keyboard](#)



Ultra Compact **Bluetooth Keyboard**

## Package Contents


- Anker Ultra Compact Bluetooth Keyboard
- 2.3ft Micro USB charging cable
- Welcome Guide

## Product Overview















1. Caps Lock indicator
2. Bluetooth indicator
3. Power indicator
4. Micro USB charging port
5. Power switch

## Shortcut Keys on Different Systems

	iOS	Mac OS	Android	Windows
	N/A	Esc	Return	Esc
	Return to homepage	N/A	Return to homepage	Return to browser homepage
	Brightness down	Brightness down	N/A	N/A
	Brightness up	Brightness up	N/A	N/A
	Search	N/A	Search	Search
	Keyboard display	N/A	N/A	N/A
	Previous track	Previous track	Previous track	Previous track
	Play / Pause	Play / Pause	Play / Pause	Play / Pause
	Next track	Next track	Next track	Next track
	Mute	Mute	Mute	Mute
	Volume down	Volume down	Volume down	Volume down
	Volume up	Volume up	Volume up	Volume up
	Screen lock / Unlock	N/A	Screen lock / Unlock	N/A

## Special symbols (€, £, #) for UK input

	iOS & Mac	Android & Windows
€	 + 	 +  + 
£	 + 	 + 
#	 + 	

For Android and Windows users: please note “@” and “”” are reversed.

### Pairing Instructions

- Flick the power switch to the ON position to turn on the keyboard.
- The keyboard will automatically enter pairing mode. The power status indicator will turn on for 2 seconds and the Bluetooth indicator will start to flash.
- Activate your device’s Bluetooth function and search for the keyboard.
- On your device, click the keyboard name “Anker A7721” to connect. On your laptop find the keyboard and follow the on-screen instructions).

- Once the Bluetooth keyboard has successfully connected to your device, the Bluetooth indicator will turn off.

After pairing for the first time, your device will connect to the keyboard automatically when turning on the keyboard. To pair with a different device, simultaneously press the Fn and Z keys to enter pairing mode, and repeat the above procedure.

Note: In case of connection failure, delete the pairing record from your device and repeat the procedures above.

## **Power Saving Mode**

After being idle for 30 minutes, the keyboard will enter sleep mode. To wake it, press any key and wait for 2 seconds.

## **Charging Instructions**

When battery power is low, the power indicator will turn red, indicating that it is time to recharge the keyboard.

1. Connect the Bluetooth keyboard to a computer or USB adapter using the Micro USB charging cable. The power indicator will show a solid light while the keyboard is charging.
2. Once fully charged, the power indicator will turn green.

## **Federal Communication Commission Interference Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation. Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **Visit iAnker Support to get more detailed information**

Visit our official website at [www.ianker.com/support](http://www.ianker.com/support), and follow the simple instructions to get to the specific product support page. You can get more detailed information from our manual download section concerning

- Product Features
- Product Specifications
- Detailed Pairing Procedure on iOS, Android, Mac OS and Windows

## Warranty

Our company provides customers with a warranty of **18 MONTHS** from the date of purchase.

## Contact Us

For any inquiries or comments concerning our products, please send an email to [support@ianker.com](mailto:support@ianker.com), and we will respond to you as soon as possible. If there is any quality-related issue with the product, you may request a REPLACEMENT OR REFUND by submitting a request form at [www.ianker.com/support](http://www.ianker.com/support).

## Statement

- We're only able to provide after-sales service for purchases made directly from Anker. If you purchased through a different retailer, please contact them for any exchange or refund requests.
- Please note that unauthorized reselling of Anker products is prohibited.



## FCC STATEMENT :

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



1-800-988-7973 (U.S.) Mon-Fri 9:00-5:00 (PST)  
069-9579-7960 (DE) Mon-Fri 6:00-11:00  
03-4455-7823 (日本) Mon-Fri 9:00-17:00

[www.anker.com](http://www.anker.com)  
[support@anker.com](mailto:support@anker.com)