Figure 8

The EUT-Inside View



Figure 9

The EUT-Inside View



Figure 10

PCB of the EUT-Front View




Figure 11 PCB of the EUT-Front View




Figure 12

PCB of the EUT-Back View





Figure 13 PCB of the EUT-Module View



Antenna