


55mm

**Wireless Portable Speaker
With FM Radio**
Model No.: D-83B
FCC ID: 2ABC2-D-83B



MINISO
User Manual

65mm



- ① Previous (long press for Volume Down)
- ② Power /Mode:BLUETOOTH/OFF/AUX
- ③ Phone/Play/Pause
- ④ Next (long press for Volume Up)
- ⑤ Led Light
- ⑥ Charging/AUX-IN
- ⑦ TF Card Slot
- ⑧ DC 5V Slot
- ⑨ Reset (Short press for power off)

Thank you for using the Mp3 Player produced by company to allow you to easily experience the product. We randomly with detailed instructions for using. You can get from the introductions of the products concerned. The use of knowledge of instructions carefully. So that you can use the device and hope the majority of user understanding. If any typographical errors or translation errors involved in the content subject to change without notice.

Product Overview

This device is a beautifully designed, portable Bluetooth stereo mini speaker. High performance explosion-proof sound amplifier chip. Ultra-low power consumption, super-low-frequency dynamics, bass-rich, flexible, achieve a more shocking extremely overweight bass effect. Can be directly connected with a PC ,Laptop,MP3/MP4,MOBLIEPHONE and other products connection.Super Bluetooth receiver functions. It is the best companion for Bluetooth mobile phone and other Bluetooth enabled products.

Features

- 1.Bluetooth function
- 2.Memory function, Resume Playback

- 3.Built-in lithium battery, environmentally friendly and practically.
- 4.Using high-fidelity speakers, make the sound more natural and delicately.
- 5.Audio input interface: standard 3.5mm Aux in jack, can be used for computer speakers, Mobile audio and so on.
- 6.Built-in microphone, Can be achieved mobile voice speakerphone
- 7.Support MP3 music format decode.

Key basic definition:

- 1." M / ⏻ " : Power ON/OFF unit.
- 2." 📞 " : Answer/Hang Up the calling, Play/Pause
- 3." ⏪ " : Switch to previous song, Volume down
- 4." ⏩ " : Switch to next song, Volume up
- 5. "Reset" : Power reset.

Key basic operation:

Boot up: Long Press " M / ⏻ " for three seconds and release the button, after a second or so the indicator lighted up to express boot up.
Short press "Reset" can power off.

Shutdown: Long press "M/⏻" for three seconds and release the button, then after a second or so the indicator light to light up to express shutdown.

Short press " 📞 "can play, pause ,Bluetooth play and switch to answer/Hang up the phone functions.

During playback, short press " ⏪ "key can select the previous song, short press " ⏩ " key can select the next song.

Volume adjustment:

During playback, long press "+ (" key, the system can increase the volume, long press " ⏪ "key, the system can decrease the volume.

Tip Lights:

In Bluetooth mode it flash the blue lights. Read TF card flashing green lights, Audio input modes, the green lights will long bright.
After the device boot up (TF card is not inserted) defaults to Bluetooth mode state;Insert TF card, the system will switch to TFcard mode playback status automatically.

FM radio scan and save

Put the 3.5mm audio cable line as the antenna. Press "M/⏻" button to the mode of radio automatically. Press the button " 📞 ", it can scan and saved the available frequency automatically. After searching, you can select the saved channel by " ⏪ " / " ⏩ " + (" button. If you don't want to auto search the button, don't press the " 📞 " button, long press " ⏪ " / " ⏩ " + (" button can help to search the previous/next available FM frequency.

Charge to use

The device designed with charge protection circuit, can be connected to computer or charger prolonged and fully charged about 5hours.Each time the life time of the battery will be different because of the volume size when playing.

Troubleshooting

- 1. Automatically shut down: Low battery, charging for two hours before using.
- 2. Play automatically shut down: Low battery, charging for two hours before using
- 3. Can not play music:

The storage path of MP3 music files can not be identified by the player. Please store your files in the root directory of removable devices.

- 4. The speaker no sound: Whether is the volume turned on?
- 5. Connected to the computer no sound: The computer interface connection error. Please select the correct audio output interface of the computer.
- 6. The headphone hole of the device built-in a reset, in the case of exception crash, you can light press the button by the elongated flat stick.

Tips:

- 1. If you want to use Bluetooth function, pls connect firstly. Turn on speaker and enter pairing status. If you use mobile phones: Initiate Bluetooth setting, Searching for Bluetooth devices " MINISO D-83B." Then paring without any code.

2. It is suitable for all kinds of mobile phone. Bluetooth adapter or Bluetooth player with Bluetooth function.

Technical Specifications:

Bluetooth Standard: 3.0
Transmission Distance: 10 Meters
Output Power: 3W+3W
Frequency Effect: 100Hz-18KHz
Machine Speaker: (Φ 40mm 4Ω 3W)
Input Power: Direct-current DC 5V
Maximum Current Consumption: 1200mAh
Audio signal input interface: Standard Φ 3.5mm Aux in jack (stereo).

Packing Accessories:

- 1. Host : One PC
- 2. Manual :One PC
- 3. Aux in Cable :One PC
- 4. Charging Cable: One PC

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.