



Product Overview
This device is a new fabric design, portable Bluetooth speaker. High performance explosion-proof sound amplifier chip. Ultra-low power consumption, super-low-frequency dynamics, bass-rich, flexible, achieve a more shocking extremely overweight bass effect. It could use TF card to play music directly, also can be directly connected with a PC, laptop, MP3/MP4, mobile phone etc. It is the best choice for Bluetooth mobile phone and other Bluetooth enabled products

Features
1. Bluetooth function
2. Memory function, Resume playback
3. Built-in lithium battery, environmentally friendly and practically
4. Using high-fidelity speakers, make the sound more natural and delicately
5. Audio input interface: 2 in 1 charging cable&aux in cable (Option). Standard 3.5mm Aux in jack, can be used for computer speakers, Mobile audio and so on.
6. Built-in microphone, support mobile phone hands free calls

7. Support MP3 music format decode.

Key basic definition
1. ⏻ Power On/OFF/Mode
2. 📞 Answer/Hang up the calling, Play/Pause
3. ⏪ Switch to next song/volume up
4. ⏩ Switch to previous song/Volume down

Key basic operation
Power on ⏻ : Long press power key to power on, the blue indicator lights up and beep
Shutdown ⏻ : Long press power key to power off
Short press ⏻ can change mode
Short press 📞 can play/pause the music
Bluetooth play and switch to answer/hang up the phone function
During playing back, short press ⏩ key can select the previous song, short press ⏪ key can select the next song

Bluetooth Mode
To ensure you get the best performance from your Bluetooth device. Keep the distance between your Bluetooth and device as small as possible and avoid

placing your body or other objects in signals path

1. Long press the Power key for 3 seconds. You will heard the remind sound and blue light flash fast
2. Turn on the Bluetooth function of your device. You will find the Pairing Name: "MINISO D9"
And click on it to make connecting. If it is required the pass code please input "0000" and pairing
3. Press shortly the button or it will go to song selection "Next or Previous". Long press or it will be Volume up or Volume down
4. If there is a call coming the music will be mute automatically and you can hear a beep sounds. After the call ended the music will auto play again

Hand Free Assistant Function
Make sure the Bluetooth speaker is pairing with your mobile phone as well
1. Making a calling
To dialing a number from your cell phone the music will be paused until hanging up. Double press the 📞 button you can call the last one phone number
2. Answer a call
Press the 📞 button to answer when there is a incoming calling. Music will be paused until

hanging up. Enjoy your hands free call with this Bluetooth speaker. Micro SD Music Playing (with Micro SD card slot)
Insert the Micro SD(TF) into the card slot it will play the music automatically. Short press button will Pause the music playing. Short press +⏪ or ⏩ button to select "Next or Previous". Long press +⏪ or ⏩ it will be Volume up or Volume down
Under the Bluetooth mode if you want to play TF card's music that you have inserted TF card into card slot. You can press shortly ⏻ button to change mode.

AUX-IN Mode
Power on connect the 2 in 1 cable to Aux-in(DC 5V) port and plug other side 3.5mm connector to your music device. It will transfer music to the AUX-IN mode directly

Volume adjustment
During playback, long press +⏪ key the system can increase the volume
Long press ⏩ key the system can decrease the volume

Charge to use
The device equipped with charge protection circuit, can be connected to computer or charger prolonged and fully charged about 3~4hours till charging red light. Each time the life time of the battery will be different because of the different volume when playing.

Trouble shooting
1. Automatically shut down: Low battery charging for two hours before using.
2. Play automatically shut down: Low battery charging for two hours before using.
3. Can't play music: The storage path of MP3 music files can't be identified by the player. Please store your files in the root directory of removable devices.
4. The speaker no sound: Whether is the volume turned on?
5. Connected to the computer no sound: The computer interface connection error. Please select the correct audio output interface of the computer.
6. Keys has no function or function fault: Shutdown and try it again.

7. If it has some problems when you use this Bluetooth speaker you can switch off and turn on again. The problems will be solved.

Technical Specifications
Bluetooth Standard: V4.1
Transmission Distance: 10Meters
Output Power: 3W+3W
Frequency Effect: 180Hz ~ 20KHz
Machine Speaker: Φ40mm 4Ω 3Wx2
Operating temp: -20°C~50°C
Input Power: Direct-current DC 5V
Built-in Battery: 1200mAh 3.7V
Aux-in interface: same with charge port

Packing Accessories
1. Host : One PC
2. Manual : One PC
3. Stand holder : One PC
4. Charging Cable : One PC
00674BH24A-I30

www.miniso.jp Designed by Japan, Made in China

株式会社 名創優品産業
〒104-0061 東京都中央区銀座3-10-7
銀座京屋大厦7楼
MINISO INDUSTRIES CO., LTD.
GINZA KYOYA BLDG. 7F
3-10-7 GINZA, CHUO-KU, TOKYO 104-0061, JAPAN

CE FC RoHS METRO NOM EAC CASP

MINISO JAPAN

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.