

AIRSEE®

USER MANUAL

LED Pool Chlorine Floater Lights



Model: AS-2301

www.airseelife.com

AIRSEE®

General Description

AIRSEE upgrade IP68 waterproof pool light with chlorine tablet dispenser not only can decorate your swimming pool but also can be used as a chlorine tablet dispenser to clean and maintain pool water safe and sanitary. It can also remove the dispenser and be used as a color-changing night light for your pool, you can also switch lights remotely, very convenient. Perfect glow balls led lights outdoors and indoors for swimming pool, pond, backyard, fountain, garden, pathway, lawn, stage, or home for holidays, festivals, parties, weddings, and more decorations—nice gift idea for your kids, family, and friends.


Package Included



1. LED Floating Light



2. Adjustable Chlorine Tablet Dispenser




3. Remote Control



4. Charging Port


Product Details Diagram



Feature

Light Material:	PVC
Dispenser Material:	ABS
Power:	12W
Input:	DC 5V/2A
Color:	RGB (16 colors)
Color Changing:	Yes
Remote Control:	Yes
Mode:	3 color change modes (Flash, Fade, Smooth)
Light Brightness Adjustment:	5Gear
Power On/Off:	Press and hold for 2 seconds
Light Size:	10.14 x 4.7 inch
Dispenser Size:	3.94 x 5.3 inch
Timer Settings:	4H/8H/12H
Remote Control Battery Capacity:	2000mAh
Remote Control Battery Type:	CR2025

How to Use the Remote Control of the Light



Note
The control distance of the remote control is ≒ 30M(Without obstacle).

Remote control battery replacement steps:



1. Snap the slit and push it to the right



2. Pull out at the same time



Please confirm the positive and negative direction of the battery before putting it into the remote control to avoid jamming and not being able to use the remote control normally.

How to Use Chlorine Tablet Dispenser



1. Twist to the left to separate the disinfection box from the lamp



2. Fill 3 Inch of chlorine tablets



3. Check that the seal is aligned and tighten to the right



4. Adjustment of flow vents

Operate Step

1. Charge the battery and cover the charging port tightly.
2. Long press the bottom button of the light for 2s, the light will be on.
3. Use the remote control to adjust the colour and mode of the light.
4. Press and hold the bottom button of the light for 2s, the light will turn off.

Light Runtime & Charging Time

White Light Runtime: 35H

RED Light Runtime: 60H

Charging Time: 2.5H

The red light is always on when charging, the green light is always on when fully charged, and the red light is flashing when the power is low.



Before charging, please make sure the charging port is dry without water.

Note: In the discharge mode, the slow flashing red light is an indication that the product is running out of power and needs to be charged in time.

No matter in what state, as long as the floating light is charged, the machine will automatically shut down first, please turn on the power button again before the next use.

Warm Tips:

1. After fully charged, please turn on the bottom switch first before using the remote control to operate.
2. If you do not use the light for a long time, it is recommended to turn off the power at the bottom of the light to avoid the battery has been discharged, such as not charged in time, it is easy to cause the light to break down.
3. Please do not overcharge, over discharge, fully charged to unplug the power in time, prompting low power needs to be charged in time, do not wait until the automatic shutdown and then charge, and do not use while charging.

AIRSEE®

4. Please use the correct charger charging, to ensure that the charger or rechargeable battery output voltage and current is 5V/1A or 5V/2A.



Using the wrong charger can easily cause fire or explosion, to avoid the danger, please pay attention to safety.

Attentions-Troubleshooting

Product does not work or does not charge

1. Check that the plug at the AC end of the adapter is not loose or has poor contact.
2. Check if the DC output of the adapter is well connected to the DC socket of the product.
3. Long press the button and it does not turn on, the battery may be dead, charge the machine first first.
4. The remote control does not work, check if the battery on the remote control is dead, you can replace the battery and try to operate again.

Warranty and Customer Service

AIRSEE offers 6 months limited warranty on quality-related issues. Please apply for your extra 6 months warranty extension and download the instruction manual in other languages by registering on www.airseelife.com if needed.

Thank you for purchasing from AIRSEE.
You are welcome to share your experience after receiving the product.
Please contact us for any technical support if needed.

Declaration of conformity

This product complies with the radio interference requirements of the European community. Hereby, **Shenzhen Nanjiakexinxi youxiangongsi** declares that the product is in compliance with the essential requirements and other relevant provisions of RE Directive 2014/53/EU. You can find the Declaration of Conformity on www.airseelife.com.

FCC Statement

This device complies with Part 15 of the FCC Rules.

1. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

AIRSEE®

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

✉ service@airseelife.com

🌐 www.airseelife.com

Discover a wonderful life!