


Mini Bluetooth Speaker #2717

USER MANUAL




Introduction

Thank you for choosing our Bluetooth speaker. This manual will help you to operate the Bluetooth speaker, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Bluetooth speaker. For example, the computer's Bluetooth functionality.

Safety rules:


1. In order to ensure safety, please observe the rules mentioned in this specification. We would strongly recommend that you read this manual before using this Bluetooth speaker.
2. Be more wary of any edges, uneven surfaces, metal parts, accessories and packaging. In order to prevent any possible injury or damage.
3. Please do not dismantle, repair this Bluetooth speaker. These actions may cause fire, electric shocks, complete breakdown of this Bluetooth speaker. All of which are not in the warranty.
4. Please do not use any oil or volatile liquid to clean the Bluetooth speaker.
5. Please do not use the Bluetooth speaker in a hazardous location.

Packing list



Product Appearance Introduction

- ①. Charging interface
- ②. Switch button
- ③. AUX interface



Technical specifications

Bluetooth Speaker Model:	#2717
Bluetooth Specification:	3.0
Bluetooth Profile:	HFP A2DP
Range:	≤10m
Frequency Response:	100Hz-20KHz
Loudspeaker Output:	3W
Signal-To-Noise:	≥75dB
Distortion:	≤1.0%
Playback Time:	2-3 hours
Charging Time:	2 hours
Dimension:	62*62*51mm
Weight:	94g

Pairing to Mobile phone or other device

In order to use the Bluetooth speaker, you must first pair your Bluetooth speaker with your phone or computer. If the phone is paired with Bluetooth speakers and over, in the effective distance, mobile phones and Bluetooth speakers will automatically pair. If you are using a computer, you only need to select the audio connection on the line.

1) Paired with your phone and using:

- Turn on your phone and ensure its Bluetooth function is switched on.
- Turn on the Bluetooth speaker and go into pairing mode.
- Please search for Bluetooth device "#2717" according to the manual of your phone.
- After a few seconds, the phone will list the device as a discoverable device. Select it and follow your phone's instructions to select this pairing.
- Your phone will confirm the pairing.
- Finally, select to connect with the device from your phone. You can open the phone player to play music, watch movies, play games. All sounds are heard from the Bluetooth speakers.

2) Charging your Bluetooth Speaker:

Bluetooth speaker using a more generic "DC Micro" charging interface, with icons on the product logo, the product provides a charging cable which can turn "USB" to "DC Micro". Of course, you can also choose to output interface with "DC Micro" adapter, but please note that you must choose the regular manufacturer's DC output voltage 5V adapter. Ensure that for the first time you use your Bluetooth speaker charging at least 6 hours. The method is to use your charger or charging cable DC output plug into "DC Micro". While charging, the red LED light constantly. When charging is completed, the LED turns off.

3) Put the audio cable into the AUX port to connect the product to a computer or mobile audio output port, which can be used as an external speaker.

Warning

You must select a qualified charger from a regular manufacturer. You must charge the Bluetooth speaker if it has been not used for more than 12 months.

Service and Support

If your device is not performing as it should, please take it to your local service providers or dealer for service.

FAQ:

1) Why is there no sound even when the speaker is powered on?

A: Make sure the battery is being charged up to 4 hours for the first time using. The LED is lit when it starts charging.

2) There is no sound when playing the speaker.

A: Check that the playback device and the Bluetooth speaker whether to establish a good connection, if there is no connection, please reconnect. Also ensure the speaker device is paired and connected with your target phone or other master device.

3) How to identify if the Bluetooth speaker has been fully charged? When the red charging indicator automatically turns off, which means that the Bluetooth speaker has been fully charged.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.