

55mm

70mm

Light up dock wireless earbuds




FCC ID: 2ABHA0120

Made in china

GETTING STARTED

- ① Type-C charging port
- ② Charging Case RGB indicators
- ③ Left earbud LED indicator
- ④ Left control touch button
- ⑤ Right earbud LED indicator
- ⑥ Right control touch button

Left Earbud/Right Earbud
Pause/Play/Answer Call/End Call



CHARGING YOUR CASE

- Charging the charging case: It will request 1-2 hours to complete the charging. The charging case RGB indicator will be lit and turn off after fully charged
- Do not charge longer than suggested time. Do not charge overnight.

CHARGING YOUR EARBUDS



Insulating trip

- Please remove the insulating trip before charging earbuds.
- Place Right and Left Earbuds in charging case
- Charging case RGB indicator (2) will be illuminated and the earbud LED indicators (3,5) will illuminate Red, indicating that the earbuds are charging properly. When Earbuds LEDs (3,5) turns off, earbud batteries are fully charged.

MONO MODE (SINGLE EARBUD USE)



- Remove earbud from charging case
- Once earbud is powered on, it will automatically proceed to **PAIRING**


STEREO MODE (DUAL EARBUD USE)



- Remove both earbuds from charging case and close each other
- Earbuds will automatically link together after a few seconds, and earbuds will have a tone. One earbud will flash red and blue, another earbud will flash blue only.
- Once Earbuds are linked together you may proceed to pairing with your mobile device.

Front

PAIRING



— Search for pairing name "CPP-6743" and select it on your mobile phone. Once the earbuds are successfully paired, a notification will sound.

— Now you can enjoy your wireless Earbuds.

*Note: 1. Once earbuds have been initially paired successfully with your mobile device, they will automatically pair the next time.

OPERATING EARBUDS

Model: CT04044
Item No.: CPP-6743
Capacity(Cradle): 200mAh / 3.7V (0.74Wh)
Capacity(Earbuds): 30mAh / 3.7V (0.11Wh)
Input of earbuds: 5V / 60mA
Input of Cradle: 5V / 200mA (Type-C)

Function	Action	Button
Pause/start music playback	Short Press	Left / right
Volume up	Double press	Right
Volume down	Double press	Left
Select previous track	Long press 2 seconds	Left
Select next track	Long press 2 seconds	Right
Answer/End call	Short press	Left / right
Reject call	Long press	Left / right

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Back