


JBP TEST SETUP PHOTOS

B.1 Radiated Field Strength Measurement




30 MHz-1 GHz (USB Test Mode)




Above 1 GHz (USB Test Mode)

AY0520 Charger



30 MHz-1 GHz (Camera Test Mode)




Above 1 GHz (Camera Test Mode)

ONE0520 Charger




30 MHz-1 GHz (Camera Test Mode)




Above 1 GHz (Camera Test Mode)

B.2 Conducted Emission




USB Test Mode

AY0520 Charger



Camera Test Mode



Camera Test Mode