





















## Band Edge

Condition	Mode	Frequency (MHz)	Antenna	Max Value (dBc)	Limit (dBc)	Verdict
NVNT	ac20	5260	Ant1	-38.41	-27	Pass
NVNT	ac20	5320	Ant1	-38.96	-27	Pass
NVNT	ac20	5260	Ant2	-39.21	-27	Pass
NVNT	ac20	5320	Ant2	-39.04	-27	Pass
NVNT	ac20	5260	Ant3	-38.46	-27	Pass
NVNT	ac20	5320	Ant3	-38.98	-27	Pass
NVNT	ac20	5260	Ant4	-40.17	-27	Pass
NVNT	ac20	5320	Ant4	-40.08	-27	Pass
NVNT	ac40	5270	Ant1	-38.96	-27	Pass
NVNT	ac40	5310	Ant1	-38.32	-27	Pass
NVNT	ac40	5270	Ant2	-38.26	-27	Pass
NVNT	ac40	5310	Ant2	-37.12	-27	Pass
NVNT	ac40	5270	Ant3	-39.42	-27	Pass
NVNT	ac40	5310	Ant3	-38.84	-27	Pass
NVNT	ac40	5270	Ant4	-40.82	-27	Pass
NVNT	ac40	5310	Ant4	-39.36	-27	Pass
NVNT	ac80	5290	Ant1	-38.69	-27	Pass
NVNT	ac80	5290	Ant2	-38.32	-27	Pass
NVNT	ac80	5290	Ant3	-38.71	-27	Pass
NVNT	ac80	5290	Ant4	-39.05	-27	Pass
NVNT	ax20	5260	Ant1	-38.58	-27	Pass
NVNT	ax20	5320	Ant1	-38.76	-27	Pass
NVNT	ax20	5260	Ant2	-38.61	-27	Pass
NVNT	ax20	5320	Ant2	-38.52	-27	Pass
NVNT	ax20	5260	Ant3	-39.11	-27	Pass
NVNT	ax20	5320	Ant3	-38.53	-27	Pass
NVNT	ax20	5260	Ant4	-39.75	-27	Pass
NVNT	ax20	5320	Ant4	-39.03	-27	Pass
NVNT	ax40	5270	Ant1	-38.05	-27	Pass
NVNT	ax40	5310	Ant1	-39.03	-27	Pass
NVNT	ax40	5270	Ant2	-38.05	-27	Pass
NVNT	ax40	5310	Ant2	-38.85	-27	Pass
NVNT	ax40	5270	Ant3	-39.03	-27	Pass
NVNT	ax40	5310	Ant3	-38.59	-27	Pass
NVNT	ax40	5270	Ant4	-40.98	-27	Pass
NVNT	ax40	5310	Ant4	-39.58	-27	Pass
NVNT	ax80	5290	Ant1	-39.34	-27	Pass
NVNT	ax80	5290	Ant2	-38.02	-27	Pass
NVNT	ax80	5290	Ant3	-38.25	-27	Pass
NVNT	ax80	5290	Ant4	-40.13	-27	Pass

NVNT	ac20	5260	Ant5	-35.33	-27	Pass
NVNT	ac20	5320	Ant5	-37.06	-27	Pass
NVNT	ac20	5260	Ant6	-36.89	-27	Pass
NVNT	ac20	5320	Ant6	-36.19	-27	Pass
NVNT	ac20	5260	Ant7	-38.55	-27	Pass
NVNT	ac20	5320	Ant7	-38.1	-27	Pass
NVNT	ac20	5260	Ant8	-40.12	-27	Pass
NVNT	ac20	5320	Ant8	-39.31	-27	Pass
NVNT	ac40	5270	Ant5	-37.51	-27	Pass
NVNT	ac40	5310	Ant5	-37.17	-27	Pass
NVNT	ac40	5270	Ant6	-37.28	-27	Pass
NVNT	ac40	5310	Ant6	-35.43	-27	Pass
NVNT	ac40	5270	Ant7	-38.22	-27	Pass
NVNT	ac40	5310	Ant7	-37.41	-27	Pass
NVNT	ac40	5270	Ant8	-39.71	-27	Pass
NVNT	ac40	5310	Ant8	-39	-27	Pass
NVNT	ac80	5290	Ant5	-36.93	-27	Pass
NVNT	ac80	5290	Ant6	-35.79	-27	Pass
NVNT	ac80	5290	Ant7	-37.44	-27	Pass
NVNT	ac80	5290	Ant8	-40.3	-27	Pass
NVNT	ax20	5260	Ant5	-37.32	-27	Pass
NVNT	ax20	5320	Ant5	-37.57	-27	Pass
NVNT	ax20	5260	Ant6	-36.5	-27	Pass
NVNT	ax20	5320	Ant6	-36.74	-27	Pass
NVNT	ax20	5260	Ant7	-38.23	-27	Pass
NVNT	ax20	5320	Ant7	-36.37	-27	Pass
NVNT	ax20	5260	Ant8	-39.89	-27	Pass
NVNT	ax20	5320	Ant8	-39.54	-27	Pass
NVNT	ax40	5270	Ant5	-37.14	-27	Pass
NVNT	ax40	5310	Ant5	-37.03	-27	Pass
NVNT	ax40	5270	Ant6	-37.56	-27	Pass
NVNT	ax40	5310	Ant6	-35.09	-27	Pass
NVNT	ax40	5270	Ant7	-37.93	-27	Pass
NVNT	ax40	5310	Ant7	-35.52	-27	Pass
NVNT	ax40	5270	Ant8	-39.84	-27	Pass
NVNT	ax40	5310	Ant8	-38.52	-27	Pass
NVNT	ax80	5290	Ant5	-37.2	-27	Pass
NVNT	ax80	5290	Ant6	-35.93	-27	Pass
NVNT	ax80	5290	Ant7	-37.78	-27	Pass
NVNT	ax80	5290	Ant8	-39.62	-27	Pass































































