

# **Product name: Relocatable Power Taps with Surge Protector** Model name: DR-1710

# Manual

Smart Life Smart Living




#### 1.Login

●●●●○ 中国移动 令	11:27 PM	L @ 7 O \$4
<b>&lt;</b> Back	Login	
Region	Un	nited States +1 >
Mobile numbe	r/E-mail	
Password		O
Sign in with SMS		Forgot password

#### Sign in with social media account




2.Register






1.Add



#### 2.Set Wi-Fi




#### **Add Devices**


### 3.Connect

#### 4.Success

Cancol	●●●●● 中国移动 令	11:21 PM	L @ 7 O ¥
Cancel		Add Device	C
Connecting now	Succes	sfully add 1 o	devices
4%	Smart Plug-f	677	<u>_</u>
Make sure your phone and device are as close to your router as possible.			
<ul> <li>Searching for device</li> <li>Registering device to the cloud</li> <li>Initializing your device</li> </ul>			
	S	hare with famil	У
		Done	








**Power strip** 

## 2.Wi-Fi Power strip



#### 3.Menu

●●●●● 中国移动 夺	11:22 PM	L @ 7 Ö	• 4
<b>&lt;</b> Back	More		
Modify Device Nam	ne	Smart Plug-f677	>
Add Sharing			>
Device Info			>
Create Group			>
Use Echo			>
Send Feedback			>
Check for Firmware	e Update		>

#### Remove Device

Restore Manufacture Defaults



•••••	9:41 AM	100% <b>——</b> •
<b>〈</b> Back	Timer	
Programma	ble timer	>
Countdown	timer	>
Vacation		>
Security		>

2.Progr	(
---------	---

•••••	
<back pr<="" th=""><th>r (</th></back>	r (
Timer accuracy is -/+	-
AM 06:00 Everyday Switch:On	
<b>PM 07:00</b> Monday, Tuesday, Sun Switch:Off	IC
PM 09:00 Monday Switch:Off	

Timer

#### ammable Timer 3.Add Timer

9:41 AM	100% 💼 I
ogrammable Timer	
30 seconds	
day	
Add Timer	

●●●●○中国移动	Ŷ	11:22 PM	6 🕀 🕇 1	D B - +
<b>&lt;</b> Back	A	dd Timer		Save
		06	58	
		07	59	
	AM	08	00	
	PM	09	01	
		10	02	
		11		
Repeat			Only O	nce >
				<b>a</b>
Switch				On >



#### 4.Repeat

●●○○○ 中国电信 🗢	5:36 PM	֎ ፇ∦ \$ 50% ■_•
<b>〈</b> Back	Repeat	
Sunday		×
Monday		<ul> <li>✓</li> </ul>
Tuesday		
Wednesday		
Thursday		
Friday		
Saturday		

#### 5.Switch

●●○○○ 中国电信 🗢	•	5:37 PM	• 7 *	50% 🔳
<b>〈</b> Back	A	dd Timer		Save
			57 58	
		07	59	
	AM	08	00	
	PM	09	01	
		10	02	
Repeat			Every	day >
Switch				On >
		Switch		
		On		
		Off		
Canc	el		Confirn	n



•••••	9:41 AM	100% 📖
<b>〈</b> Back	Timer	
Programmab	le timer	>
Countdown t	imer	>
Vacation		>
Security		>

#### 2.Countdown Timer

••••		9:41 AM	100% 💼 -
<в	ack Coun	Countdown Timer	
	Hour	Minute	
		18	
		19	
	0	20	
	1	21	
	2	22	
		OK	



$\mathbf{O}$	$\mathbf{X}$	$\sim$	$\sim$ ti
$\angle$	. V	ac	ati

•••••	9:41 AM	100%
<b>〈</b> Back	Timer	
Programmab	le timer	>
Countdown t	imer	>
Vacation		>
Security		>

•••••	
	NIGHT:
$\checkmark$	DAY: 9a
$\checkmark$	ALL DAY

ion

9:41 AM	100% <b>——</b> •
Vacation	Keep
6pm–11pm	
)am–11pm	
Y	

#### 3. Security


••••• ?	9:41 AM		100% <b>—</b> •	
<	Security		Keep	
	Opening time	Э		
Dec 6th	Tuesday	20	58	
Dec 7th	Wednesday	21	59	
	Today	22	60	
Dec 8th	Friday	23	01	
Dec 9th	Saturday	24	02	
	Closing time			
Dec 6th	Tuesday	20	58	
Dec 7th	Wednesday	21	59	
	Today	22	60	
Dec 8th	Friday	23	01	
Dec 9th	Saturday	24	02	
	OPEN			


OPEN





#### 1.Devices List













Timer

Socket

## 2.Wi-Fi Socket

#### 3.Menu

•	●●●● 中国移动 🗢	11:22 PM	l 🕑 7 🏵 🗍 🗖	<b>•</b>
•	<b>〈</b> Back	More		
	Modify Device Nam	е	Smart Plug-f677	>
	Add Sharing			>
	Device Info			>
	Create Group			>
	Use Echo			>
	Send Feedback			>
	Check for Firmware	Update		>

#### **Remove Device**

Restore Manufacture Defaults



•••••	9:41 AM	100% <b>——</b> •
<b>〈</b> Back	Timer	
Programma	ble timer	>
Countdown	timer	>
Vacation		>
Security		>

2.Progr	(
---------	---

•••••	
<back pr<="" th=""><th>r (</th></back>	r (
Timer accuracy is -/+	-
AM 06:00 Everyday Switch:On	
<b>PM 07:00</b> Monday, Tuesday, Sun Switch:Off	IC
PM 09:00 Monday Switch:Off	

Timer

#### ammable Timer 3.Add Timer

9:41 AM	100% 💼 I
ogrammable Timer	
30 seconds	
day	
Add Timer	

●●●●○中国移动	Ŷ	11:22 PM	6 🕀 🕇 1	D B - +
<b>&lt;</b> Back	A	dd Timer		Save
		06	58	
		07	59	
	AM	08	00	
	PM	09	01	
		10	02	
		11		
Repeat			Only O	nce >
Switch				On >



#### 4.Repeat

●●○○○ 中国电信 🗢	5:36 PM	֎ ፇ∦ \$ 50% ■_•
<b>〈</b> Back	Repeat	
Sunday		×
Monday		✓
Tuesday		
Wednesday		
Thursday		
Friday		
Saturday		

#### 5.Switch

●●○○○ 中国电信 🗢	•	5:37 PM	• 7 *	50% 🔳
<b>〈</b> Back	A	dd Timer		Save
			57 58	
		07	59	
	AM	08	00	
	PM	09	01	
		10	02	
Repeat			Every	day >
Switch				On >
		Switch		
		On		
		Off		
Canc	el		Confirn	n



•••••	9:41 AM	100% 📖
<b>〈</b> Back	Timer	
Programmab	le timer	>
Countdown t	imer	>
Vacation		>
Security		>

#### 2.Countdown Timer

••••		9:41 AM	100% 💼 -
<в	ack Coun	tdown Timer	
	Hour	Minute	
		18	
		19	
	0	20	
	1	21	
	2	22	
		OK	



$\mathbf{O}$	$\mathbf{X}$	$\sim$	$\sim$ ti
$\angle$	. V	ac	ati

•••••	9:41 AM	100%
<b>〈</b> Back	Timer	
Programmab	le timer	>
Countdown t	imer	>
Vacation		>
Security		>

•••••	
	NIGHT:
$\checkmark$	DAY: 9a
$\checkmark$	ALL DAY

ion

9:41 AM	100% <b>——</b> •
Vacation	Keep
6pm–11pm	
)am–11pm	
Y	

#### 3. Security

••••• ?	9:41 AM		100% <b>—</b> •
<	Security		Keep
	Opening time	Э	
Dec 6th	Tuesday	20	58
Dec 7th	Wednesday	21	59
	Today	22	60
Dec 8th	Friday	23	01
Dec 9th	Saturday	24	02
	Closing time		
Dec 6th	Tuesday	20	58
Dec 7th	Wednesday	21	59
	Today	22	60
Dec 8th	Friday	23	01
Dec 9th	Saturday	24	02
	OPEN		

OPEN





1.Scene	S		2.Add So
●●●●○中国移动 令	11:22 PM Scenes	€	●●●●○ 中国移动 令 Cancel E
Home		Perform	Home
Out		Perform	Step 1: Add condit
			No condition ye
			Step 2: Add task
			Switch : On
Devices	Scenes	Profile	

cene

11:23 PM 🕒 🕀 🕂 🏵	* 💶 +
Edit Scene	Save
ndition	Ð
on yet (can be added manually)	
sk	•
ıg-f677	
•	/
Delete	

#### 3.Condition

●●●●○中国移动 🗢	11:23 PM	C @ 7 O \$ 💶 4
<b>〈</b> Back	Select condition	ı
Select condition for	or task	
temperature		>
humidity		>
weather		>
PM2.5		>
AQI		>
device		>




#### 1.Profile 2.Profile Edit ●●●●● 中国移动 🗢 ●●●●● 中国移动 🗢 **€** ● **1** ● **\* ■** • **f** 11:23 PM **く** Back Profile Settings daniel **Profile Picture** $\geq$ 104@abc.com Nickname 🗇 🛛 Use Echo > Phone Number $\bigcirc$ Experience Center > 📄 Scan QR Code > Change Login Password $\ll$ Device Sharing > Pattern Unlock 🖂 Message Center $\geq$ ? FAQ >Change Pattern Password 😳 Feedback $\geq$ $\bigcirc$ About > $\bigcirc$ 0

Profile

Scenes

Devices

#### **Profile**





#### **Devices Sharing / Feedback / Settings**

1.My Sharings				
●●●●● 中国移动 🗢	11:23 PM	L @ 7 Ø \$ 🔳	<b>_</b> • <del>/</del>	
<b>&lt;</b> Back	My Sharings			
Sent		Received		
USERS BELOW AR	E SHARING YOUR I	DEVICES		
Daniel		100@abc.com	>	

#### 2.Add Sharing

●●●●● 中国	国移动 <b>令</b> 11:23 PM	l @ 7 0 * 🔳
Cancel	Device Sharii	ng
	Share New Devi	Start
Set Up	Sharing Devices	
Ļ,	Smart Plug-f677	





## 3.Add Feedback


)• <i>+</i>	●●●●○中国移动 令			
	Cancel N	Write Your Feed	back	Submit
>	Please descr	ibe your issue		
)				
				240

### 4.Settings

●●●●● 中国移动 🗢	11:23 PM	6 🕑 7 0
<b>&lt;</b> Back	Settings	
SOUNDS AND VIBR	ATION	
Sound		
Vibrate		(
MESSAGE NOTIFIC	ATION	
App Message No	otification	
Clear Cache	7.77	







#### **FCC Statement:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

- —Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.