

Contents

1. Instruction Before Use

- 1.1. Install SIM Card
- 1.2. Charging Method

2. Instruction of Buttons

3. Starter

- 3.1. Standby Interface
- 3.2. How to Use Dialer


4. Menu

- 4.1. Music Player
- 4.2. Record
- 4.3. Bluetooth
- 4.4. Contacts
- 4.5. Message
- 4.6. Call History
- 4.7. Setting
- 4.8. Calculator
- 4.9. Anti-Lost
- 4.10. Shortcut Key

1.1 Install SIM Card


The SIM card slot is on the right side of the back of Talkase, first remove the cover as instructed, then put the SIM card into the slot, close the cover, the installing is done.

Only support micro SIM card.




1.2 Charging Method

Let the four metal contacts of charging slip correspond to the four of Talkase, then press the charging clip to ensure it is tightly attached to the back of Talkase, connect the computer using USB cable or an adapter for charging. Take out the clip from down to up in vertical direction, sliding way is not suggested for protecting the four contacts in charging clip.



Wrong way of installing
charging clip




Slide up and down
is not allowed

Right way of installing
charging clip



Install from
vertical direction

Instruction of Buttons



3.1. Standby Interface

Long press the power key to start up, standby interface show the internet signal, Battery Capacity, and the message notification when there is message you have not read. When open the Bluetooth it will show on the interface too. The middle of the interface is the present time. Press top or bottom menu key for changing different function.



Lock and Unlock

Press power on/off key and "#" simultaneously to lock or unlock.

3.2 How to Use Dialer

Press the number key can make a call directly, or dial by GSM SIM card, or use the BT call to make a dial after connecting with your smart phone through Bluetooth. (There must be a SIM card in your smart phone, how to pair the Bluetooth please refer to BT3.5). If there is error in input number using the delete key to correct.

13500002344




4.1 Bluetooth Music Control

After connecting with the smart phone by Bluetooth can use the music player. (Note: Only can control music but can not play, control smart phone to play the previous and next one.)

4.1.1 How to control music

Press "OK" to enter the function interface when in the music control menu, press top and bottom key to select the previous and the next one, press "OK" to play or pause.



4.2 Record Begin Recording


Press "OK" to enter the function interface when in the recording menu, press top and bottom key to select the function you want, choose the record mark and begin to record.

Save/Pause/Give up

When recording the screen will show the record time, press "OK" will show "save/pause/give up", select function by press top and bottom key, press "OK" to confirm, press recording key to continue recording.


Play and Delete Record List

Press top or bottom key to select, press OK to enter the record list, press top or bottom key to choose that you want to play, press “OK” will show “play” or “delete”, select by press top or bottom key, press “OK” to confirm.



4.3 Bluetooth


4.3.1 Instruction of Bluetooth



Open the Bluetooth, search the Talkase Bluetooth on your smart phone, then pair it.


4.4 Contacts

Press "OK" to enter the contacts list when in the contacts menu, press top or bottom key to select SIM card contacts, Bluetooth contacts and add contacts.




4.4.1 Add Contacts

Press "OK" will show the pop-up circle in add contacts menu, press top or bottom key to input name and number to the input area, press "OK" to save or cancel. Press "#" to choose input method.




4.4.2 Call SIM Card Contacts

Press top and bottom key to choose contacts from SIM Card Contacts, then press "OK" will show "Find Contacts", "Send Message", "Call the Contacts", "Edit Contacts", "Delete Contacts", "Choose the Save Area" and so on. Press top or bottom key to select "Call the Contacts".



4.4.3 Dialer to Bluetooth Contacts

Press “OK” to enter the Bluetooth contacts, another press to choose different functions, press top or bottom key to “Text Message”, “Dial to the Contacts”, “Save to the phone book”.



Note: select contacts in the contact list, dial the BT Key or GSM Key to call directly.

Note: Press “#” could exchange input method, press “*” could choose different punctuation mark when texting message or edit the contacts’ name.


4.5 Message

Press "OK" to enter the message operation interface when in the message menu, press top or bottom key to "Text Message", "Inbox", "Drafts", "Outbox".



4.5.1 Text and Send Message

Choose "Text Message", press "OK" when the message is done and the screen will show "send", recipient could be choosed from contacts or input number directly, press "OK" to send. Press top or bottom key could choose "Save Message", "Punctuation", "Input Method" and so on.



4.5.2 Inbox

Choose "Inbox", press "OK" to enter the list, press top and bottom key to select, press "OK" to read, press again to "Reply", "Add Contacts", "Delete", "Forward", "Dial" and so on.



4.5.3 Outbox

Choose “Outbox”, Press “OK” to the list, press top or bottom key to choose, and press “OK” to read, press “OK” again to “Forward” or “Delete”.


4.5.4 Drafts

Choose “Drafts”, press “OK” to the list, press top or bottom key to choose, and press “OK” to read, “OK” again to “Send”, “Edit”, “Delete” and so on.

Note: Press “#” could exchange input method, press “*” could choose different punctuation mark when texting message or edit the contacts’ name.

4.6 Call History

Press “OK” to the call history, another press to choose and “OK” again to “Add contacts”, “Dial”, “Send Message”, “Delete Call History”.



4.7 Setting



4.7.1 Alarm Clock Setting

Enter setting-alarm, press “OK” begin to set time, Press “OK” could enjoy the following functions after setting done: “Ringtone Setting”, “Repeat Setting”, “Save Alarm Clock” and so on. The circle could become solid after successful setting.

4.7.1.1

How to turn off

Enter setting-Alarm Clock, choose the one you want to delete, press “OK” to confirm, the circle would be hollow.



4.7.2 Phone Setting

This including: “Date Setting”, “Time Setting”, “Zone Setting”, “Time Format Setting”, “System Language Setting”, “Ringtone Setting”, “Volume Setting”, “Operator Manul Setting”, “Screen display Time Setting”, Details See Below:

Phone Setting

Date Setting
Input date by keyboard

Time Setting
Input time by keyboard

Zone Setting
Top and bottom key to select
OK to confirm

Time Format Setting
Top and bottom key to select
OK to confirm

Language Setting
Top and bottom key to select
OK to confirm


Volume Setting
Volume up by top key
Volume down by bottom key

Operator Manual
Top and bottom key to select
OK to confirm

Screen Display Time
Top and bottom key to select
OK to confirm

4.7.3 Profiles

It including: “Standard Mode”, “Silent Mode”, “Conference Mode”, “Outdoors Mode”, “Airplane Mode”. Press “OK” to confirm the one you like.




4.7.4 Restore Factory Setting

Enter setting- restore factory settings, press “OK” get a notification and “OK” again could accomplish the setting, press return button to cancel. It can be restored to the initial status.



4.8 Calculator

Long press calculator key to enter when in standby interface, then Talkase will be a calculator, input number to count directly.



Anti-Lost

Press "OK" to enter Anti-Lost function, another press to switch on or off (Only available after connected by bluetooth).



Shortcut Key

1. When the Bluetooth is turned off, press return button on standby interface, "Connect by..." comes out, press "OK" can activate Bluetooth rapidly, otherwise it will be turned on by press the return button when the Bluetooth is turned off.
2. Press "#" could exchange input method, press "/*" could choose different punctuation mark when texting message or edit the contacts' name.
3. Press OK key to turn on/off the loudspeaker while in the call status.

NOTICE

This product complies with the requirement of the 1999/5/EC directive.

The maximum operating temperature of the product is 40 °C.

FCC Statement

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate(SAR)

Information SAR tests are conducted using standard operating positions accepted by the FCC with the Phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone While operating can be well below the maximum value, in general, the closer you are to a Wireless base station antenna, the lower the power output. Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each the FCC that it does not exceed the exposure limit established by the FCC, Tests for each required by the FCC.

For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the handset a minimum of 1.0cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.