

sound pop²

Congratulations on your purchase of the AudioSource® Sound pOp 2™ Bluetooth Speaker—the latest in mobile audio technology. Please retain this document for further reference and take a few moments to read this entire manual.

Please read and observe all instruction.

NOTE: If any part of this product is damaged or missing, please call your dealer or AudioSource® directly at

1.877.715.5439

Please read your warranty and retain your receipt and original carton for possible future use.

For more information about AudioSource® electronics, speakers, and accessories, please visit www.audiosource.net

AudioSource®

Specifications

Bluetooth version 4.0, Class 2
HFP v1.6, HD Voice, A2DP, AVRCP
mSBC codec for High Quality Audio
IPX4 rated water resistance
Noise Cancellation/Echo Reduction for clear calls
1.5" High definition/High efficiency driver
500mAH UL listed battery (up to 8 hours play time)
Charge using any USB port
Silicone rubber case
TPR (Thermoplastic Rubber) suction cup
Dimensions: 2.87" H, 2.65" D

Package Contents:

- Sound pOp 2™ Bluetooth Wireless Speaker
- USB Charging Cable
- Instruction Manual


Getting Started

Charging Sound pOp 2™


1. Plug included USB cable into the micro USB port on the back of Sound pOp 2™.
2. Connect USB cable to a USB port on a computer or USB power adaptor. Status Indicator LED will light solid once Sound pOp 2™ is connected to a power source.
3. Charge Sound pOp 2™ fully. This will take approximately 3-4 hours. Status Indicator LED will not appear once Sound pOp 2™ is fully charged.
4. Once Sound pOp 2™ is fully charged, Sound pOp 2™ is ready to pair with your Bluetooth device.

Features

1. Status Indicator LED: solid – charging
quick flash – pairing mode
slow flash – paired to a device
2. Power On/Off Button
3. Plus Button: short push/tap – volume up
long push/hold – track forward
4. Microphone
5. Phone Button: short push/tap – play/pause and accept/end call
long push/hold – dial most recent in call log
6. Minus Button: short push/tap – volume down
long push/hold – track backward
7. Micro USB Charging Port (reverse of displayed side)



Bluetooth Wireless Sources



In Case of Trouble

1. Ensure Sound pOp 2™ is fully charged, Sound pOp 2™ will not be able to pair if Sound pOp 2™ is not charged.
2. Turn Sound pOp 2™ off and retry "Pairing Sound pOp 2™."
3. Ensure Bluetooth is enabled on your device and retry "Pairing Sound pOp 2™."
4. Move Sound pOp closer to your Bluetooth device and retry "Pairing Sound pOp 2™."
5. Try pairing Sound pOp 2™ with a different Bluetooth device.
6. Sound pOp 2™ will not be able to pair if currently paired to a device (Status Indicator LED will flash slowly). Try unpairing with other devices and retry "Pairing Sound pOp 2™."

For Further Assistance

Please visit our website at www.audiosource.net or contact our customer service department at support@audiosource.net or call us at **1.877.715.5439**
Limited Warranty

AudioSource, a division of Peak Audio Group, warrants this product against defects in materials and workmanship for a limited period of time. For a period of 90 days from date of original purchase, we will repair or replace the product, at our option, without charge for parts. The limited warranty period for factory refurbished products expires after ninety (90) days from date of original purchase. This limited warranty applies only to purchases from authorized AudioSource Retailers or Distributors. This limited warranty is extended only to the original purchaser and is valid only to consumers in the United States.

Consumers are required to provide a copy of the original sales invoice from an authorized AudioSource Retailer or Distributor when making a claim against this limited warranty. This limited warranty only covers failures due to defects in materials or workmanship that occur during normal use. It does not cover failures resulting from accident, fire, flood, misuse, abuse, neglect, mishandling, missapplication, alteration, faulty installation, modification, service by anyone other than AudioSource, or damage that is attributable to Acts of God. It does not cover costs of transportation to AudioSource or damage in transit. The customer should return their defective product, freight prepaid and insured, to AudioSource only after receiving a Return Authorization.

Repair or replacement under the terms of this warranty does not extend the term of this warranty. Should a product prove to be defective in workmanship or material, the consumer's sole remedies will be repair or replacement as provided under the terms of this warranty. If the defective product is discontinued, AudioSource may replace the product with an equivalent or superior product at its option. Under no circumstances shall AudioSource be liable for loss or damage, direct, consequential or incidental, arising out of the use of or inability to use the product. There are no express warranties other than described above.

Sound pOp 2 Owner's Manual 8100.SOUNDPOP2

AudioSource ©2014

13970 SW 72nd Ave, Portland, OR 97223

www.audiosource.net



■ AudioSource®

www.audiosource.net

FCC Statement

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Important Notice!


Please use the special tab on the suction cup to remove it from the surface it is adhered to.

Please do not try to pull Sound pOp 2™ off by pulling on the body as it could damage the unit.

Please note that the suction cup adhesion time will vary depending on the surface it is attached to.

Surface texture, temperature, and debris can all reduce adhesion time.

Follow Us!



@SoundpOpAudio

Like Us!



/SoundpOpAudio

IF FCC ID could not be found on the silicon shell, you might find the same marking

FCC ID: 2AC6P-SOUNDPOP2 on plastic shell by removing the silicon.

FCC WARNING

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.