User Manual

Model: SOLE B240 AK47

Brand: SOLE

Declaration

Please read the user's manual so as to keep your mobile phone in the best condition. The manual has been verified and reviewed to guarantee the accuracy. Instructions and descriptions contained herein are accurate at the time of publication. However, mobile phones developed afterwards and the contents of their manual are subject to modification without further notification. Our company reserves the rights in relation to the manual.

Overview

Please read the following concise rules carefully. Nonobservance to the rules may lead to danger or violence of the laws. The user's manual gives details about the safety precautions.

■ Emergency call

Make sure the equipment is in the covered area of the network service and the calling f unction is activated. As per the specific requirements, press the key of finish to clear the screen and return to the standby state. Input the emergency call number (112) and press the call key.

■ Function Description

The phone is a perfect combination of humanized design and exquisite workmanship, the streamline and ingenious body is comfortable to hold. With streamline and ingenious frame, it feels comfortable to hold the mobile phone in your hand. It supports TXT electronic book, Blue-tooth, dual SIM cards with one standby, network camera, camera, FM and etc. It makes your work more convenient and your free time more fun with the combination of keyboard, florid colored screen, pleasant bells, cartoon head portrait for incoming calls, strong file management function (supporting T-FLASH card), fashionable camera function and long time tape recording function, music player, video player.

Introduction

Insert the SIM card and the battery

Ask your SIM card dealer whether he has provided SIM card service and the method of usage who may be service provider or other dealers, SIM card and its contacts are vulnerable to scratch or bending. Attention shall be attached when use, insert or take out the card.

■ Inserting/taking out T-FLASH CARD

Only use approved and compatible T-FLASH card applicable to the mobile phone.

Approved memory card trade standard is applied; however, certain bands may not be completely compatible with the mobile phone. Using incompatible memory card may

damage not only the card and the mobile, but also the data stored in the card.

Charging the battery

Check the model number of the charger before using it to charge the mobile. Only use approved battery, charger and accessories applicable to the specific mobile model. Using other types of battery, charger and accessories may violate the certification or warranty terms of the equipment and may result in danger, Refer to the dealer for supply of relative approved accessories.

Startup and shutdown

Press the key of power supply to start up or shut down the mobile phone. If it is prompted to input PIN or UPIN, please input the required password (shown as **** on the screen).

Function of main menu

Contacts

You my save the information of contacts including names and telephone numbers in the phonebook.

Message

Write a message: You may select to send the finished message from SIM card 1 or SIM card You may select multiple receivers to send the message to more than 1 person.

■ Call logs

Information, invites the menu \rightarrow choosing if needing to check your communicating by phone \rightarrow Communicate by phone centre \rightarrow Communicate by phone taking notes \rightarrow SIM card 1 communicates by phone recording/ SIM card 2 communicates by phone taking notes \rightarrow SIM card 1/ SIM card 2 possessions telephone, SIM card 1/ SIM card 2 has not answered the phone, SIM card 1/ SIM card 2 already answers the

phone or 2 already batches of SIM card 1/ SIM card telephone.

Settings

Call settings

This is some of the communications settings. There are have Dual-SM, Call divert, Call waiting, Call barring, Hide ID ant others.

Phone settings

- **1.1.Date&Time**: You can set the phone's time and date and the format.
- 1.2.Language Settings: You can select the phone's display language .
- **1.3.Auto power on/off:**After setting the time, and by that time the phone will auto power on/off.
 - 1.4.Power management:Battery remains.
- 1.5.Restore factory settings:Enter the correct password of the phone will have to change your phone settings back to factory default state value, the user of the function be used with caution. (Default password: 1234).

Display

- 1.1.Wallpaper:Set wallpaper.
- 1.2.**Idle display settings:** You can choose to display or not display.
- 1.3. Contrast&Backlight&Keypad backlight time: The menu is to control of mobile phone screen brightness and Keypad backlight time.

Security

You can manage your phone safely with this function.

The phone lock password, SIM card and PIN2 support 4-8digit numbers, do not support other characters. The password and PIN2 and SIM card are provided by the network operator. When the PIN/PIN2 is input wrongly in successively.

Connections

You can set up the phone network with this function.

SIM1/SIM2network settings

Network selection:choice the modes of searching the phone network,including Auto and Manual modes.

■ Multimedia

■ Camera

In the options of camera, you may set the photometry mode, flash light, exposure compensation, avoidance of flickering, postponing shooting, white balance, photo quality, photo size, special effect, profile and etc. You may enter the album to check the formats that the cell phone supports.

Image viewer

Check the pictures in the memorial card in formats supported by the cell phone.

■ Video Recorder

phone provides video recording, select video footage that can enter the video recording. In the preview video press OK button to begin, press stop again, can have white balance, exposure compensation, night mode, avoid flashing to set one by one. Settings are stored path cell phone or memory card. Restore all the camera options of setting for the system default values.

■ Video player

Check the video files in the memory card supported by the cell phone. Play your favorite video files.

■ Sound Recorder

Open the recording function, can pause, stop and play. After recording, the recording can be played

■ FM radio

Turn on FM broadcast, and you may press the direction keys of left and right to manually tune the channel. Press the direction key of upward to turn on or off the auto-searching mode. Press OK to record the FM broadcast. Press the direction key of downward to turn on or off FM broadcast. In the options, you may set manually or automatically searching for channels, turning off the background during broadcasting as well as the format of recording thereof.

My Files

Phone & memory card

The File Manager list the all the files stored in your phone or memory card.you can new folder, delete folder, view the detail, edit folder (rename, copy, cut), search folder, mark folder, sort the folder, and view the memory status.

Profiles

There are generally 6 kinds of models (Normal, Silent, Meeting, Indoor, Outdoor,BT). You can start, custom, rename, the ring settings, adjust the volume, ringing mode (including Silent, ringtones, vibration) and other ring mode operation (including ring volume adjustment, caller ID, information prompt, alarm, voice tone, low voltage, the switch machine set).

Audio

The music player is used to play music files in supported formats in the current player's list. You may view details of the music files and set the current music file as the ring signal for incoming call. You can enjoy the music with this function.

Extras

Calendar

calendar this feature allows you to view the calendar. In the calendar interface, press left soft key, you can make a new schedule, check the schedule, all schedule, empty, empty all, go to the date that day, weekly show operation, etc.

■ Alarm

Set the time of alarm clock, ring signal, ring mode, alarm ring mode and interval between repeated alarm rings.

■ Torch

Turn on or off the flashlight.

■ Bluetooth

You may establish wireless connection with other compatible devices with the Bluetooth technology; you may send images, videos, music files and etc. with the Bluetooth technology.

■ Calculator

Make a simple calculation.

Internet

your mobile Internet support based on wireless application protocol (WAP) service. You can access a variety of WAP service. WAP service need network support, the WAP service availability, price and tax, please contact your network operator or provide you with the service providers of services required.

STK

This function by the network providers, according to the SIM card provides ser vices will appear different menu options. If a SIM card and network supplier do es not support this service, this function will not be used. If you need to get more information please contact with network providers.

3. PC connect

■ USB

Use the T-Flash inserted in the mobile phone as U-Disk. You can transfer music, videos, games and other files form PC to the T-Flash by USB cable. Enjoy it anytime and anywhere.

■ COM PORT

Establish a modem on the local computer and construct a network, and the serial interface is connected after signing in with the account.

4. Maintenance and service

Refer to the local dealer for supply of accessories. Hereafter are some precautions for

usage of the accessories, Only use batteries, chargers and accessories approved by the manufacturer. Usage of other types of batteries, chargers and accessories may result in violence of the certification or warranty terms or even lead to danger, Keep the equipment dry, Don't keep the equipment in under cooled places; otherwise, when the temperature rises to normal, moisture may be generated within the equipment, resulting in damage of the circuit board. Only use matched or approved antenna.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This mobile phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: mobile phone (FCC ID: 2AC7ISOLEB240) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.510W/kg and when properly worn on the body is 0.487W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.