


Internal Picture

Internal view of EUT




Internal view of EUT




Internal view of EUT




Front view of PCB




Internal view of EUT




Antenna of EUT




Back view of PCB



Internal battery pack (EVE PL401223GH)



Internal battery pack (Everpower PL401224H)



Internal battery pack (ATL PL401323)

