

GARAGE AMOUR OPERATION INSTRUCTION G2

Syncing your new Remote Control to your Control Module

1. Press and release the “Learning Switch” located on the right side of the Control Module. You may need a pen to push this.
2. Indicator on the Module will turn Yellow and will beep once.
3. Press and release the “0” button on your new Remote. The indicator on the Module will turn off and will beep once. This confirms proper programing of the Remote Control to the Control Module. Note that this must be done within 10 seconds or the system will exit.
4. Up to 10 Remotes can be programmed to one Control Module.

Program your Password

1. Press and release the “Learning Switch” on the Control Module.
2. Press and release the “#” button on the Remote Control you wish to program that has already been synced with your Control Module and Indicator will turn Red.
3. Enter your 3 to 8 digit code (using number 0 to 9) then press enter.
4. Indicator will turn off and beep twice to confirm entry.
5. To change password simply repeat.

Using Remote to Open your Door Among Three Doors

1. Input your new 3 to 8 digit code.
2. Press enter.
3. Input door no.1 or no.2 or no.3 at the same time and press Enter
4. Buzzer will beep twice, indicator will turn green and door will open.
5. Press Enter to reverse.

Note: For security purpose, 5 incorrect entries will result in a long warning beep and require resynchronization.

Using Remote to Open your Two Doors Among Three Doors At The Same Time

6. Input your new 3 to 8 digit code.
7. Press enter.
8. Input door no.1 no.2 or no.2 no.3 or no.1 no.3 or no.1 no.2 no.3 and then press Enter
9. Buzzer will beep twice, indicator will turn green and door will open.
10. Press Enter to reverse.

Note: For security purpose, 5 incorrect entries will result in a long warning beep and require resynchronization.

You might enter any series of digits prior to your real code so as long as your last inputted digits are correct, then enter and the door will open.

Pressing Enter again within 15 seconds will stop the operation of the opening of your garage door. You may hit Enter repeatedly to open and stop the opening. Press the “#” button to stop this function.

To Erase Password from Remote Control Memory

1. Press and hold “Learning Switch” for 3 seconds.
2. Buzzer will beep 3 times, indicator light will turn off.

The Button on Receiver:

The button on the receiver is only functional for the door no. 1.

NOTICE :

The changes or modifications not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est