
RADIO CONTROL RACING DRIVER




RADIO CONTROL RACING DRIVER

REALISTIC FAMOUS

OOR CAN BE OPENED





SUPER 458 1: 14 R/C model


SUPER THE CAR

- 1. While playing the remote control car indoors, please take care
- not to cause any damage of the furniture or glasses. 2. In case of any danger, don't play in the road or crowd. Please
- play it in safe places outdoors. 3. While playing it outdoors, if there is thunder, stop playing it at once.
- 4. To avoid the malfunction of the circuit, please don't play it in places with water or sand.
- 5. Never fold the antenna improperly. If it's broken, its sharp part
- 6. Don't drag the wire of its body, because it may lose some functions when the wire is broken. 7. When the wheels are running, never touch them with hands to
- avoid injury. Pay attention not to entangle hair or clothes etc.
- 8. Never run the remote control car towards people. 9. Never leave about or crash the remote control car.
- 10. Please keep the remote control car away from fire or heat. 11. This car is equipped with complicated circuits and electronic parts.
- Please don't disassemble or refit the circuit board. 12. When the car slows down or it's out of control, please replace it
- 13. In order to prolong batteries, please do as follows: * Please remove batteries when it's not used for a long time. * While replacing it with new batteries, use the new ones only. Don't mix new and old ones.

Caution for using batteries:

- While placing batteries, please insert them as per the polarities.
- Never mix new and old batteries.
- Don't charge the non-rechargeable batteries. Please don't mix alkaline, carbonic or rechargeable batteries.
- When the car is not used, batteries must be taken out. Please check its wires, plug, outer cover and other parts regularly.

If any of them is damaged, please stop using and repair it.







partes pequeñas, No recomendado

para niños menores de 3 años.













